Order No. MD0303077C1
A6

CD Stereo System

COMPACT
disc
DIGITAL AUDIO

SA-PM16P

Color
(S) ... Silver Type



SPECIFICATIONS

Specification

■ Amplifier Section

Power output	
10% Total harmonic distortion	
60 Hz - 3 kHz, both channels driven	20 W per channel (6 Ω)
(Low channel)	
3 kHz - 16 kHz, both channels driven	20 W per channel (6 Ω)
(High channel)	
Total Bi-Amp power	40 W per channel
Power output	
10% Total harmonic distortion	
1 kHz, both channels driven (Low channel)	25 W per channel (6 Ω)
8 kHz, both channels driven (High channel)	25 W per channel (6 Ω)
Total Bi-Amp power	50 W per channel
Input sensitivity	
AUX	250 mV
Input impedance	
AUX	19.8 kΩ

■ FM Tuner Section

Frequency range	87.9 - 107.9 MHz (200 kHz steps) 87.5 - 108.0 MHz (100 kHz steps)
Sensitivity	2.5 μV (IHF)
S/N 26 dB	2.4 μV
Antenna terminal	75 Ω (unbalanced)

■ AM Tuner Section

Frequency range	520 - 1710 kHz (10 kHz steps)
Sensitivity	
S/N 20 dB (at 999 kHz)	560 μV/m

■ Cassette Deck Section

Track system	**4 track, 2 channel**
Heads	
Record/playback	**Solid permalloy head**
Erasure	**Double gap ferrite head**
Motor	**DC servo motor**
Recording system	**AC bias 100 kHz**
Erasing system	**AC erase 100 kHz**
Tape speed	**4.8 cm/s (1-7/8 ips)**
Overall frequency response (+3 to -6 dB at Deck Out)	
Normal (Type I)	**35 Hz - 14 kHz**
S/N	**50 dB (A weighted)**
Wow and flutter	**0.18% (WRMS)**
Fast forward and rewind time	**Approx. 120 seconds with C-60 cassette tape**

■ CD Section

Sampling frequency	**44.1 kHz**
Decoding	**16 bit linear**
Beam source/ Wavelength	**Semiconductor laser / 780 nm**
Number of channels	**Stereo**
Frequency response	**20 Hz - 20 kHz (+1, -2dB)**
Wow and flutter	**Below measurable limit**
Digital filter	**8 fs**
D/A converter	**MASH (1 bit DAC)**

■ General

Power supply	**AC 120 V, 60 Hz**
Power consumption	**105 W**
Power consumption standby mode	**0.45 W**
Dimensions (W x H x D)	**179 x 247 x 378 mm** **(7 -1/16” x 9-23/32” x 14-7/8”)**
Mass	**5.25 kg (11.7 lb.)**
■ System: SC-PM16 (P)-S	**Music Center: SA-PM16 (P)-S** **Speaker: SB-PM18 (P)-MA**

Notes:

1. **Specifications are subject to change without notice. / Mass and dimensions are approximate.**
2. **Total harmonic distortion is measured by the digital spectrum analyzer.**

© 2003 Matsushita Electronics (S) Pte. Ltd. All rights reserved.
Unauthorized copying and distribution is a violation of law.

⚠ **WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Panasonic

1. Safety Precaution

(This “Safety Precaution” is applied only in U.S.A.)

1. **Before servicing, unplug the power cord to prevent an electric shock.**
2. **When replacing parts, use only manufacturer’s recommended components for safety.**
3. **Check the condition of the power cord. Replace if wear or damage is evident.**
4. **After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.**
5. **Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.**

- **Insulation Resistance Test**

1. **Unplug the power cord and short the two prongs of the plug with a jumper wire.**
2. **Turn on the power switch.**
3. **Measure the resistance value with ohmmeter between the jumper AC plug and each exposed metal cabinet part, such as screw heads, antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between 3M Ω and 5.2M Ω to all exposed parts*. (Fig 1) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig 2)**
   ***Note: Some exposed parts may be isolated from the chassis by design. These will read infinity.**
4. **If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.**

Fig. 1


Antenna terminal
Exposed metal part
Ohmmeter
Resistance = 3MΩ - 5.2MΩ

Fig. 2


Exposed metal part
Resistance = Approx. ∞
Ohmmeter

2. Before Repair and Adjustment

Disconnect AC power, discharge Power Supply Capacitors C506, C507, C508, C576, C577, C587, C588, C601, C602 and C615 through a 10 Ω, 5 W resistor to ground. DO NOT SHORT-CIRCUIT DIRECTLY (with a screw driver blade, for instance), as this may destroy solid state devices.
After repairs are completed, restore power gradually using a variac, to avoid over current.
Current consumption at AC 120 V, 60 Hz in NO SIGNAL mode should be ~300 mA.

3. Protection Circuitry

The protection circuitry may have operated if either of the following conditions are noticed:

- No sound is heard when the power is turned on.

- Stops during a performance.

The function of this circuitry is to prevent circuitry damage if, for example, the positive and negative speaker connection wires are “shorted”, or if speaker systems with an impedance less than the indicated rated impedance of the amplifier are used.
If this occurs, follow the procedure outlines below:

1. Turn off the power.

2. Determine the cause of the problem and correct it.

3. Turn on the power once again after one minute.

Note:

When the protection circuitry functions, the unit will not operate unless the power is first turned off and then on again.

4. Accessories

AC Power Supply Cord.....1 pc



AM Loop Antenna.....1 pc



FM Indoor Antenna.....1 pc



Remote Control Transmitter.....1 pc



5. Front Panel Controls



Front panel controls

Main unit

①**Cassette lid**

②**Cassette open button (≜ OPEN)**

③**AC supply indicator (AC IN)**
This indicator lights when the unit is connected to the AC mains supply.

④**Standby/on switch (⏻/I POWER)**
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.

⑤**Aux button (AUX)**

⑥**CD skip/search, tape fast-forward/rewind/TPS, tune/ preset channel select, time adjust buttons (▶▶I ∧/FF, I◀◀ ∨/REW)**

⑦**CD check button (CD CHECK)**

⑧**CD trays**

⑨**Tape indicator**
This indicator changes in the following manner:
ⓐ Orange (when no cassette is inserted.)
ⓑ Green (when cassette is inserted.)
ⓒ Red (when in recording mode.)

⑩**Display**

⑪**Recording start/pause button (●/II REC)**

⑫**Super sound EQ button (S.SOUND EQ)**

⑬**Volume control (VOLUME DOWN, UP)**

⑭**CD tray open/close button (≜ OPEN/CLOSE)**

⑮**CD change button (≜ CD CHANGE)**

⑯**Headphone jack (PHONES)**

⑰**Stop/program clear and demonstration button (STOP ■, –DEMO)**

⑱**Tuner/band select button (TUNER/BAND)**

⑲**Cassette play button (TAPE ▶)**

⑳**CD play/pause button (CD ▶/II)**

㉑**Disc direct play buttons (CD 1~CD 5**)



Front panel controls

Remote Control

Buttons such as ❹ function in exactly the same way as the buttons on the main unit.

㉒**Sleep timer/auto off button (SLEEP, –AUTO OFF)**

㉓**Disc button (DISC)**

㉔**Play mode select button (PLAY MODE)**

Use this for selecting repeat mode, CD play mode, tune mode, FM mode and AM beat proof function.

㉕**CD Program, tuner preset button (PGM)**

㉖**Muting button (MUTING)**

㉗**Preset EQ select button (PRESET EQ)**

㉘**Play timer/recording timer button (⊙PLAY/REC)**

㉙**Clock/timer button (CLOCK/TIMER)**

㉚**Numeric buttons (≧10, 1–9, 0)**

㉛**Stop/program clear button (■ CLEAR)**

㉜**Dimmer button (DIMMER)**

㉝**Display button (DISPLAY)**

6. Handling Precautions For Traverse Deck

The laser diode in the traverse deck (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body. So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

- Handling of traverse deck (optical pickup)

1. **Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.**
2. **To prevent the breakdown of the laser diode, an antistatic shorting pin is inserted into the flexible board (FFC board).**
3. **Take care not to apply excessive stress to the flexible board (FFC board). When removing or connecting the short pin, finish the job in as short time as possible.**
4. **Do not turn the variable resistor (laser power adjustment). It has already been adjusted.**

- Grounding for electrostatic breakdown prevention

1. **Human body grounding**
   Use the anti-static wrist strap to discharge the static electricity from your body.
2. **Work table grounding.**
   Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is place, and ground the sheet.

Caution:

The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).

on when replacing the Traverse Deck

The traverse deck has a short point shorted with solder to protect the laser diode against electrostatics breakdown. Be sure to remove the solder from the short point before making connections.


Flexible board
FPC
(Handle it carefully)
Lens
(Do not touch)
Short land
Optical pickup
No. 5 Pin (GND)
No. 4 Pin (LD)
Variable resistor
(Do not turn)


Wrist strap
(Anti-static Bracelet)
1 MΩ
Iron plate or some metals
to conduct electricity

7. Handling the Lead-free Solder

7.1. About lead free solder (PbF)

Distinction of PbF P.C.B.:

P.C.B.s (manufactured) using lead free solder will have a PbF stamp on the P.C.B.

Caution:

- Pb free solder has a higher melting point than standard solder;

Typically the melting point is 50 - 70°F (30 - 40°C) higher. Please use a high temperature soldering iron. In case of soldering iron with temperature control, please set it to 700 ± 20°F (370 ± 10°C).

- Pb free solder will tend to splash when heated too high (about 1100°F/600°C).
- When soldering or unsoldering, please completely remove all of the solder on the pins or solder area, and be sure to heat the soldering points with the Pb free solder until it melts enough.

8. Disassembly and Main Component Replacement Procedures.

“ATTENTION SERVICER”
Some chassis components maybe have sharp edges. Be careful when diassembling and servicing.

1. This section describes procedures for checking the operation of the major printed circuit boards and replacing the main components.
2. For reassembly after operation checks or replacement, reverse the respective procedures. / Special reassembly procedures are described only when required.
3. Select items from the following index when checks or replacement are required.
4. Refer the Parts No. on the page of “Main component Replacement Procedures”, if necessary.

Content

- Disassembly Procedure for each major P.C.B.
- Disassembly of CD Loading Unit
- Disassembly of CD Loading Section
- Disassembly of Traverse Mechanism
- Main Component Replacement Procedures
  1. dure for replacing Cassette Holder
  2. Procedure for replacing Pinch Roller and Head Block (Cassette Mechanism Unit)

3. Procedure for replacing Motor, Capstan Belt A, Capstan Belt B and Winding Belt (Cassette Mechanism Unit)
4. Procedure for replacing Parts on Mechanism P.C.B
5. Replacement for CD Traverse Deck
6. Replacement for Optical Pickup Unit (CD Mechanism)
7. Replacement for a Traverse Gear A and a Traverse Gear B
8. Replacement for Disk Tray
9. Replacement for the Traverse Mechanism
10. Replacement for CD Loading Unit

Assembly of CD Loading Unit
Handling of Cassette Tape jam

Warning:

This product uses a laser diode. Refer to "Precaution of Laser Diode".

8.1. Checking for Major P.C.B.

8.1.1. Checking for Main & AC Transformer P.C.B.



Step 1 Remove all the screws.
Step 2 Remove side panel.

- Checking for Main P.C.B.




(Step 3)
b x 2
(Step 3)
a x 4
(Step 4)

Step 3 Remove all the screws.
Step 4 Remove side panel.

- Checking for AC Transformer P.C.B.


AC Transformer P.C.B.

8.1.2. Checking for Deck P.C.B. and Deck Mechanism P.C.B.

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

Step 1 Remove one screw at the rear chassis.

Step 2 Release a claws at both ends, and lift up the (Deck Mechanism) (Top unit).


Claw
(Step 1)
b x 1

- Checking for Deck P.C.B. and Deck Mechanism P.C.B.


Deck P.C.B.
Deck Mechanism P.C.B.

8.1.3. Checking for Panel P.C.B.

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

Step 1 Release connector CN1303 & CN1304. Upset the Top cabinet.


Top cabinet
FFC's

Step 2 Release 2 claws. Disconnect CN505 & CN500.



Step 3 Remove 2 screws.



Step 4 Push front panel forward as arrow shown.

- Checking for Panel P.C.B.



8.1.4. Checking for Headphone P.C.B., AC Led P.C.B. ,Tact Switch P.C.B. , CD Servo P.C.B. & CD Loading P.C.B.

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 4) of Item 8.1.3.

Step 1 Disconnect CN305, CN606 and CN500.



- Checking for Headphone, AC Led & Tact Switch P.C.B.


AC Led
P.C.B.
Headphone
P.C.B.
Tact Switch
P.C.B.

Step 2 Remove FFC and connector CN310 (Fan unit).



Step 3 Remove all screws (back cabinet).


Back cabinet
a
a x 9
Step 5

Step 4 Pull the back cabinet backward.
Step 5 Remove all screws.


Step 6
b x 2
Step 5
b x 2

Step 6 Remove all screws.
Step 7 Lift up the middle unit as the arrow shown above.



Step 8 Remove 2 screws. Upset the CD Unit sideway.

- Checking for CD Servo P.C.B. and CD Loading P.C.B.


CD Servo P.C.B.
CD Loading P.C.B.

8.1.5. Replacement of the Power Amplifier IC

- Replacement of the Power Amplifier IC

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 4) of Item 8.1.3.

- Follow the (Step 1) - (Step 8) of Item 8.1.4.


Power Amp IC
IC500
(RSN314H41A-P)
Step 3
d x 2
d
Heat
Sink
Power P.C.B.

Step 1 Remove 2 connector CP501 and CP504 and pull out the Main P.C.B.

Step 2 Remove 2 screws fixed to the Power Amp I.C.


Solder terminal

Step 4 Unsolder the terminals of Power Amp IC, transistor and replace the component.

8.2. Procedure for Replacing Cassette Holder

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.


Step 3
Remove the
cassette
mechanism unit.
a
a
Step 1
a × 4
a
Cassette cover
lever

Step 2 Press the lever to open the cassette cover.



Step 4

Lift up the cassette cover to the arrow direction to remove.

Cassette Cover



Step 5

Pull out the ribs of the cassette holder to the arrow direction.

Cassette Holder
Rib
Rib
Cassette Holder
Cassette Holder



Step 6

Remove the cassette holder.

Step 7

Remove the cassette open spring.

8.3. Procedure for Replacing Pinch Roller and Head Block (Cassette Mechanism Unit)

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 3) of Item 8.2.


Step 1

Release catches to remove the pinch rollers (R) and (F).
Pinch Roller (R)
Pinch Roller (L)
Catch
Catch


Note:
Support the Mechanism PCB by hand to remove the Mechanism Control PCB.

Step 4

Remove the Mechanism Control PCB, keeping track of connectors

Step 2

ⓐ × 3

Step 3

Remove 2 solders of the motor terminal.
Mechanism PCB
ⓐ
ⓐ
Mechanism Control PCB
White Line
Solder


Step 7

Remove the head block.

Step 6

ⓑ × 2

Step 5

Release the catches to remove the head connector.
ⓑ
①
①
②
Catch
Catch
Head Connector

8.4. Procedure for Replacing Motor, Capstan Belt A, Capstan Belt B, and Winding Belt (Cassette Mechanism Unit)

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 3) of Item 8.2.


Step 3
Remove the sub chassis.
Step 2
ⓐ × 3
ⓐ
ⓐ
Head Connector
Catch
Catch
①
②
①
Step 1
Release the catches to remove the head connector.


Step 5
ⓑ × 2
ⓑ
Step 4
Remove the capstan belt.
Capstan Motor


Tape Facing Side
Catch
Step 6
Remove the flywheel (R).
Winding Belt
(RDV0033-1)
Step 7
Release the catch on the tape facing side to remove the winding lever and spring.
Step 8
Remove the flywheel (F).

Installing Belt


Boss
Marking
Boss
Boss

Step 1

The positions of boss and marking hole should be horizontal to each other.

Step 2

Install the winding belt temporarily as shown in the figure above.

Step 3

Attach the flywheel (F).


Flywheel
Winding Belt
Tweezers

Step 4

Catch the winding belt on the flywheel (F).


Winding Arm

Step 6

Attach the flywheel (R).

Step 5

Install the winding lever and spring while the winding arm is pressed to the arrow direction. (Be sure that the winding lever is firmly inserted and the catch is hooked.)

Note:

The winding lever should be positioned as shown in the right figure.


Winding Lever
Winding Arm
Winding Belt

Step 7

Install the capstan belt temporarily as shown in the figure below.


Boss
Capstan Belt
Boss


Capstan Belt

Side View

Note:
Keep the belt away from grease.


a
a
a
Cassette Mechanism Unit

Step 9
a × 3

Step 8
Attach the sub chassis to the cassette mechanism.


Capstan Belt
Boss

Step 10
Catch the capstan belt to the pulley of the capstan motor.

8.5. Procedure for Replacing Parts on Mechanism PCB

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 3) of Item 8.2.


Step 1

Step 3
Remove 3 catches to remove the Mechanism PCB.

Step 2
Remove the solders of the plunger terminal.

a
Catch
Catch

8.6. Replacement of CD traverse deck

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 4) of Item 8.1.3.

- Follow the (Step 1) - (Step 8) of Item 8.1.4.


Step 1
Move ribs at both sides to the arrow direction
(The vertical rack (R) slides and the groove opens)

(Bottom side)
Vertical rack (R)
Boss
Groove
Traverse deck
Rib
Rib


Step 2
Remove CD traverse deck rotating to the arrow direction.

8.7. Replacement of optical pickup unit (CD mechanism)

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.1.2.

- Follow the (Step 1) - (Step 2) of Item 8.6.


Step 2
Widening the catch, push the pin in
(2)
Pin
(1)
(1)
Catch
Step 1
Pull out FFC

Step 3

Remove 4 pins



Step 4

Remove the traverse deck (JUN)


Floating spring
Floating spring

Note:
As floating springs (4 pieces) come off at the same time, be careful not to lose them.

Step 7
Remove CD servo board and turn it over.

Step 5



b × 3
Welding
b
b
Welding

Step 6
Remove 4 welded parts of the motor terminal.

Step 8
Pull FFC out from the connector.



Note:
Insert a short pin into FFC of the optical pickup.
[See "Notice on handling of the optical pickup"]



FFC
Short pin

Step 9
Rotate the traverse deck (B) to the arrow direction and shift the optical pickup to the furthest backward.



Optical pickup
Traverse gear (B)

Step 10




Drive rack
Catch

Step 11

Remove the catch of the drive rack, and take out the drive rack.


Optical pickup
Concave part of traverse base
Convex part of optical pickup

Step 12
Place the convex part of an optical pickup to the concave part of a traverse base, then take out the optical pickup.


Lens
Optical pickup

Note:
Do not touch the lens of the optical pickup

8.8. Replacement of a traverse gear A and a traverse gear B

- Follow the (Step 1) - (Step 4) of Item 8.1.1.

- Follow the (Step 1) - (Step 2) of Item 8.6.

- Follow the (Step 1) - (Step 12) of Item 8.7.

Step 1
Rotate the traverse gear (B) to the arrow direction, and shift the optical pickup to the furthest backward.


Optical pickup
Traverse gear (B)



Step 2
Insert a fine edged flat head screwdriver into the hole of CD servo board and push the catch of the traverse gear (B), then pull the traverse gear (B) out.

Note:
Be careful not to break the hook of the traverse gear (B)

Step 3
Remove the traverse gear (B).

Step 4
Remove the traverse gear (A).



Note:
Do not use the removed traverse gear (B) anymore.
Surely replace with a new one.

8.9. Procedure for removing CD loading mechanism

1. Turn off by pressing power SW in the body.

2. Unplug AC power cord after the indication of [GOOD-BYE], then disassemble the body.

3. Disassemble the body, and take out CD loading mechanism.

4. Perform disassembly according to the following procedure for disassembly.

8.10. CR16 mechanism disassembly procedure

8.10.1. Gear for servicing information

- **This unit has a gear which used for checking items (open/close of disc tray, up/down operation of traverse unit by manually) when servicing. (For gear information, that is described on the items for disassembly procedures.)**
- **For preparation of gear (for servicing), perform the procedures as follows.**
- **In case of re-servicing the same set, the “gear for servicing” may be took off because it had been used. So, the “gear for servicing” must be stored.**

1. Remove the gear attached to top cover of CD loading mechanism.


Cut these portion to take the gear off.
Top cover

2. Insert the hexagonal wrench (2.5mm) into the gear.


Gear
Hexagonal wrench

(Preparation of gear as jig is completed)

8.10.2. Replacement for the disc tray

(Step 1)
Rotate the gear for servicing and move the select rack to advanced corner.


Select rack
Gear for servicing
(as jig)

(Step 2)
Fit the mechanism unit base to select rack.


Select rack
Mechanism unit base
Advanced corner

(Step 3)
Release the 2 claws, and then remove the top cover.


Push
Claw
Top cover
Push
Claw

(Step 4)
Remove the open switch lever.


Minus screwdriver
Open switch lever

Push the open switch lever with minus screwdriver.

(Step 5)
Release the claw, and then remove the speed up lock.


Claw
Speed up lock



Insert the tweezers between the mechanism base and disc tray, and then lift up the disc tray.

(Step 6)
Draw out all dise tray completely.

(Step 7)
Release the both claws, and then lift up the disc tray.

Lift up the disc tray.

Tweezers
(2)
Claw
(3)
(1)
Disc tray
(2)
Claw

(Step 8)
Remove the 5 pieces of disc tray.




Tweezers
Tray gear shaft
Tray drive gear ass'y

(Step 9)
Pull out the tray gear shaft with tweezers.

(Step 10)
Remove the tray drive gear ass'y.

8.10.3. Replacement for the traverse deck

- Follow the (Step 1) - (Step 10) of item 8.10.2.

(Step 1)
Confirm the position for lever of UD. rack (R) to remove traverse unit.

(Step 2)
Turn the unit over. (Upside: P.C.B.)


Lever of UD. rack (R)
(Locked here)
NOTE: not this

(Step 3)
Turn the unit over again, slide UD. rack (R) while pushing up the lever from the bottom.


Lever
UD. rack (R)
(1)
(2)

(Step 4)
Remove the traverse unit.



8.10.4. Disassembly for CD loading unit

- Follow the (Step 1) - (Step 10) of item 8.10.2.

- Follow the (Step 1) - (Step 4) of item 8.10.3.


Separate lever (1)
UD. connection lever
ⓐ
Claw
Pitch plate
ⓐ
Claw
Claws

(Step 1)
ⓐ × 3

(Step 2)
Release the 4 claws, and then remove the pitch plate together with separate lever (1) and UD. connection lever.

(Step 3)
Remove the speed up gear and hor belt.


Speed up gear
Hor belt

(Step 4)
Remove the reverse gear, hor pulley gear, hor speed down gear (1), hor speed down gear (2) and hor drive gear.


(2) Hor pulley gear
(1) Reverse gear
(3) Hor speed down gear (1)
(4) Hor speed down gear (2)
(5) Hor drive gear

(Step 5)
Remove the UD. belt and tray relay gear.

(Step 6)
Pull out the UD. pulley gear, loosen 2 hooks of the bottom of mechanism bese.


UD. belt
Tray relay gear
UD. pulley gear
Hooks
(Bottom side)

(Step 7)
Remove the 2 hor relay gears and UD. speed down gear No.2.


Hor relay gears
UD. speed down gear No.2

(Step 8)
Remove the main gear and main gear spring.


Main gear
Main gear spring

(Step 9)
Remove the change gear.

(Step 10)
Raise the change lever upright, and pull it out of hook.


Change gear
Change lever
Hook
Hook

(Step 11)


Claw
Claw
Timing gear plate
ⓑ
Timing gear plate
Timing gear

(Step 12)
Release the 2 claws, and then remove the timing gear and timing gear plate.

(Step 13)
Move the UD. rack (L) to backward, and then remove it.

(Step 14)
Remove the UD. rack (R).


UD. rack (R)
UD. rack (L)

(Step 15)
Remove the 2 gears and load relay gear.


Gears
Load relay gear

(Step 16)
Pull out the GENEVA gear, loosen 2 hooks of the bottom of mechanism base.


GENEVA gear
Hooks

(Bottom side)

(Step 17)
Remove the UD. speed down gear No.1 and UD drive gear.


UD. drive gear
UD. speed down gear No.1

(Step 18)
Slide the select rack to the edge direction of the arrow (1). Push the claw and pull out to arrow (2) while sliding the select rack to the arrow (1).


Claw
(2)
(1)
Select rack


Select speed down gear
Select drive gear
Hooks
(Bottom side)

(Step 19)
Pull out the select drive gear, loosen 2 hooks of the bottom of mechanism base. Then, remove the select speed down gear.

(Step 20)
Remove the select guide after sliding upside.


Select guide

(Step 21)
Remove the hook of the tray stopper with a minus screwdriver.


Hook
Tray stopper
Minus screwdriver
Tray stopper

(Step 22)
Remove the bottom of the tray lock lever with a minus screwdriver and others.


Tray lock lever
Minus screwdriver

8.11. CR16 MECHANISM ASSEMBLY PROCEDURE

The following specified greases and/or oil must be applied when some specific parts are changed.

1. **Floil grease (VFK1298) : The floil grease must be applied to tray, tray (L) and tray (R).**
2. **Hanarl oil (VFK1700) : The hanarl oil must be applied to any parts with grease other than the said parts.**

(Step 1)
Install the tray lock lever to mechanism base.


Tray lock lever
Upper side
Low side
Tray lock lever

(Step 2)
Push the tray lock lever with a hand and install it.


Tray lock lever

(Step 3)
Install the tray stopper to mechanism bese.


Tray stopper

(Step 4)
Push the tray stopper with a hand and install it.


Tray stopper

(Step 5)
Insert the select guide with a groove of the mechanism base and move it below.


Select guide
Groove

(Step 6)
Install the select speed down gear to mechanism base.

(Step 7)
Install the select drive gear to mechanism base.


Select speed bown gear
Select drive gear
30.5mm
25.5mm
Select speed down gear
(White)
Select drive gear
(White)

(Step 8)

Fit a mechanism base marking to the rectanguler mark of gear so that the triangle mark can indicate the sideward direction.


Rectanguler
Mechanism base marking
Triangle mark
Select drive gear

(Step 9)

Install the select rack to mechanism base.

(Checking items before the installation.
1. Check select guide is completely in lowest position.
2. Check its phase of select drive gear is correct position.(Rectangle/Trianguler mark)(Refer to Step 8))

1. Put a select rack down with it fitted to its circumference of mechanism base.


Mechanism base
Select rack
Select guide

2. Slide the select rack with it's pushing to a little right direction and install it.


Select rack

(Figure to see from the inside)


First groove of select rack
Select drive gear
Select rack

3. Check whether its end of triangular mark is in first groove of select rack, after fixing.
4. After insertion of select rack, continue the following work until the indication that it gose forward. And, all the while it must be checked that select rack is in the extreme end.

5. After insertion the select rack, the marking of select gear has a little gap when it is in the extreme end.


a little gap
Select drive gear

(Step 10)
Install the UD. speed down gear No.1 and UD. speed down gear No.2.


UD. speed down gear No.1
UD. speed down gear No.2



UD. speed down gear No.1 (White)



UD. speed down gear No.2 (Semi-transparent)

(Step 11)
Install the UD. drive gear to mechanism base.


UD. drive gear



UD drive gear
(White)

(Step 12)
Insert the UD. drive gear with its marking hole upward.
At that time, its triangle mark should be sideways.


UD. drive gear
Marking hole
Triangle mark

(Step 13)
Insert the GENEVA gear with its marking hole upward, and fix it by 2 hooks on bottom of mechanism base.
At that time, UD. drive gear mustn't be moved.


Marking hole
GENEVA gear


UD. drive gear
GENEVA gear
Marking hole

(Step 14)
Install the 2 gears to mechanism base.


Gears
20mm
Gear (White)

(Step 15)
Insert the UD. rack (R) to (2) from arrow (1).



NOTE:
Put a groove of the mechanism base to the UD. rack (R).


Grooves of mechanism base
Groove of UD. rack (R)


UD. rack (L)
Long groove
UD. rack (L)
(1)
(2)
Trapezoid tooth
UD. drive gear

(Step 16)
Align the trapezoid tooth of UD. drive gear with long groove of UD. rack (L), and then fix UD rack (L) in mechanism base.

(Figure to see from the upper side)


UD. rack (L)
Triangle mark
Long groove of UD. rack (L)
Trapezoid tooth of UD. drive gear
UD. rack (L)

(Step 17)
Install the tray relay gear and 2 hor relay gears.


Tray relay gear
Hor relay gears


15.5mm
12mm
Hor relay gears
(White)
Tray relay gear
(White)

(Step 18)
Install the load relay gear to mechanism base.
(Fit load relay gear with its big hole downward.)


Load relay gear
Big hole
10mm
Load relay gear
(White)

(Step 19)
Put on the top of the timing gear, then, install the timing gear and it's plate.
At that time avoid the UD. rack (L).


Timing gear plate
Hole
Timing gear
Tip of timing gear
Shaft
UD. rack (L)
Groove of
mechanism base

(Step 20)

Fix 2 claws and a screw to fix the timing gear and it's plate.


Claws
Timing gear plate
Screw
Timing gear

(Step 21)

Install the UD. pulley gear to mechanism base.


UD. pulley gear
26mm
UD. pulley gear
(White)

(Step 22)

Insert the change lever with it upright.


Change lever
Hook
Hook

(Step 23)

Be sure the notice of bellow before fixing the change gear.

1. Select track should be in the rear of mechanism base.
2. Its hole of GENEVA gear should turn up.


(Rear side)
Select rack


Marking hole
GENEVA gear

(Step 24)
Install the change gear as insert the change lever into the groove of change gear.


Change gear
Shaft
Change lever

1. Pushing the ○ part and pull up the change lever 45°.


Change gear
Change lever
45°

2. Insert the change lever into the groove of change gear.


Change gear
Groove of change gear.
Change lever

(Step 25)
Put change gear down with projection part of change gear fitted to triangle mark of mechanism base, when fixing change gear.
At that time, check change gear is inserted into the groove of change lever.

(Step 26)
Lastly, turn GENEVA gear clockwise slightly and drop change gear to mechanism base.


GENEVA gear
Change lever
Triangle mark of mechanism base
Projection part of mechanism base

(Step 27)
Move the select rack smoothly forward manually until 2 extreme points of both select track and mechanism base.


Select rack
Mechanism base
Extreme points
Select rack

(Step 28)
Install the main gear spring and hor drive gear.


Main gear spring
Hor drive gear


17.5mm
Hor drive gear
(White)

(Step 29)

Don't bring change lever into touch to projection part of main gear, when fixing main gear in mechanism base.


Main gear
Back side of main gear
Projection part
Change lever

(Step 30)

After that, turn main gear so that 2 holes inside main gear would be in alignment with mechanism base.


Holes
Main gear
Mchanism
base shaft

(Step 31)
Install the hor speed down gear (2), hor speed down gear (1), hor pullry gear and reverse gear.


(4) Reverse gear
(3) Hor pulley gear
(2) hor speed down gear (1)
(1) hor speed down gear (2)



Hor speed down gear (2) (White)



Hor speed down gear (1) (Semi-transparent)



Reverse gear (White)



Hor pulley gear (White)

(Step 32)
Install the UD. belt and hor belt.

NOTE:

1. Take care not apply the grease to the belt.
2. Install the belt without twist.


UD. belt
Hor belt

(Step 33)
Install speed up gear to its shaft of mechanism base with 2 fitting.


Speed up gear


Speed up gear
Hole
Shaft of mechanism base



Speed up gear
(White)

(Step 34)
Install the pitch plate. (The 4 claws should be latched.)

(Step 35)
Fix 2 ribs of UD. rack (L) and (R) into groove of both ends of UD. connection lever.


Rib
Claw
UD. connection lever
Pitch plate
Claw
Claws
Rib

(Step 36)

Fixed it by three screws further.


Screw
Screw
Screw
Pitch plate

(Step 37)

Be sure the notice of below before fixing the traverse mechanism.

1. Check that 2 holes of both pitch plate and main gear is fitted. (Refer to Fig.1)
   If it's not fitted, put the gear for servicing in the hole of the bottom side and adjust it. (Refer to Fig.2)
2. Check that 2 holed of both pitch plate and speed up gear is futted. (Refer Fig.3)
   If it's not fitted turn the speed up gear to adjust it.


Pitch plate
Fig.1
Hole A
Hole of main gear
Fig.2
Fig.3
Hole B
Hole of speed up gear
Hole
Gear of servicing
(as jig)
(Bottom side)

(Step 37)
Be sure the notice of below before fixing the traverse mechanism.

1. Check that 2 holes of both pitch plate and main gear is fitted. (Refer to Fig.1)
   If it's not fitted, put the gear for servicing in the hole of the bottom side and adjust it. (Refer to Fig.2)
2. Check that 2 holed of both pitch plate and speed up gear is futted. (Refer Fig.3)
   If it's not fitted turn the speed up gear to adjust it.


Pitch plate
Fig.1
Hole A
Hole of main gear
Fig.3
Hole B
Hole of speed up gear
Fig.2
Hole
Gear of servicing (as jig)
(Bottom side)

(Step 38)
Turn the separate lever (2) slowly toward left side until it clicks.


Traverse mechanism
Separate lever (2)

(Step 39)
Fix the left boss into the top groove of the UD. rack (L) and fix 2 bosses into the groove of the UD. rack (R).


Traverse mechamism
Bosses
Boss
Top groove
Top groove

(Step 40)
At that time, fix separate lever (2) into the separate lever (1).


Separate lever (2)
Separate lever (1)

(Step 41)
After the traverse mechanism fixed, confirm the phase in order below.

1. Check that 2 holes of both pitch plate and main gear is fitted. (Refer to Fig.1)
   If it's not fitted, put the gear for servicing in the hole of the bottom side and adjust it. (Refer to Fig.2)
2. Check that 2 holed of both pitch plate and speed up gear is futted. (Refer Fig.3)
   If it's not fitted turn the speed up gear to adjust it.


Hole A
Fig.1
Hole of main gear
Fig.2
Fig.3
Hole B
Hole of speed up gear
Hole
Gear for servicing (as jig)
(Bottom side)

3. In the cog of road gear, the groove with it's cutting halfway set side ward. (Refer to Fig.4)
   Remove the traverse mechanism again when it is not set side ward and install it after adjustment of inserting position.
   NOTE: By this time, do not adjust to rotate the road gear.



Fig.4

(Step 42)

After insertion of traverse mechanism, pull the UD. rack (R) on this side that each phase is "OK" and then lock the traverse mechanism.


Traverse mechanism
UD. rack (2)

(Step 43)

Install the tray drive gear to select guide.
(Install the top rib of the tray drive gear with side ward.)

NOTE:

Confirm the each phase surely before install the tray drive gear. (Refer to Step 41).


Tray drive gear ass'y
Select guide


Tray drive gear ass'y
Tray drive gear ass'y
The top rib
Tray drive gear ass'y
The top rib

(Step 44)
Insert the tray gear shaft.


Tray gear shaft

NOTE:
Be careful to handle it because the shaft is yet to fix until fixing top cover.

(Step 45)
Move the tray guide (R) and (L) to direction of arrow that fixed (stopped) it and install 5 pieces of disc tray.


Tray guide (R)
Tray guide (L)
Disc tray

(Step 46)
Confirm that when the disc tray insert the upper side, the speed up gear is rotate clockwise a little.

- When the rotation of speed up gear is not clockwise or rotate, repeat from Step 45.
- Until the speed up gear rorate, repeat from Step 45 and 46.


Speed up gear

NOTE:
While keeping all postion, install 5 pieces of disc tray.

(Step 47)
Insert 5 pieces of disc tray at the same time until it's stop.



(Step 48)
Turn the traverse side 180°.

(Step 49)
While install the tip of speed up lock beween tray (No.1) of the most lower side and pitch plate for the time being.
(Do not to insert the cog of speed up gear), insert it to boss.

NOTE:
At that time, do not move the tray.
(See the tray the most front side)


Pitch plate
Tray (the bottom side)
Boss
Speed up lock

(Step 50)
Insert the rib of speed up lock into a groove of main gear, and lock it with 2 claws.


Speed up lock
Claw
Claw
Rib of speed up lock
Groove of main gear

(Step 51)
Move the bottom tray to the arrow while pushing the top of the speed up gear. And insert it to a cog of the speed up gear.


Top of the speed up lock
Speed up gear
Bottom tray

(Step 52)
Install the open switch lever.
(Put the boss into the hole of the mechanism base.)


Open switch lever
Boss
Hole
Inset it with a click

(Step 53)
Install the top cover.
Fix it into hooks and slide direction to the arrow.

NOTE:
The claw should be latched.


Top cover
Claw
Claw
Hook

8.12. Disassembly of traverse mechanism

- Follow the (Step 1) - (Step 14) of Item 8.1.

- Follow (Step 1) - (Step 7) described in Item 8.10.

- Follow (Step 1) - (Step 7) described in Item 8.11.

- Follow Step 1 described in Item 9.11.



Step 1
Shift ribs of both side to the arrow direction.
(A vertical rack (R) slides and groove opens)

Step 2
Remove CD traverse deck.

Vertical rack (R)
Boss
Groove
Rib
Rib
Loading gear
Loading gear

Step 3
Lift a loading gear slightly and pull out.

Step 4

Fixing lever to the arrow direction, rotate a traverse.

Step 5

Remove catch and take out a clamp guide.


Catch
Traverse fixing lever
Clamp guide


Dividing lever (2)

Step 6

Remove a traverse fixing lever.

Step 7

Remove the bottom part of the dividing lever to the arrow direction.

Step 8

Slide a traverse sliding plate to the arrow direction (1), and shift a rib to the arrow direction (2).


(1)
Rib
(2)
Traverse
sliding plate

(Bottom side)

Step 9

Shifting a traverse sliding plate slightly and rotate a tray change lever.


Tray change lever

Step 10

Remove a tray change lever.

Step 11
Holding the catch down, slide a traverse sliding plate to the arrow direction and remove it.



8.13. Handling of cassette tape jam

- Follow the (Step 1) - (Step 4) of Item 8.1.

Step 1
If the cassette tape is not ejected due to twining around capstan or pinch roller during playing or recording, rotate a flywheel F to the arrow direction to remove twined tape.



Step 2
Push the lever to the arrow direction, open the cassette cover (JUN) and take out the cassette tape.



9. Self-Diagnostic Display Function

This unit is equipped with a self-diagnostic display function, which will be useful during

servicing and maintenance.

- Refer to the next page for display symbols, symptoms, etc.

9.1. Preparations

1. **A Cr02-positioned blank cassette tape with an erase prevention niche on either Side A or B.**
2. **A normal-positioned music tape with erase prevention niches on both Sides A and B. Both tapes are halfway forwarded in advance.**
3. **The remote controller that comes with this unit.**

9.2. Setting of the Self-Diagnostic Mode



No.	Operation Procedure	Operation and Processing of Microcomputer
1	Switch the SELECTOR to TAPE. There should be NO cassettes loaded.	
2	Press the [■ /-DEMO] key for 2 sec and press [∧ /FF/▶▶I] for another 2 sec, it shall enter into the self-diagnostic mode.	[T] shall be displayed in the FL.

9.3. Restoring Normal Display

- From the F76 display, the normal display does not appear till an error is recovered.

- For displays other than F76, press “POWER” button to turn off the power, and then turn on the power.



9.4. Clearing Self-Diagnostic Memory

<CD Section> (F15, F17, F22, F26, F27, F28, F29)

1. **Enter a self-diagnostic mode.**
2. **Press "■/-DEMO" button. A symbol of self-diagnostic is indicated on the display if an error is found. If several errors are found, a respective indication is displayed when "■/-DEMO" button is pressing repeatedly. (e.g. H01 → CD F15 → F01) / If no error is found, only "TEST" indication is displayed and remains unchanged even if "■/-DEMO" button is pressed.**

9.5. Displaying Self-Diagnostic Results

<Cassette Deck Section> (H01, H02, H03, F01, F02)

1. **Enter the self-diagnostic mode, following the instructions described in [5.2. Entering Self-Diagnostic Mode].**
2. **Insert a normal-positioned music tape with erase prevention niches on both Sides A and B. Press [TAPE ▶] button to activate the TPS operation so that the tape automatically stops at an interval between music selections.**

3. Press [■ /CLEAR] and [TAPE ▶] buttons together on the remote controller. (Recording does not start.)
4. Then, insert a Cr02-positioned blank cassette tape with an erase prevention niche of Side A or B set to the left side.
5. Press [∧ /FF/ ▶▶|] button. The tape will be forwarded and automatically stop after two seconds.
6. Remove the cassette tape, and set the other side.
7. Press [∨ /REW/ |◀◀] button. The tape will be rewound and automatically stops after two seconds.
8. Press [■/-DEMO] button on the unit.
   If an error is found, a self-diagnostic key appears on the display.
   If several errors are found, the display shows these keys when [■ /-DEMO] button is pressed repeatedly. (Ex.: H01 - H02 - F01 - H01)
   If no error is found, only the message, “CD TEST” appears on the display.

(*1) TPS operation (music search) detects the blank sections between music selections. Therefore, do not use tapes with the following conditions:

- A blank section that lasts only 4 seconds or less.
- No blank sections (recording through microphones, etc.).
- Music selections that have extremely low pitches or prolonged silent sections (such as classical music).
- and/or Music recorded with fade in/out effect.



Displayed Key	Symptoms	Causes and Troubleshooting
H01	Cassette mchanism operates erratically. Ex.: REV operation starts even when "FWD" button is pressed.	Malfunction of cassette mechanism mode switch (S971), plunger, and capstan motor. (Check and replace the parts.)
H02	Recording fails or starts when an erase prevention tab on cassette tape is broken off.	Malfunction or short-circuit of erase prevention detect switch (S975). (Check and replace the parts.)
H03	No playback when "TAPE ▶" button is pressed. The motor operates when no cassette tape is inserted and "TAPE ▶" button is pressed.	Malfunction or short-circuit of cassette mechanism tape detect switch (S972). (Check and replace the parts.)
F01	Tape playbacks and stops soon after "TAPE ▶" button is pressed.	Reel pulse problem. Malfunction of photo interrupter (IC971). (Check and replace the parts.)
F02	TPS does not operate.	Malfunction of playback EQ/recording amplifier IC (IC1302). (Check and replace the parts.)
F15	CD REST SW abnormal.	CD traverse position initial setting operation failsafe counter (1000 ms) waiting for REST SW to turn on. Error No. shall be cleared by force or duing coldstart.
F17	DOWN SW abnormal.	During vertical operation going to the bottom position, if failsafe timer is finished and switch no change or switch target condition was not achieve, this error shall be memorized. The next time mechanism operates, it shall do mechanism initialization. Error No. shall be cleared by force or coldstart.
F22	Loading Mode / Mecha abnormal.	During mehca initialization, Loading mode mechanism abnormal, normal operation cannot be achieved. The next time mechanism operates, it shall do mechanism initialization. Error No. shall be cleared by force or coldstart.
F26	CD servo LSI command signal abnormal.	CD function DTMS command, after system setting, if SENSE = 'L' cannot be detected. Memory shall contain F26 code. After Power on, CD function shall continue, error shall occur "NO DISC". Error No. shall be cleared by force or coldstart.
F27	Slide operation abnormal.	During vertical operation, if failsafe timer is finished and switch no change or switch target condition was not achieve, this error shall be memorized. Next time mechanism operates, it shall do coldstart. Error No. shall be cleared by force or coldstart.
F28	DISC load abnormal.	While going to play position, if failsafe counter is finished and switch no change or switch target condition was not achieve, this error shall be memorized. Next time mechanism operates, it shall do coldstart. Error No. shall be cleared by force or coldstart.
F29	DISC unload abnorml.	While going to play position, if failsafe counter is finished and switch no change or switch target condition was not achieve, this error shall be memorized. Next time mechanism operates, it shall do coldstart. Error No. shall be cleared by force or coldstart.

10. Precaution of Laser Diode

CAUTION:

This unit utilizes a class 1 laser.
Invisible laser radiation is emitted from the optical pickup lens.
When the unit is turned on:

1. **Do not look directly into the pick up lens.**
2. **Do not use optical instruments to look at the pick up lens.**
3. **Do not adjust the preset variable resistor on the pickup lens.**
4. **Do not disassemble the optical pick up unit.**
5. **If the optical pick up is replaced, use the manufacturer's specified replacement pick up only.**

6. Use of control or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION!

THIS PRODUCT UTILIZES A LASER.
USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN TH
SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

11. Procedure for Checking Operation of Individual Parts of Cassette Mechanism Unit

11.1. Operation Check with Cassette Tape

1. Pull up the EJECT lever using a rubber band. (Cf. Fig. 6)
2. Supply DC5V to MOTOR. (→ MOTOR rotates.) (Cf. Fig. 5)
3. Insert a cassette tape to the unit.
4. Supply DC9V to the plunger, and turn the power ON and OFF. (→ Power +PL, -PL) (Cf. Fig. 5)
   A. FWD PLAY: Supply the plunger power in a flash. (ON: approx. 5msec)
   B. FWD FF: Supply the plunger power in a flash at PLAY mode. (ON: approx. 5msec)
   C. STOP: Supply the plunger power in a flash at FWD FF mode. (ON: approx. 5msec)
   D. REV PLAY: Supply the plunger power in a normal timing at STOP mode. (ON: approx. 200msec)
   E. REV REW: Supply the plunger power in a flash at REV PLAY mode. (ON: approx. 50msec)
   F. STOP: Supply the plunger power in a flash at FF mode. (ON: approx. 50msec)
   Repeat the operation (→ FWD PLAY)
   (Note) Other operation may start if a timing of supplying the plunger power is missed.

11.1.1. Connection Status between Mechanism and Power Supply (Motor, Plunger)


DC 5V
V
A
ON
OFF
G
DC 9V
V
A
ON
OFF
G
The lead at the positive side is cut off, and is manually turned on and off.
Plunger
Motor
M
Rear View of Mechanism Unit

Fig. 5

11.1.2. Operative Parts of Mechanism Unit (EJECT lever fitted with rubber band, / Plunger/Rib operation)

Fig. 6


EJECT Lever

11.2. Operation Check without Cassette Tape

1. **Pull up the EJECT lever using a rubber band. (Cf. Fig. 6)**
2. **Supply DC5V to MOTOR. (→ MOTOR rotates.)**
3. **Lift up the mechanism unit's plunger/rib with the tip of a negative screwdriver, and operate the unit in the same timing as / supplying the power. (Cf. Fig. 7) /**

Fig. 7


Plunger/Rib

12. Measurement And Adjustments

12.1. Tuner Section

12.1.1. AM-IF Alignment

- AM-IF ALIGNMENT

SIGNAL GENERATOR OR SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER OSCILLOSCOPE)	ADJUSTMENT(Shown in Fig.3)	RE
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate signal into loop of receiver.	450 kHz	Point of non-interference (on/ about 600 kHz)	Headphone Jack (32 Ω) Fabricate the plug as shown in Fig. 2 and then connect the lead wires of the plug to the measuring instrument.	Z102 (AM IFT)	Adju maxi outp

- AM-RF ALIGNMENT

SIGNAL GENERATOR OR SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER OSCILLOSCOPE)	ADJUSTMENT(Shown in Fig.1)	RE
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate signal into loop of receiver.	522 kHz	Tuning capacitor fully closed.	Headphone Jack (32 Ω) Fabricate the plug as shown in Fig. 2 and then connect the lead wires of the plug to the measuring instrument.	Z101 (AM OSC Coil)	Adju maxi outp
Fashion a loop of several turns of wire and radiate signal into loop of receiver.	603 kHz	Tuning capacitor fully open.	Headphone Jack (32 Ω) Fabricate the plug as shown in Fig. 2 and then connect the lead wires of the plug to the measuring instrument.	Z101 (AM ANT Coil)	Adju maxi outp

12.2. Cassette Deck Section

12.2.1. Requirements

- Test tape (QZZCFM) (QZZCWAT)

- Normal blank cassette tape (QZZCRA)
- Frequency indicator
- Oscilloscope
- Electrical voltmeter
- Headphone jack output jig (Cf. Fig. 8)

12.2.2. Setting of Unit

- VOLUME: MAX

12.2.3. Preparations

1. Apply [10. Procedure for Checking Mechanism Control P.C.B., LCD P.C.B., Headphone/P-MD P.C.B., and USB P.C.B.] under [9. Disassembly and Main Component Replacement Procedures before Operation Checks].
2. Remove 4 screws from the mechanism unit to disassemble. (Refer to [7.3. Procedure for Replacing Pinch Roller and Head Block (Cassette Mechanism Unit)] under [7. Disassembly and Main Component Replacement Procedures before Operation Checks].
3. Connect the headphone jack output jig (Cf. Fig. 8) to headphone jack.

Fig. 8


To Headphone Jack
R=32Ω
R
R
+
L ch
−
−
R ch
+
To Oscilloscope
Or
Electrical Voltmeter
Or
Frequency Indicator

Fig. 9



12.2.4. Tape Speed Adjustment

- Normal speed adjustment (only during forward playback)
(Product reference value: 3,000±90Hz)

1. Connect a frequency indicator. (Cf. Fig. 12)

2. Playback the middle portion of the test tape (QZZCWAT).

3. Adjust the motor screw so that the following output level is produced. (Cf. Fig. 10)
Adjustment Range: 3,000 ± 90Hz (a constant speed)

Fig. 10


Frequency Indicator
Rch of Headphone Output Jig
+
–

Fig. 11


Motor Volume

12.2.5. Bias Voltage Check

1. Connect an electrical voltmeter. (Cf. Fig. 9) (Cf. Fig. 12)

2. Set the function to “TAPE” position.

3. Insert a normal blank cassette tape (QZZCRA).

4. While pressing and holding down [REC (●/❚❚)] button, press [TAPE (▶)] button to pause the recording mode. (Repeat pressing the buttons till the recording pause mode is activated.)

5. Check that the output level is within the standard range.
Standard Range: 14 ± 4mV

Fig. 12


1MΩ
TP6
(SIG)
+
Electrical Voltmeter
1KΩ
TP4
(GND)
−

12.2.6. Bias Frequency Check

1. Connect a digital frequency counter (Figure 13).

2. Set the function to “TAPE” position.

3. Insert a normal blank cassette tape (QZZCRA) and press “REC” mode on main unit.

4. Check that the output frequency is within the standard range.

Standard Value: 98 ±8 kHz

Fig. 13


UNIT
TP6
TP4
(GND)
+
−
Digital frequency counter

13. Block Diagram

14. Schematic Diagram

(All schematic diagrams may be modified at any time with the development of new technology.)
Notes:

S1	**Stock Switch**
S2	**Play Switch**
S3	**Bottom Switch**
S4	**Open Switch**
S600	**Rec Switch**
S602	**Tape Eject Switch**
S603	**Rew Switch**
S604	**Demo/Stop Switch**
S605	**FF Switch**
S606	**CD Play/Stop Switch**
S607	**Tape Switch**
S608	**Tuner/Band Switch**
S609	**AUX Switch**
S610	**CD Eject Switch**
S611	**CD Change Switch**
S612	**CD Check Switch**
S613	**CD 5 Switch**
S614	**CD 4 Switch**
S615	**CD 3 Switch**
S616	**CD 2 Switch**
S617	**CD 1 Switch**
S618	**Power Switch**
S619	**S.S.EQ Switch**
S701	**Reset Switch**
S780	**Open Switch**
S971	**Mode Switch**
S972	**Half Switch**
S973	**CR20 Switch**
S975	**RECINH_F Switch**

- The voltage value and waveforms are the reference voltage of this unit measured by DC electronic voltmeter (high impedance) and oscilloscope on the basis of chassis. Accordingly, there may arise some error in voltage values and waveforms depending upon the internal impedance of the tester or the measuring unit.

No mark	**...Playback**	**< >**	**...FM**
(( ))	**...CD**	**( )**	**...AM**

- Importance safety notice:

Components identified by ⚠ mark have special characteristics important for safety. Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used. When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

Caution!

IC, LSI and VLSI are sensitive to static electricity.

Secondary trouble can be prevented by taking care during repair.

- **Cover the parts boxes made of plastics with aluminium foil.**
- **Put a conductive mat on the work table.**
- **Ground the soldering iron.**
- **Do not touch the pins of IC, LSI or VLSI with fingers directly.**

15. Printed Circuit Board

16. Wiring Connection Diagram

17. Troubleshooting Flowchart (CD Section Circuit)


No CD playback
Disc rotation OK?
NO
A
YES
TOC reading OK?
NO
YES
"PLAY" appears on display?
NO Not accessible.
Playing time appear on the display
TJ701 (RF)
700mV or below or no output
B
Output at approx. 1Vp-p.
Pins 1, 2 and 3 of IC702 dubbing from internal CD OK?
Output NG
①BCLK
②LRCK
③SRDATA
OK
"L"
Pin 66 of IC702
Check Pin 23 (FEOUT) of IC701
No waveforms appear or the top and bottom balances of waveforms are distorted.
"H"
Top and bottom of waveforms are leveled equally.
Output NG
Pins 73 and 75 of IC702
OK
"H"
Pin 16 of CN702
NG
Pin 27 of IC702
NG
Pin 31 (FBAL) of IC702
NO
No output.
"L"
OK
OK
IC702 failure
Check the unit.
IC702 failure
IC702 failure
Snapping at R727 (1k) or R749 (18k)
IC701 failure
IC702 failure
Optical pickup failure


A
Remove clamper to eject test disc.
Switch to CD mode from other modes.
Check the movement of optical pickup.
No movement
Moves to inner direction, and then 2 to 3mm to outer direction.
Lens moves up and down?
NO
YES
Laser diode lit?
NO
YES
0.2V or above
Check the both end voltages at R701.
0.2V or below
Optical pickup failure (Laser diode NG)
Insert test disc.
Switch to CD mode from other modes.
B
Remains at "H".
Check Pin 15 (/RFDET) of IC701
Changes from "H" to "L".
Check Pin 11 (/FLOCK) of IC702.
Remains at "H".
Changes from "H" to "L".
Check Pin 24 (ECM) of IC702.
Remains at 1.65V. (High impedance)
"L" setting from 1.65V. (High impedance)
IC702 failure
Check the output from Pins 11 and 12 of IC703.
NG
OK
Spindle motor failure
IC703 failure
Check the both end voltages at R701.
0.4V or below
0.4V or above
Optical pickup failure
0.6V or above
Check the voltage between B and E of Q701.
0.6V or below
Q701 or optical pickup failure
IC701 failure
Check output from Pins 15 and 16 of IC703.
NG
OK
Optical pickup failure
Check the position of optical pickup.
Outer or center
Inner
Check Pin 2 of CN702.
"L"
"H"
"H"
Check Pin 2 of CN702.
"L"
Inner limit switch (S701) failure or snapping
Inner limit switch (S701) failure or snapping
Check Pins 13 and 14 of IC703.
NG
OK
Traverse deck failure
Check Pin 28 (FOD) of IC702.
NG
OK
IC703 failure
IC702 failure
NG
Check Pin 21 (TRV) of IC702.
OK
IC703 failure

18. Type Illustrations of ICs, Transistors & Diodes

19. Terminal Function of IC's

19.1. IC701 (AN22004A-NF) Servo Amplifier

Pin No.	Mark	I/O	Function
1	LPD	I	APC Amp input terminal
2	LD	O	APC Amp. output terminal
3	VCC	I	Power source terminal
4	EQSW	-	Equalizer switch terminal
5	RFOUT	O	RF summing Amp output terminal
6	RFIN	O	AGC input terminal
7	AGC	-	AGC loop filter connecting capacitor terminal
8	AGC	O	AGC output terminal
9	HPF-AMP	-	HPF Amp connecting capacitor terminal
10	3TOUT	O	3TOUT output terminal
11	HPFDET	-	Detection system’s HPF connecting capacitor terminal
12	OFTCNT	-	PFTR detection level adjustment terminal
13	BDO	O	BDO output terminal
14	OFTR	O	OFTR output terminal
15	/RFDET	O	NRFDET output terminal
16	LDON	-	LDON terminal
17	GND	-	Earth terminal
18	EQBST	-	Equalizer boost adjustment terminal
19	VREF	O	VREF output terminal
20	TEN	I	Amp inverting input terminal
21	TEOUT	O	TE amp output terminal
22	FEN	I	Amp inverting input terminal
23	FEOUT	O	FE amp output terminal
24	GCTL	-	GCTL terminal
25	FBAL	I	FBAL control terminal
26	TBAL	I	TBAL control terminal
27	E	O	Tracking signal input terminal 1
28	F	O	Tracking signal input terminal 2
29	D	O	Tracking signal input terminal 4
30	B	O	Tracking signal input terminal 2

			terminal 2
Pin No.	**Mark**	**I/O**	**Function**
31	C	O	Tracking signal input terminal 3
32	A	O	Tracking signal input terminal 1

19.2. IC702 (MN662790RSC) Servo processor/ Digital signal processor/ Digital filter/ D/A converter

No.	Mark	I/O	Function
1	BCLK	O	N.C.
2	LRCK	O	N.C.
3	SRDATA	O	N.C.
4	DVDD1	I	Power supply input (for digital circuit)
5	DVSS1	I	GND (for digital circuit)
6	TX	O	Digital audio interface signal output (Latches data at first transition)
7	MCLK	I	Microprocessor command clock signal input
8	MDATA	I	Microprocessor command data signal input
9	MLD	I	Microprocessor command load signal input
10	SENSE	O	Sense signal output (OFT, FESL, MADGEND, NAJEND, POSAD, SFG) (Not used, open)
11	/FLOCK/	O	Focus servo feeding signal output (“L”: Feed)
12	/TLOCK	O	Tracking servo feeding signal output (“L”: Feed)

No.	Mark	I/O	Function
13	BLKCK	O	Sub-code block clock signal output (BLKCKf = 75Hz during normal playback)
14	SQCK	I	External clock signal input for sub-code Q resistor
15	SUBQ	O	Sub-code Q code output
16	DMUTE	I	Muting input (“H”: mute)
17	STAT	O	Status signal output (CRC, CUE, CLVS, TTSTVP, FCLV, SQCK)
18	/RST	I	Reset signal input
19	SMCK	O	1/2-divided clock signal of crystal oscillating at MSEL = “H” (fSCMK = 8.4672 MHz) 1/4-divided clock signal of crystal oscillating at MSEL = “L” (fSMCK = 4.2336 MHz)
20	CSEL	I	Frequency Selection Terminal H = 33.8688 MHz; L = 16.9344 MHz
21	TRV	O	N.C.
22	TVD	O	Traverse drive output
23	PC	O	Spindle motor ON output (“L”: ON)
24	ECM	O	Spindle motor drive signal output (forced mode output)
25	ECS	O	Spindle motor drive signal output (servo error signal output)
26	KICK	O	N.C.
27	TRD	O	Tracking drive output
28	FOD	O	Focus drive output

No.	Mark	I/O	Function
29	VREF	I	D/A (drive) output (TVD, ECS, TRD, FOD, FBAL, TBAL) Reference voltage input
30	FBAL	O	Focus balance adjustment output
31	TBAL	O	Tracking balance adjustment output
32	FE	I	Focus error signal input (analog input)
33	TE	I	Tracking error signal input (analog input)
34	RFENV	I	RF envelope signal input
35	VDET	I	Vibration detection signal input (“H”: detection)
36	OFT	I	Off-track signal input (“H”: off track)
37	TRCRS	I	Track cross signal input
38	/RFDET	I	RF detection signal input (“L”: detection)
39	BDO	I	Dropout signal input (“H”: Dropout)
40	LDON	O	Laser on signal output (“H”: ON)
41	PLLF2	I/O	N.C.
42	DSLF2	O	Tracking Offset alignment output/DSL Balance Output (DA Output)
43	WVEL	O	N.C.
44	ARF	I	RF signal input
45	IREF	I	Reference current input
46	DRF	I	DSL bias terminal (Not used, open)
47	DSLF	I/O	DSL loop filter terminal
48	PLLF	I/O	PLL loop filter terminal
49	VCOF	I/O	VCO loop filter terminal

No.	Mark	I/O	Function
50	AVDD2	I	Power supply input (for analog circuit)
51	AVSS2	I	GND (for analog circuit)
52	EFM	-	EFM signal output
53	PCK	-	PLL extraction clock output (PCK = 4.321 MHz during normal playback)
54	VCOF2	I/O	VCO Loop filter for 33.8688 MHz conversion terminal for 16.9344 MHz crystal mode, must use other circuit
55	SUBC	O	Sub-code serial data output
56	SBCK	I	Clock input for sub-code serial data
57	VSS	I	GND
58	X1 IN	I	Crystal oscillating circuit input (f = 16.9344 MHz)
59	X2 OUT	O	Crystal oscillating circuit input (f = 16.9344 MHz)
60	VDD	I	Power supply input (for oscillating circuit)
61	BYTCK	-	Byte clock output
62	/CLDCK	-	Sub-code frame clock signal output (fCLDCK = 7.35 kHz during normal playback)
63	FCLK	-	Crystal frame clock signal output (fCLK = 7.35 kHz, double = 14.7 kHz)
64	IPFLAG	-	Interpolation flag output (“H”: Interpolation)
65	FLAG	-	Flag output
66	CLVS	-	Spindle servo phase synchronizing signal output (“H”: CLV, “L”: rough servo)

No.	Mark	I/O	Function
67	CRC	-	Sub-code CRC checked output (“H”: OK, “L”: NG)
68	DEMPH	-	De-emphassis ON signal output (“H”: ON)
69	RESY	-	Frame re-synchronizing signal output
70	IOSEL	I	Mode Switching Terminal
71	/TEST	I	Test input
72	AVDD1	I	Power supply input (for analog circuit)
73	OUTL	O	Left channel audio signal output
74	AVSS1	I	GND
75	OUTR	O	Right channel audio signal output
76	RSEL	I	RF signal polarity assignment input (at “H” level, RSEL=”H”, at “L” level, RESL = “L”)
77	IOVOD	I	5V supply input
78	PSEL	I	Test terminal (connected to Gnd)
79	MSEL	I	SMCK oscillating frequency designation input (“L” : 4.2336 MHz, “H”: 8.4672 MHz)
80	SSEL	I	SUBQ output mode select (“H”: Q-code buffer mode)

19.3. IC703 (BA5948FPE2) Focus coil/ Tracking coil/ Traverse motor/ Spindle motor driver

No.	Mark	I/O	Function
1	IN2	I	Motor Drive (2) input
2	PC2	I	Turntable motor drive signal (:L”: ON)
3	IN1	I	Motor driver (1) input
4	PC1	I	Spindle motor On/Off
5	NC	-	N.C.
6	NC	-	N.C.
7	NC	I	N.C.
8	NC	-	N.C.
9	PGND1	-	Ground connection (1) for driver
10	PVCC1	I	Power supply (1) for driver
11	D1-	O	Motor driver (1) reverse-action output
12	D1+	O	Motor driver (1) forward-action output
13	D2-	O	Motor driver (2) reverse-action output
14	D2+	O	Motor driver (2) forward-action output
15	D3-	O	Motor driver (3) reverse-action output
16	D3+	O	Motor driver (3) forward-action output
17	D4-	O	Motor driver (4) reverse-action output
18	D4+	O	Motor driver (4) forward-action output
19	PVCC2	I	Power supply (2) for driver
20	PGND2	-	Ground connection (2) for driver
21	NC	-	N.C.
22	NC	-	N.C.
23	NC	-	N.C.
24	NC	-	N.C.
25	VCC	I	Power supply terminal
26	VREF	I	Reference voltage input
27	IN4	I	Motor driver (4) input
28	IN3	I	Motor driver (3) input

19.4. IC600 (C02BBGF000424) Microprocessor

Pin No.	Mark	I/O	Function
1	DECK2	I	DECK2 input
2	N.C.	O	No Connection
3	KEY2	I	Key 2 input
4	KEY1	I	Key 1 input
5	VOL_JOG	I	Volume Jog AD Detection
6	CD\	O	CD unit power control
7	M1_FOUT	O	CHANGER MOTOR 1 FORWARD CONTROL
8	CDRST	O	CD Reset Output
9	STATUS	I	CD Signal Processor Status Input
10	M1_ROUT	O	CHANGER MOTOR 1 REVERSE CONTROL
11	BOTTOM	I	BOTTOM SWITCH
12	ST/DO/SQCK	I/O	Tuner IF Data/Stereo Input/CD Sub Code Clock Output
13	SD	I	Tuner Signal Detect Input
14	SUBQ	I	CD Sub Code Data Input
15	RDS_CLOCK	I	RDS Clock Input (See region setting for detail)s
16	RDS_DATA	I	RDS Data Input (See region setting for details)
17	CNVSS	-	Flash Mode Terminal (Connect to 10K ohm)
18	/RESET	-	Reset Input
19	XCout	-	32.768 kHz Sub Clock
20	XCin	-	32.768 kHz Sub clock
21	VSS	-	Ground (0V)
22	Xin	-	4.19 MHz Main Clock
23	Xout	-	4.19MHz Main Clock
24	VCC	-	Power Supply (+5)
25	MBP1	O	Microcomputer Beat Proof Output 1
26	MBP2	O	Microcomputer Beat Proof Output 2
27	MCLK/ PLLCK	O	CD command Clock Output/Tuner PLL Clock Output

			Output

Pin No.	Mark	I/O	Function
28	MDATA/ PLLDA	O	CD command Data Output/ Tuner PLL Data Output
29	RMT	I	Remote Control Input
30	BLKCK	I	CD Block Clock Input
31	MLD/PLLCE	O	CD Command Load Output/ Tuner PLL Chip Enable
32	SYNC	I	AC Failure Detect Input
33	DCDET	I	DC Detect Input
34	POSITION	I	POSITION SWITCH
35	OPEN	I	OPEN SWITCH
36	M2_FOUT	O	CHANGER MOTOR 2 FORWARD CONTROL
37	M2_ROUT	O	CHANGER MOTOR 2 REVERSE CONTROL
38	STOCK_SW	I	STOCK SWITCH
39	EE_DATA	O	EEPROM DATA
40	REST_SW	I	CD Limit SW Input for the Most Inner Point (Active Low)
41	PCONT	O	Main Transformer Control Output
42	CD_LED	O	LED Drive
43	MOTOR	O	Deck Motor Control Output L=Motor ON, H=Motor OFF
44	MUTEA	O	Audio Mute
45	MUTEH	O	HIC Mute
46	SSEQ CTRL	O	Super Sound EQ CTRL (Active H)
47	REC	O	Record Circuit Control Output L=Record OFF, H= Record ON
48	BP1	O	AM Beatproof 1 Output L=BP1, H=BP2
49	DMT	O	Deck Mute Output L=Mute OFF, H=Mute ON
50	EE_CLK	O	EEPROM CLOCK
51	EE_CS	O	EEPROM Chip Select
52	GREEN	O	LED Drive

Pin No.	Mark	I/O	Function
53	PLUNGER	O	Plunger Control Output L=Plunger ON, H= Plunger OFF
54	RED	O	LED Drive
55	SSEQ	O	SSEQ LED Control
56	N.C.	O	No Connection
57-80	SEG24-SEG1	O	SEGMENT DRIVE OUTPUT (ANODE DRIVE OUTPUT)
81-82	GRID8(REG8) - GRID7(REG7)	O	Digit Drive Output(Grid Drive Output) For region setting/ Function Selection use
83	GRID6	O	Grid Drive Output For region setting/ Function Selection use
84-88	GRID5(REG5) - GRID1(REG1)	O	Digit Drive Output(Grid Drive Output) For region setting/ Function Selection use
89	VEE	-	Power Supply (-30V)
90	REG_IN	I	Region and Function Setting Input
91	VOC_C	O	Karaoke Control C
92	VOC_B	O	Karaoke Control B
93	ASP_ LATCH	O	ASP CONTROL LATCH OUTPUT
94	PLAY_SW	I	PLAY SWITCH
95	ASP_CLK	O	ASP_CLK
96	ASP_DATA	O	ASP_DAT
97	AVss	-	Analog Ground (0V)
98	VREF	-	Reference for A-D
99	PHOTO	I	PHOTO (SG mechanism only)
100	DECK1	I	DECK_AD1

20. Parts Location and Replacement Parts List

Notes:

- Important safety notice:

Components identified by ⚠ mark have special characteristics important for safety.

Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of these components, be sure to use only manufacturers's specified parts shown in the parts list.

- **The parenthesized indications in the Remarks column specify the areas or color. (Refer to the cover page for area or color.)**
  Parts without these indications can be used for all areas.
- **Warning: This product uses a laser diode. Refer to caution statements on “Precaution of Laser Diode”.**
- **Capacitor values are in microfarad (μF) unless specified otherwise, P=Pico-farads(pF); Farads.**
- **Resistance values are in ohms, unless specified otherwise, 1K= 1,000(ohms).**
- **The marking (RTL) indicates that the Retention Time is limited for this item. After the discontinuation of this assembly in production, the item will continue to be available for a specific period of time. The retention period of availability is dependant on the type of assembly, and in accordance with the lows govening part and product retention. After the end of this period, the assembly will no longer be available.**
- **[M] indicates in the Remarks columns indicates parts that are supplied by MESA.**
- **The “(SF)” mark denotes the standard part.**
- **Reference for O/I book languages are as follows :**

Ar : Arabic
Cf : Canadian French
Cz : Czech
Da : Danish
Du : Dutch
En : English
Fr : French
Ge : German
It : Italian
Ko : Korean
Po : Polish
Su : Russian
Sp : Spanish
Sw : Swedish
Co : Traditional Chinese
Cn : Simplified Ch

20.1. Deck Mechanism (RAA4402-S)

20.1.1. Deck Mechanism Parts Location


A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9
10
113
121
122
136
120
111
101
103
122
104
111
112
103
138
(MECHANISM P.C.B)
CS951
134
137
137
133-2
133-1
133
137
129
S954
S952
S951
130
135
135
130-1
124
139
123
108
126
118
115
132
107
128
105
119
116
110
114
117
125
139

20.1.2. Deck Mechanism Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
		CASSETTE DECK	
101	RED0067	R/P HEAD BLOCK UNIT	[M]
103	RDG0300	REEL BASE GEAR	[M]
104	RDG0301	WINDING RELAY GEAR	[M]
105	RDK0026	MAIN GEAR	[M]
107	RDV0033-4	WINDING BELT	[M]
108	RDV0064	CAPSTAN BELT	[M]
110	RMB0312	TRIGGER LEVER SPRING	[M]
111	RMB0400	REEL SPRING	[M]
112	RMB0403	HEAB PANEL SPRING	[M]
113	RMB0404	BRAKE ROD SPRING	[M]
114	RMB0406	FR LEVER SPRING	[M]
115	RMB0408	THRUST SPRING	[M]
116	RML0370	TRIGGER LEVER	[M]
117	RML0371	FR LEVER	[M]
118	RML0372	WINDING LEVER	[M]
119	RML0374	EJECT LEVER	[M]
120	RMM0131	BRAKE ROD	[M]
121	RMM0133	EJECT ROD	[M]
122	RMQ0519	REEL HUB	[M]
123	RMS0398-1	MOVING CORE	[M]
124	RXQ0470	PLUNGER	[M]
125	RMC0061	PACK SPRING	[M]
126	RXF0061	FLYWHEEL F ASS’Y	[M]
128	RXG0040	FF RELAY GEAR ASS’Y	[M]
129	RMK0283A-J	SUB-CHASSIS	[M]
130	RXL0124	PINCH ROLLER F ASS’Y	[M]
130-1	RMB0401	PINCH ARM SPRING F	[M]
132	RXL0126	WINDING ARM ASS’Y	[M]
133	RXQ0412	HEAD PANEL ASS’Y	[M]
133-1	RMB0405	FR ROD SPRING	[M]
133-2	RMM0132	FR ROD	[M]
134	REM0098	CAP MOTOR ASS’Y	[M]
135	RHD26022	MOTOR SCREW	[M]
136	XTW2+5L	HEAD BLOCK UNIT SCRE	[M]
137	XTW26+10S	SUB-CHASSIS SCREW	[M]
138	XYC2+JF17	PCB EARTH SCREW	[M]
139	RFKJSTR280PP	CHASSIS ASS’Y	[M]

20.2. CD Loading Mechanism

20.2.1. CD Loading Mechanism Parts Location


A
B
C
D
E
F
G


H
I
J
K
L
M
331-3
331-1
331-3
331-2


A
B
C
D
E
F
G
TRAVERSE DECK


H
I
J
K
L
M
N
1
2
3
4
5
6
7
8
380
361
348
324
349
316
322
310
328
319
323
333
374
321
373
308
312
345
383
318
346
320
353
375
343
372
310
369
311
376
344
309
305
309
307
335
327
313
373
326
315
306
314
379
373
380
378
380

20.2.2. CD Loading Mechanism Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
		TRAVERSE DECK	
301	RAE0157A-V	TRV UNIT WITHOUT SER	[M]
303	RDG0455	TRV GEAR (A)	[M]
304	RDG0456	TRV GEAR (B)	[M]
305	RDG0519	MAIN GEAR	[M]
306	RDG0520	SPEED UP GEAR	[M]
307	RDG0521	REVERSE GEAR	[M]
308	RDG0522	GENEVA GEAR	[M]
309	RDG0523	HOR RELAY GEAR	[M]
310	RDG0525	CROWN GEAR	[M]
311	RDG0526	TRAY RELAY GEAR	[M]
312	RDG0527	UD PULLEY GEAR	[M]
313	RDG0528	HOR SPEED DOWN GEAR	[M]
314	RDG0529	HOR SPEED DOWN GEAR	[M]
315	RDG0530	HOR DRIVE GEAR	[M]
316	RDG0531	LOAD RELAY GEAR	[M]
317	RDG0532	LOAD GEAR	[M]
318	RDG0534	UD SPEED DOWN GEAR	[M]
319	RDG0535	UD SPEED DOWN GEAR	[M]
320	RDG0536	SELECT SPEED DOWN GE	[M]
321	RDG0537	SELECT DRIVE GEAR	[M]
322	RDG0538	CHANGE GEAR	[M]
323	RDG0539	UD DRIVE GEAR	[M]
324	RDG0540	TIMING GEAR	[M]
325	RDG0542	TRAY GEAR	[M]
326	RDG0543	HOR PULLEY GEAR	[M]
327	RDV0068	HOR BELT	[M]
328	RDV0069	UD BELT	[M]
329	RHM0001	MAGNET	[M]
330	RME0109	FLOATING SPRING	[M]
331	RFKNCT101	TRAVERSE UNIT ASS'Y	[M]
331-1	RME0369	PRESS SPRING	[M]
331-2	RXQ0632	TRV MOTOR UNIT	[M]
331-3	XQN17+C28F	SCREW	[M]
332	RME0344	UD ASSIST SPRING	[M]
333	RME0361	TRAY STOPPER SPRING	[M]
334	RME0363	LIMIT SPRING	[M]
335	RME0368	MAIN GEAR SPRING	[M]
336	RMG0563-T	FLOATING RUBBER	[M]
337	RML0616	SPEED UP LOCK	[M]
338	RML0617	SEPARATE LEVER 1	[M]
339	RML0618	SEPARATE LEVER 2	[M]
340	RML0619-1	UD. CONNECTION LEVER	[M]
341	RML0620	TRV.CONNECT LEVER	[M]
342	RML0621	TRAY CHG. LEVER	[M]
343	RML0622	TRAY LOCK LEVER	[M]
344	RML0623	OPEN SW. LEVER	[M]
345	RML0624	CHG. LEVER	[M]
346	RML0637	TRAY STOPPER	[M]
347	RMM0218	TRV DRIVE RACK	[M]
348	RMM0239	UD.RACK [L]	[M]
349	RMM0240	UD.RACK [R]	[M]
350	RMM0241	TRV.SLIDE PLATE [L]	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
351	RMM0242	TRV.SLIDE PLATE [R]	[M]
352	RMM0243	SELECT RACK	[M]
353	RMM0244	SELECT GUIDE	[M]
354	RMQ1051	PITCH PLATE	[M]
355	RMQ1052	UD BASE	[M]
356	RMQ1056	TRAY GUIDE [L]	[M]
357	RMQ1057	TRAY GUIDE [R]	[M]
358	RMQ1058	GEAR HOLDER	[M]
359	RMQ1059	TOP COVER	[M]
360	RMQ1060	CLAMP GUIDE	[M]
361	RMQ1061	TG.PLATE	[M]
362	RMR0334	FIXTURE	[M]
363	RMR0624-W5	CLAMPER	[M]
364	RMR1407A-H1	TRAY NO. 1	[M]
365	RMR1407B-H1	TRAY NO. 2	[M]
366	RMR1407C-H1	TRAY NO. 3	[M]
367	RMR1407D-H1	TRAY NO. 4	[M]
368	RMR1407E-H1	TRAY NO. 5	[M]
369	RMR1408-K	MECHA BASE	[M]
370	RMR1427-X	MIDDLE CHASSIS	[M]
371	RMS0757-1	FIXED PIN	[M]
372	RMS0758	CHANGE GEAR SHAFT	[M]
373	RMS0759	UD SPEED DOWN GEAR S	[M]
374	RMS0760	LOAD RELAY GEAR SHAF	[M]
375	RMS0762	TRAY GEAR SHAFT	[M]
376	RXG0053	TRAY DRIVE GEAR ASSY	[M]
377	RXQ0999	OPU UNIT	[M]
378	RXQ0803	LOADING MOTOR ASS’Y	[M]
379	RXQ0804	UD MOTOR ASS’Y	[M]
380	XTB3+10J	SCREW	[M]
381	XTN2+6G	SCREW	[M]
382	RMC0472	TRAY SPRING	[M]
383	XTBS26+8J	SCREW	[M]

20.3. Cabinet

20.3.1. Cabinet Parts Location


A
B
C
D
E
F
G
H610A
H607A
VR600
(TACT SWITCH
P.C.B)
H604/
W604
(PANEL P.C.B)
H600/W600
CN611
CN607A
CN602
CN606
H611/
W611
W308A
CN608
CN609B
(AC LED P.C.B)
(TAPE EJECT
P.C.B)
(SENSOR
P.C.B)
LCD
(FL600)
H610B
CN1304
W308B
CP1301
H609A
CN1303
(DECK P.C.B)
CP1902
14-1
JK600
(HEADPHONE
P.C.B)


H
I
J
K
L
M
N
1
2
3
4
5
6
7
8
9
54
54
(AC TRANSFORMER P.C.B)
CN507A
CN507A
T502
JK501
13
48
48
48
48
48
CN505
T501
48
48
48
38
45
CN506
49
53
CN504
H503/ W503
CP501
CN500
(POWER P.C.B)
7
48
36
CN310
JK101
(MAIN P.C.B)
(TUNER PACK P.C.B)
JK303
48
48
41
JK302
H307
48
CN306
JK301
H303/W303
CN301
CN305
48
48
48
24
48
37
24
24
31
5
24
25
25
4

20.3.2. Cabinet & CD Loading Mechanism Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET AND CHASSIS	
1	RDG0357	DAMPER GEAR	[M]
2	RDLX0003-Q	POWER LENS	[M]
3	REEX0165	14P FFC	[M]
4	REEX0166	14P FFC WIRE	[M]
5	REEX0167	19P CD FFC	[M]
6	REEX0282	30P FFC	[M]
7	REM0094	COOLING FAN	[M]
8	REXX0294	12P (BTN-PANE)	[M]
9	REXX0352	9P (PANEL-HP)	[M]
10	RGKX0173-S	JOG ORNAMENT	[M]
11	RGKX0175-S	VOLUME ORNAMENT	[M]
12	RGKX0189-S	CENTER ORNAMENT	[M]
13	RKSX0050R-H	REAR CABINET	[M]
14	RFKGAPM16P-S	FRONT CABINET ASS'Y	[M]
14-1	RGPX0097C-S	FL WINDOW	[M]
15	RGUX0497-S	DECK EJECT BUTTON	[M]
16	RGUX0498-S	CD EJECT BUTTON	[M]
17	RGUX0499-S	POWER BUTTON	[M]
18	RGUX0500-S	ALL DISC BUTTON	[M]
19	RGUX0501-S	RECORD BUTTON	[M]
20	RGUX0502-S	AUX BUTTON	[M]
21	RGUX0504-S	FUNCTION BUTTON	[M]
22	RGUX0505-S	CD MANAGER BUTTON	[M]
23	RGWX0075-S	VOLUME KNOB	[M]
24	RHD30007-1S	SCREW	[M]
25	RHGV0008	LEG CUSHION	[M]
26	RKF0479-1H	CASS HOLDER	[M]
27	RKFX0106-S	CASS LID	[M]
28	RKFX0107-S	CD LID	[M]
29	RKMX0083-S	TOP CABINET	[M]
30	RKMX0084-S	SIDE PANEL L	[M]
31	RKMX0085-S	SIDE PANEL R	[M]
33	RMA1543	CD LID SUPPORT	[M]
34	RMBX0029	CASS OPEN SPRING	[M]
35	RMEX0020	CD LID OPEN SPRING	[M]
36	RMKX0070	INNER CHASSIS	[M]
37	RMKX0071	BOTTOM CHASSIS	[M]
38	RMY0260	HEAT SINK (SMALL)	[M]
40	RUS757ZAA	CASS HALF SPRING	[M]
41	RWJ1109180XX	9P MAIN-DECK	[M]
42	RWJ1111138XX	11P PANEL-DECK WIRE	[M]
43	RMNX0094-1	FL HOLDER	[M]
44	RXQX0014	REC. LIGHTING HOLDER	[M]
45	RXXX0043	HEAT SINK UNIT	[M]
46	RYQX0083-S	S. SEQ UNIT	[M]
48	XTB3+10JFZ	SCREW	[M]
49	XTB3+8JFZ	SCREW	[M]
50	XTBS26+10J	SCREW	[M]
52	XTV3+10G	SCREW	[M]
53	XTW3+15T	SCREW	[M]
54	XTWS3+8T	SCREW	[M]

20.4. Components Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
		PRINTED CIRCUIT BOARD	
	REPX0362A	CD SERVO P.C.B.	[M](RTL)
	REP1999B	TUNER PACK P.C.B.	[M](RTL)
	REPX0349A	MAIN P.C.B.	[M](RTL)
	REPX0349A	PANEL P.C.B.	[M](RTL)
	REPX0350A	DECK P.C.B.	[M](RTL)
	REPX0321H	DECK MECHANISM P.C.B.	[M](RTL)
	REPX0348A	POWER P.C.B.	[M](RTL)
	REPX0348A	AC TRANSFORMER P.C.B.	[M](RTL)
	REPX0349A	TACT SWITCH P.C.B.	[M](RTL)
	REPX0349A	AC LED P.C.B.	[M](RTL)
	REPX0349A	HEADPHONE P.C.B.	[M](RTL)
	REPX0349A	SENSOR P.C.B.	[M](RTL)
	REPX0350A	TAPE EJECT P.C.B.	[M](RTL)
	REP3340A	CD LOADING P.C.B.	[M](RTL)
		INTEGRATED CIRCUITS	
IC11	C0GAG0000007	IC DRIVER	[M]
IC21	C0GAG0000007	IC DRIVER	[M]
IC101	LA1833NMNTLM	IC IF & MPX	[M]
IC102	LC72131MDTRM	IC PLL	[M]
IC301	C1BB00000617	IC	[M]
IC500	RSN314H41A-P	IC POWER AMP HIC	[M]
IC501	C0AABB000117	IC COP-AMP (HP AMP)	[M]
IC600	C2BBGF000424	IC MICROPROCESSOR	[M]
IC701	AN22004A-NF	IC HEAD AMP	[M]
IC702	MN662790RSC	IC LSI	[M]
IC703	BA5948FPE2	IC 4 CH DRIVE	[M]
IC971	CNB13030R2AU	IC PHOTO INTERUPTOR	[M]
IC1000	C1AA00000612	IC ANALOG SW	[M]
IC1001	AN7326K	IC DECK R/P	[M]
		TRANSISTORS	
Q1	2SK544F-AC	TRANSISTOR	[M]
Q1	B3NAA0000068	TRANSISTOR	[M]
Q2	B1AAAC000011	TRANSISTOR	[M]
Q3	B1AAAD000013	TRANSISTOR	[M]
Q4	B1AAAD000013	TRANSISTOR	[M]
Q101	2SC2058SPTA	TRANSISTOR	[M]
Q106	KRA102MTA	TRANSISTOR	[M]
Q500	KTA1046	TRANSISTOR	[M]
Q501	KTC2026	TRANSISTOR	[M]
Q502	KTA1046	TRANSISTOR	[M]
Q503	KTA12710YTA	TRANSISTOR	[M]
Q505	KTA1267GRTA	TRANSISTOR	[M]
Q506	KTA1046	TRANSISTOR	[M]
Q507	KTC3199GRTA	TRANSISTOR	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
Q508	KTC3199GRTA	TRANSISTOR	[M]
Q509	KRA110MTA	TRANSISTOR	[M]
Q510	KRA110MTA	TRANSISTOR	[M]
Q514	2SD0592ARA	TRANSISTOR	[M]
Q515	KTC3199GRTA	TRANSISTOR	[M]
Q516	KTC3199GRTA	TRANSISTOR	[M]
Q517	KTC32030YTA	TRANSISTOR	[M]
Q519	B1AAGC000006	TRANSISTOR	[M]
Q575	B1AAGC000006	TRANSISTOR	[M]
Q577	2SC3940ARA	TRANSISTOR	[M]
Q578	KRC102MTA	TRANSISTOR	[M]
Q579	2SB0621AHA	TRANSISTOR	[M]
Q607	KRC103STA	TRANSISTOR	[M]
Q608	KTC3875GRTA	TRANSISTOR	[M]
Q609	KTC3875GRTA	TRANSISTOR	[M]
Q610	KTA1504GRTA	TRANSISTOR	[M]
Q611	KRC102STA	TRANSISTOR	[M]
Q613	KRC119STA	TRANSISTOR	[M]
Q614	KRC119STA	TRANSISTOR	[M]
Q615	KRC119STA	TRANSISTOR	[M]
Q700	B1AACF000063	TRANSISTOR	[M]
Q701	2SA1037AKSTX	TRANSISTOR	[M]
Q701	KTA12710YTA	TRANSISTOR	[M]
Q702	B1AACF000063	TRANSISTOR	[M]
Q703	B1AACF000063	TRANSISTOR	[M]
Q704	KRA110MTA	TRANSISTOR	[M]
Q710	B1AAGC000006	TRANSISTOR	[M]
Q711	B1AAGC000006	TRANSISTOR	[M]
Q714	KTC3199GRTA	TRANSISTOR	[M]
Q715	KTC3199GRTA	TRANSISTOR	[M]
Q716	KTC3199GRTA	TRANSISTOR	[M]
Q717	KTC3199GRTA	TRANSISTOR	[M]
Q718	B1AAGC000006	TRANSISTOR	[M]
Q719	B1AAGC000006	TRANSISTOR	[M]
Q720	KTC3199GRTA	TRANSISTOR	[M]
Q721	KTC3199GRTA	TRANSISTOR	[M]
Q901	KRC101STA	TRANSISTOR	[M]
Q902	KRC101STA	TRANSISTOR	[M]
Q903	KRC101STA	TRANSISTOR	[M]
Q904	KRC101STA	TRANSISTOR	[M]
Q905	KRC101STA	TRANSISTOR	[M]
Q1000	KTC3199GRTA	TRANSISTOR	[M]
Q1101	B1ABGC000005	TRANSISTOR	[M]
Q1201	B1ABGC000005	TRANSISTOR	[M]
Q1302	DTA114EKA146	TRANSISTOR	[M]
Q1303	DTC143XKA146	TRANSISTOR	[M]
Q1304	DTA143XKA146	TRANSISTOR	[M]
Q1305	DTC114EKA146	TRANSISTOR	[M]
Q1309	B1AAGC000006	TRANSISTOR	[M]
Q1310	B1AAGC000006	TRANSISTOR	[M]
Q1312	2SC2412KT96R	TRANSISTOR	[M]
Q1313	2SC2784FTA	TRANSISTOR	[M]
Q1314	DTA143XKA146	TRANSISTOR	[M]
Q1315	KTA12710YTA	TRANSISTOR	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
Q1316	2SD09650RA	TRANSISTOR	[M]
Q1317	B1ABGC000005	TRANSISTOR	[M]
		DIODES	
D1	B0CAAD000002	DIODE	[M]
D2	B0CAAD000002	DIODE	[M]
D3	B0CAAD000002	DIODE	[M]
D101	UDZSTE175R1B	DIODE	[M]
D301	RL1N4003N02	DIODE	[M]
D302	RL1N4003N02	DIODE	[M]
D500	KBL402G	DIODE	[M]
D501	B0ACCK000005	DIODE	[M]
D502	UDZSTE177R5B	DIODE	[M]
D505	B0AACK000004	DIODE	[M]
D508	MAZ4150NLF	DIODE	[M]
D515	B0BA9R600002	DIODE	[M]
D517	B0BA5R600016	DIODE	[M]
D518	B0AACK000004	DIODE	[M]
D520	B0BA9R600002	DIODE	[M]
D524	MAZ4150NMF	DIODE	[M]
D525	B0AACK000004	DIODE	[M]
D526	B0AACK000004	DIODE	[M]
D527	B0AACK000004	DIODE	[M]
D528	B0AACK000004	DIODE	[M]
D530	B0AACK000004	DIODE	[M]
D539	RL1N4003N02	DIODE	[M]
D540	RL1N4003N02	DIODE	[M]
D541	RL1N4003N02	DIODE	[M]
D578	RL1N4003N02	DIODE	[M]
D579	RL1N4003N02	DIODE	[M]
D580	RL1N4003N02	DIODE	[M]
D581	RL1N4003N02	DIODE	[M]
D582	B0BA6R600008	DIODE	[M]
D584	RL1N4003N02	DIODE	[M]
D587	RL1N4003N02	DIODE	[M]
D588	RL1N4003N02	DIODE	[M]
D589	RL1N4003N02	DIODE	[M]
D592	RL1N4003N02	DIODE	[M]
D593	RL1N4003N02	DIODE	[M]
D594	MTZJ24CTA	DIODE	[M]
D620	1SS380TE-17	DIODE	[M]
D621	1SS380TE-17	DIODE	[M]
D630	B0ACCK000005	DIODE	[M]
D631	B0ACCK000005	DIODE	[M]
D632	UDZSTE174R7B	DIODE	[M]
D633	B3AAA0000583	DIODE	[M]
D636	B3CNE0000001	DIODE	[M]
D637	B3CNE0000001	DIODE	[M]
D638	LNJ801TPSJA	DIODE	[M]
D640	RB501V-40	DIODE	[M]
D641	RB501V-40	DIODE	[M]
D642	RB501V-40	DIODE	[M]
D643	RB501V-40	DIODE	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
D644	B0ACCK000005	DIODE	[M]
D645	B0ACCK000005	DIODE	[M]
D650	B0ACCK000005	DIODE	[M]
D700	B0AACK000004	DIODE	[M]
D701	B0AACK000004	DIODE	[M]
D702	B0AACK000004	DIODE	[M]
D703	B0AACK000004	DIODE	[M]
D704	B0AACK000004	DIODE	[M]
D705	B0AACK000004	DIODE	[M]
D706	B0AACK000004	DIODE	[M]
D707	B0AACK000004	DIODE	[M]
D708	MA2C16500E	DIODE	[M]
D709	MA2C16500E	DIODE	[M]
D743	B0EAKM000085	DIODE	[M]
D750	MAZ80560ML	DIODE	[M]
D971	MA2C16500E	DIODE	[M]
D1301	B0ACCK000005	DIODE	[M]
		VARIABLE RESISTORS	
VR600	EVEJ1CF2524B	VOLUME ENCODER	[M]
		SWITCHES	
S1	K0L1BA000065	SW	[M]
S2	K0L1BA000065	SW	[M]
S3	K0L1BA000070	SW	[M]
S4	RSH1A045-1A	SW TRIGGER	[M]
S600	EVQ21405RJ	SW REC	[M]
S602	EVQ21405RJ	SW TAPE EJECT	[M]
S603	EVQ21405RJ	SW REW	[M]
S604	EVQ21405RJ	SW DEMO/STOP	[M]
S605	EVQ21405RJ	SW FF	[M]
S606	EVQ21405RJ	SW CD PLAY/STOP	[M]
S607	EVQ21405RJ	SW TAPE	[M]
S608	EVQ21405RJ	SW TUNER/BAND	[M]
S609	EVQ21405RJ	SW AUX	[M]
S610	EVQ21405RJ	SW CD OPEN/CLOSE	[M]
S611	EVQ21405RJ	SW CD CHANGE	[M]
S612	EVQ21405RJ	SW CD CHECK	[M]
S613	EVQ21405RJ	SW CD 5	[M]
S614	EVQ21405RJ	SW CD 4	[M]
S615	EVQ21405RJ	SW CD 3	[M]
S616	EVQ21405RJ	SW CD 2	[M]
S617	EVQ21405RJ	SW CD 1	[M]
S618	EVQ21405RJ	SW POWER	[M]
S619	EVQ21405RJ	SW S. SEQ	[M]
S701	RSH1A048-A	SW RESET	[M]
S780	RSH1A049-U	SW OPEN	[M]
S971	RSH1A018-3U	SW MODE	[M]
S972	RSH1A019-2U	SW HALF	[M]
S973	RSH1A019-2U	SW HALF	[M]
S975	RSH1A019-2U	SW HALF	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
		CONNECTORS	
CN1	K1MN14B00066	14P FFC CONN. (SIDE)	[M]
CN301	RJU100W13	13 PIN B2B CONNECTOR	[M]
CN305	RJS2A4230-F	30P FFC CONNECTOR	[M]
CN306	K1MN14C00004	14P FFC CONN	[M]
CN310	K1KA02A00008	FAN CONNECTOR	[M]
CN500	K1MN14A00049	14P FFC CONNECTOR	[M]
CN504	RJT119W08V	8P CONNECTOR	[M]
CN505	K1KB07A00016	7P CONNECTOR	[M]
CN506	RJT119W06V	6P CONNECTOR 2.5 MM	[M]
CN507A	REXX0320	2 PIN STANDBY WIRE	[M]
CN602	RJS2A4230-F	30P FFC CONNECTOR	[M]
CN606	K1MN19C00001	19P FFC CONN	[M]
CN607A	K1KA12B00095	12P CONNECTOR	[M]
CN608	K1MN14B00058	14P FFC CONN	[M]
CN609B	K1KA09B00064	CONNECTOR	[M]
CN611	K1KA03A00086	3P CONNECTOR	[M]
CN701	RJS2A8616	16P FPC CONNECTOR	[M]
CN702	RJS1A9319	19P FFC CONNECTOR	[M]
CN1303	RJS1A5711	11P CONNECTOR	[M]
CN1304	RJS1A5709	9P CONNECTOR	[M]
CP501	RJT100W13	13P BTB CONNECTOR	[M]
CP1301	RJS1A6805-J	CONNECTOR	[M]
CP1902	K1KA09B00058	CONNECTOR	[M]
CS971	RJU071H09M1	CONNECTOR	[M]
		COILS & TRANSFORMERS	
L1	RLQZP1R2JT-Y	RF CHOKE COIL	[M]
L2	G0CR47KA0029	RF CHOKE COIL	[M]
L102	G0C1R0JA0027	COIL	[M]
L110	G0A200D00002	RF CHOKE COIL	[M]
L111	G0A200D00002	RF CHOKE COIL	[M]
L600	G0C101JA0027	COIL	[M]
L601	G0C100JA0027	COIL	[M]
L602	G0C101JA0027	COIL	[M]
L603	G0C3R3JA0027	COIL	[M]
L605	G0C101JA0027	COIL	[M]
L1301	7L1A62N	BIAS OCS COIL	[M]
L1302	RLQB470JTD-D	RF CHOKE COIL	[M]
T501	G4C6ADD00004	POWER TRANSFORMER	[M] ⚠
T502	RTP1H3E002	BACK-UP TRANSFORMER	[M] ⚠
		COMPONENT COMBINATION	
Z101	RLA2Z007-T	COIL	[M]
Z102	RLI2Z021M-T	AM IF BLOCK	[M]
Z501	ERZV10V511CS	ZENER	[M] ⚠
Z602	B3RAB0000012	REMOTE SENSOR	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
		CERAMIC FILTERS	
CF201	J0B1075A0061	CERAMIC FILTER	[M]
CF202	J0B1075A0061	CERAMIC FILTER	[M]
		RELAY	
RL501	RSY0040M-0	POWER RELAY	[M] ⚠
		OSCILLATORS	
X102	RLFDFT22DD	CRYSTAL OSCILLATOR	[M]
X103	H0H720400005	CRYSTAL OSCILLATOR	[M]
X600	RSXZ4M19D01T	CERAMIC OSCILLATOR	[M]
X601	RSXD32K7S02	CRYSTAL OSCILLATOR	[M]
X701	H2A169500009	CERAMIC OSCILLATOR	[M]
		DISPLAY TUBE	
FL600	A2BD00000052	FL DISPLAY	[M]
		FUSES	
F1	K5D162AQ0004	1.6A FUSE	[M] ⚠
		FUSE HOLDERS	
FC1	EYF52BC	FUSE HOLDER	[M]
FC2	EYF52BC	FUSE HOLDER	[M]
		FUSE PROTECTOR	
FP501	K5G402AA0003	FUSE PROTECTOR	[M] ⚠
FP502	K5G102AA0003	FUSE PROTECTOR	[M] ⚠
		HOLDERS	
H303	K1YF08000003	8P WIRE HOLDER	[M]
H307	RMR0318	9P WIRE HOLDER	[M]
H503	K1YF06000002	6P WIRE HOLDER	[M]
H600	RMR0320	11P WIRE HOLDER	[M]
H604	RMR0316	7P WIRE HOLDER	[M]
H607A	RMR0321	12P WIRE HOLDER	[M]
H609A	RMR0318	9P WIRE HOLDER	[M]
H610A	RMR0316	7P WIRE HOLDER	[M]
H610B	RMR0316	7P WIRE HOLDER	[M]
H611	RMR0312	3P CABLE HOLDER	[M]
		JACKS	
JK101	RJH5414-1	JK ANTENNA	[M]
JK301	K4BC04B00036	JK RED/BLACK SPEAKER	[M]

[illegible]	[illegible]	JK RED/BLACK SPEAKER	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
JK302	K4BC04B00037	JK BLUE/GRAY SPEAKER	[M]
JK303	RJH2213N-1	JK AUX IN	[M]
JK501	K2AB2B000002	JK AC INLET	[M] ⚠
JK600	RJJ37TK07-X	HEADPHONE JACK	[M]
		EARTH TERMINAL	
E501	SNE1004-2	EARTH TERMINAL	[M]
		WIRES	
W303	REXX0292	8P POWER PCB-MAIN	[M]
W308B	RWJ0102095SS	2P DECK-CASS EJECT	[M]
W503	REXX0290	6P TRANS-PANEL	[M]
W604	RWJ0207130XX	7P (PANEL-TRANS)	[M]
W605	RWJ1107100XX	FRONT TOP PANEL	[M]
W611	REXX0368	WIRE	[M]
W1903	RWJ0102050KR	MOTOR WIRE	[M]
		RESISTORS	
R1	ERDS2TJ104T	100K 1/4W	[M]
R2	ERDS2TJ104T	100K 1/4W	[M]
R3	ERDS2TJ221T	220 1/4W	[M]
R4	ERDS2TJ104T	100K 1/4W	[M]
R5	ERDS2TJ564T	560K 1/4W	[M]
R6	ERDS2TJ391T	390 1/4W	[M]
R7	ERDS2TJ272T	2.7K 1/4W	[M]
R8	ERDS2TJ684T	680K 1/4W	[M]
R9	ERDS2TJ391T	390 1/4W	[M]
R10	ERDS2TJ391T	390 1/4W	[M]
R11	ERDS2TJ684T	680K 1/4W	[M]
R101	ERJ3GEY0R00V	0 1/16W	[M]
R102	ERJ3GEYJ472V	4.7K 1/16W	[M]
R103	ERJ3GEYJ271V	270 1/16W	[M]
R104	ERJ3GEYJ102V	1K 1/16W	[M]
R105	ERJ3GEYJ471V	470 1/16W	[M]
R106	ERJ3GEYJ474V	470K 1/16W	[M]
R107	ERJ3GEYJ331V	330 1/16W	[M]
R110	ERJ3GEYJ102V	1K 1/16W	[M]
R111	ERJ3GEYJ391V	390 1/16W	[M]
R112	ERJ3GEYJ104V	100K 1/16W	[M]
R113	ERJ3GEYJ103V	10K 1/16W	[M]
R114	ERJ3GEYJ562V	5.6K 1/16W	[M]
R115	ERJ3GEYJ561V	560 1/16W	[M]
R116	ERJ3GEYJ102V	1K 1/16W	[M]
R117	ERJ3GEYJ473V	47K 1/16W	[M]
R118	ERJ3GEYJ332V	3.3K 1/16W	[M]
R119	ERJ3GEYJ332V	3.3K 1/16W	[M]
R120	ERJ3GEYJ473V	47K 1/16W	[M]
R121	ERJ3GEYJ223V	22K 1/16W	[M]
R122	ERJ3GEYJ272V	2.7K 1/16W	[M]
R123	ERJ3GEYJ683V	68K 1/16W	[M]
R124	ERJ3GEYJ330V	33 1/16W	[M]

R124	ERJ3GEY0R00V	0Ω 1/16W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R125	ERJ3GEYJ471V	470 1/16W	[M]
R126	ERJ3GEYJ102V	1K 1/16W	[M]
R127	ERJ3GEYJ471V	470 1/16W	[M]
R128	ERJ3GEYJ820V	82 1/16W	[M]
R129	ERJ3GEYJ273V	27K 1/16W	[M]
R130	ERJ3GEYJ103V	10K 1/16W	[M]
R131	ERJ3GEYJ680V	68 1/16W	[M]
R132	ERJ3GEYJ103V	10K 1/16W	[M]
R133	ERJ3GEYJ102V	1K 1/16W	[M]
R134	ERJ3GEYJ471V	470 1/16W	[M]
R135	ERJ3GEYJ102V	1K 1/16W	[M]
R136	ERJ3GEYJ102V	1K 1/16W	[M]
R137	ERJ3GEYJ102V	1K 1/16W	[M]
R138	ERJ3GEYJ332V	3.3K 1/16W	[M]
R141	ERJ3GEYJ682V	6.8K 1/16W	[M]
R142	ERJ3GEYJ682V	6.8K 1/16W	[M]
R143	ERJ3GEYJ223V	22K 1/16W	[M]
R145	ERJ3GEYJ104V	100K 1/16W	[M]
R146	ERJ3GEYJ104V	100K 1/16W	[M]
R151	ERJ3GEYJ820V	82 1/16W	[M]
R152	ERJ3GEY0R00V	0 1/16W	[M]
R201	ERJ3GEYJ183V	18K 1/16W	[M]
R202	ERJ3GEYJ182V	1.8K 1/16W	[M]
R203	ERJ3GEYJ103V	10K 1/16W	[M]
R204	ERJ3GEYJ183V	18K 1/16W	[M]
R205	ERJ3GEYJ223V	22K 1/16W	[M]
R206	ERJ3GEYJ682V	6.8K 1/16W	[M]
R207	ERJ3GEYJ183V	18K 1/16W	[M]
R208	ERJ3GEYJ182V	1.8K 1/16W	[M]
R211	ERJ3GEYJ392V	3.9K 1/16W	[M]
R212	ERJ3GEYJ122V	1.2K 1/16W	[M]
R214	ERJ3GEYJ562V	5.6K 1/16W	[M]
R215	ERJ3GEYJ822V	8.2K 1/16W	[M]
R216	ERJ3GEY0R00V	0 1/16W	[M]
R218	ERDS1FVJ100T	10 1/2W	[M]
R219	ERDS1FVJ100T	10 1/2W	[M]
R301	ERJ3GEYJ472V	4.7K 1/16W	[M]
R302	ERJ3GEYJ103V	10K 1/16W	[M]
R306	ERDS1FVJ1R0T	1 1/2W	[M]
R311	ERJ3GEY0R00V	0 1/16W	[M]
R312	ERJ3GEY0R00V	0 1/16W	[M]
R313	ERJ3GEY0R00V	0 1/16W	[M]
R347	ERJ3GEYJ101V	100 1/16W	[M]
R348	ERJ3GEYJ121V	120 1/16W	[M]
R401	ERJ3GEYJ183V	18K 1/16W	[M]
R402	ERJ3GEYJ182V	1.8K 1/16W	[M]
R403	ERJ3GEYJ103V	10K 1/16W	[M]
R404	ERJ3GEYJ183V	18K 1/16W	[M]
R405	ERJ3GEYJ223V	22K 1/16W	[M]
R406	ERJ3GEYJ682V	6.8K 1/16W	[M]
R407	ERJ3GEYJ183V	18K 1/16W	[M]
R408	ERJ3GEYJ182V	1.8K 1/16W	[M]
R411	ERJ3GEYJ392V	3.9K 1/16W	[M]
R412	ERJ3GEYJ122V	1.2K 1/16W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R414	ERJ3GEYJ562V	5.6K 1/16W	[M]
R415	ERJ3GEYJ822V	8.2K 1/16W	[M]
R416	ERJ3GEY0R00V	0 1/16W	[M]
R418	ERDS1FVJ100T	10 1/2W	[M]
R419	ERDS1FVJ100T	10 1/2W	[M]
R503	ERC12UGK335D	3.3M 1/2W	[M]
R505	ERDS2TJ563T	56K 1/4W	[M]
R506	ERDS2TJ563T	56K 1/4W	[M]
R507	ERDS2TJ103T	10K 1/4W	[M]
R509	ERDS2TJ472T	4.7K 1/4W	[M]
R510	ERDS2TJ122T	1.2K 1/4W	[M]
R511	ERDS1FVJ102T	1K 1/2W	[M]
R512	ERDS1FVJ151T	150 1/2W	[M]
R513	ERDS2TJ331T	330 1/4W	[M]
R514	ERDS2TJ563T	56K 1/4W	[M]
R515	ERDS2TJ563T	56K 1/4W	[M]
R516	ERDS2TJ222T	2.2K 1/4W	[M]
R517	ERDS2TJ331T	330 1/4W	[M]
R518	ERDS2TJ122T	1.2K 1/4W	[M]
R519	ERDS2TJ2R2T	2.2 1/4W	[M]
R520	ERDS2TJ2R2T	2.2 1/4W	[M]
R521	ERDS2TJ101T	100 1/4W	[M]
R522	ERDS1FVJ120T	12 1/2W	[M]
R523	ERD2FCVG120T	12 1/4W	[M]
R524	ERDS2TJ2R2T	2.2 1/4W	[M]
R526	ERDS2TJ103T	10K 1/4W	[M]
R532	ERDS2TJ153T	15K 1/4W	[M]
R533	ERDS2TJ153T	15K 1/4W	[M]
R534	ERDS1FVJ331T	330 1/2W	[M]
R536	ERDS1FVJ2R2T	2.2 1/2W	[M]
R537	ERDS2TJ222T	2.2K 1/4W	[M]
R539	ERDS1FVJ392T	3.9K 1/2W	[M]
R540	ERDS2TJ153T	15K 1/4W	[M]
R541	ERDS2TJ153T	15K 1/4W	[M]
R542	ERDS2TJ332T	3.3K 1/4W	[M]
R543	ERDS2TJ332T	3.3K 1/4W	[M]
R544	ERDS2TJ562T	5.6K 1/4W	[M]
R545	ERDS2TJ562T	5.6K 1/4W	[M]
R546	ERDS2TJ223T	22K 1/4W	[M]
R547	ERDS2TJ683T	68K 1/4W	[M]
R548	ERDS2TJ184T	180K 1/4W	[M]
R549	ERDS1FVJ2R2T	2.2 1/2W	[M]
R550	ERDS1FVJ331T	330 1/2W	[M]
R551	ERDS2TJ104T	100K 1/4W	[M]
R554	ERDS1FVJ331T	330 1/2W	[M]
R556	ERD2FCVG270T	27 1/4W	[M]
R557	ERDS1FVJ270T	27 1/2W	[M]
R561	ERDS2TJ104T	100K 1/4W	[M]
R562	ERDS2TJ394T	390K 1/4W	[M]
R565	ERDS2TJ123T	12K 1/4W	[M]
R566	ERDS2TJ103T	10K 1/4W	[M]
R567	ERDS2TJ151T	150 1/4W	[M]
R568	ERDS1FVJ150T	15 1/2W	[M]
R569	ERDS1FVJ270T	27 1/2W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R571	ERDS1FVJ332T	3.3K 1/2W	[M]
R572	ERDS2TJ561T	560 1/4W	[M]
R573	ERDS2TJ272T	2.7K 1/4W	[M]
R574	ERDS2TJ272T	2.7K 1/4W	[M]
R576	ERDS2TJ103T	10K 1/4W	[M]
R577	ERDS2TJ103T	10K 1/4W	[M]
R578	ERDS2TJ332T	3.3K 1/4W	[M]
R580	ERDS1FVJ180T	18 1/2W	[M]
R581	ERDS1FVJ180T	18 1/2W	[M]
R583	ERDS2TJ821T	820 1/4W	[M]
R584	ERDS2TJ151T	150 1/4W	[M]
R586	ERDS2TJ151T	150 1/4W	[M]
R587	ERDS2TJ472T	4.7K 1/4W	[M]
R589	ERD2FCVJ4R7T	4.7 1/4W	[M]
R590	ERJ3GEYJ151V	150 1/16W	[M]
R591	ERJ3GEYJ331V	330 1/16W	[M]
R600	ERJ3GEY0R00V	0 1/16W	[M]
R601	ERJ3GEYJ103V	10K 1/16W	[M]
R602	ERJ3GEYJ682V	6.8K 1/16W	[M]
R603	ERJ3GEYJ472V	4.7K 1/16W	[M]
R604	ERJ3GEYJ272V	2.7K 1/16W	[M]
R605	ERJ3GEYJ222V	2.2K 1/16W	[M]
R606	ERJ3GEYJ182V	1.8K 1/16W	[M]
R607	ERJ3GEYJ122V	1.2K 1/16W	[M]
R608	ERJ3GEYJ102V	1K 1/16W	[M]
R609	ERJ3GEYJ102V	1K 1/16W	[M]
R610	ERJ3GEYJ103V	10K 1/16W	[M]
R611	ERJ3GEYJ682V	6.8K 1/16W	[M]
R612	ERJ3GEYJ472V	4.7K 1/16W	[M]
R613	ERJ3GEYJ272V	2.7K 1/16W	[M]
R614	ERJ3GEYJ222V	2.2K 1/16W	[M]
R615	ERJ3GEYJ182V	1.8K 1/16W	[M]
R616	ERJ3GEYJ122V	1.2K 1/16W	[M]
R617	ERJ3GEYJ102V	1K 1/16W	[M]
R618	ERJ3GEYJ102V	1K 1/16W	[M]
R619	ERJ3GEYJ103V	10K 1/16W	[M]
R620	ERJ3GEYJ103V	10K 1/16W	[M]
R621	ERJ3GEYJ101V	100 1/16W	[M]
R622	ERJ3GEYJ101V	100 1/16W	[M]
R623	ERJ3GEYJ223V	22K 1/16W	[M]
R624	ERJ3GEYJ101V	100 1/16W	[M]
R625	ERJ3GEYJ472V	4.7K 1/16W	[M]
R626	ERJ3GEYJ472V	4.7K 1/16W	[M]
R627	ERJ3GEYJ473V	47K 1/16W	[M]
R628	ERJ3GEYJ473V	47K 1/16W	[M]
R629	ERJ3GEYJ472V	4.7K 1/16W	[M]
R630	ERJ3GEYJ101V	100 1/16W	[M]
R631	ERJ3GEYJ101V	100 1/16W	[M]
R632	ERJ3GEYJ101V	100 1/16W	[M]
R633	ERJ3GEYJ472V	4.7K 1/16W	[M]
R634	ERJ3GEY0R00V	0 1/16W	[M]
R636	ERJ3GEYJ471V	470 1/16W	[M]
R638	ERJ3GEYJ101V	100 1/16W	[M]
R639	ERJ3GEYJ222V	2.2K 1/16W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R644	ERJ3GEYJ473V	47K 1/16W	[M]
R645	ERJ3GEYJ473V	47K 1/16W	[M]
R646	ERJ3GEYJ473V	47K 1/16W	[M]
R647	ERJ3GEYJ473V	47K 1/16W	[M]
R648	ERJ3GEYJ473V	47K 1/16W	[M]
R649	ERJ3GEYJ223V	22K 1/16W	[M]
R650	ERJ3GEYJ102V	1K 1/16W	[M]
R651	ERJ3GEYJ473V	47K 1/16W	[M]
R652	ERJ3GEYJ473V	47K 1/16W	[M]
R653	ERJ3GEYJ473V	47K 1/16W	[M]
R654	ERJ3GEYJ473V	47K 1/16W	[M]
R655	ERJ3GEYJ473V	47K 1/16W	[M]
R656	ERJ3GEYJ473V	47K 1/16W	[M]
R657	ERJ3GEYJ473V	47K 1/16W	[M]
R658	ERJ3GEYJ221V	220 1/16W	[M]
R659	ERJ3GEYJ473V	47K 1/16W	[M]
R660	ERJ3GEYJ101V	100 1/16W	[M]
R661	ERJ3GEYJ101V	100 1/16W	[M]
R662	ERJ3GEYJ103V	10K 1/16W	[M]
R663	ERJ3GEYJ123V	12K 1/16W	[M]
R664	ERJ3GEYJ223V	22K 1/16W	[M]
R665	ERJ3GEYJ223V	22K 1/16W	[M]
R666	ERJ3GEYJ223V	22K 1/16W	[M]
R667	ERJ3GEYJ472V	4.7K 1/16W	[M]
R668	ERJ3GEYJ223V	22K 1/16W	[M]
R669	ERJ3GEYJ470V	47 1/16W	[M]
R670	ERJ3GEYJ681V	680 1/16W	[M]
R671	ERJ3GEYJ221V	220 1/16W	[M]
R672	ERJ3GEY0R00V	0 1/16W	[M]
R673	ERJ3GEYJ334V	330K 1/16W	[M]
R674	ERJ3GEYJ106V	10M 1/16W	[M]
R675	ERJ3GEYJ472V	4.7K 1/16W	[M]
R676	ERJ3GEYJ472V	4.7K 1/16W	[M]
R678	ERJ3GEYJ101V	100 1/16W	[M]
R679	ERJ3GEYJ103V	10K 1/16W	[M]
R680	ERJ3GEYJ102V	1K 1/16W	[M]
R681	ERJ3GEYJ103V	10K 1/16W	[M]
R682	ERJ3GEYJ471V	470 1/16W	[M]
R683	ERJ3GEYJ473V	47K 1/16W	[M]
R684	ERJ3GEYJ223V	22K 1/16W	[M]
R685	ERJ3GEYJ474V	470K 1/16W	[M]
R686	ERJ3GEYJ472V	4.7K 1/16W	[M]
R687	ERJ3GEYJ680V	68 1/16W	[M]
R688	ERJ3GEYJ680V	68 1/16W	[M]
R689	ERJ3GEYJ332V	3.3K 1/16W	[M]
R690	ERJ3GEYJ471V	470 1/16W	[M]
R691	ERJ3GEYJ471V	470 1/16W	[M]
R692	ERJ3GEYJ471V	470 1/16W	[M]
R693	ERJ3GEYJ471V	470 1/16W	[M]
R694	ERJ3GEYJ561V	560 1/16W	[M]
R695	ERJ3GEYJ101V	100 1/16W	[M]
R697	ERJ3GEYJ101V	100 1/16W	[M]
R698	ERJ3GEYJ101V	100 1/16W	[M]
R699	ERJ3GEYJ101V	100 1/16W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R700	ERDS1FVJ180T	18 1/2W	[M]
R700	ERJ3GEYJ221V	220 1/16W	[M]
R701	ERDS2TJ563T	56K 1/4W	[M]
R701	ERJ3GEYJ221V	220 1/16W	[M]
R701	ERJ3GEYJ4R7V	4.7 1/16W	[M]
R702	ERDS2TJ101T	100 1/4W	[M]
R702	ERJ3GEYJ103V	10K 1/16W	[M]
R703	ERDS2TJ103T	10K 1/4W	[M]
R704	ERDS2TJ563T	56K 1/4W	[M]
R704	ERJ3GEYJ102V	1K 1/16W	[M]
R705	ERDS2TJ103T	10K 1/4W	[M]
R705	ERJ3GEYJ393V	39K 1/16W	[M]
R706	ERDS2TJ472T	4.7K 1/4W	[M]
R706	ERJ3GEYJ102V	1K 1/16W	[M]
R707	ERDS2TJ562T	5.6K 1/4W	[M]
R707	ERJ3GEYJ154V	150K 1/16W	[M]
R708	ERDS2TJ103T	10K 1/4W	[M]
R708	ERJ3GEYJ154V	150K 1/16W	[M]
R708	ERJ3GEYJ473V	47K 1/16W	[M]
R709	ERDS2TJ824T	820K 1/4W	[M]
R709	ERJ3GEYJ473V	47K 1/16W	[M]
R710	ERDS2TJ563T	56K 1/4W	[M]
R711	ERDS2TJ824T	820K 1/4W	[M]
R711	ERJ3GEYJ823V	82K 1/16W	[M]
R712	ERJ3GEYJ221V	220 1/16W	[M]
R713	ERDS2TJ563T	56K 1/4W	[M]
R714	ERJ3GEY0R00V	0 1/16W	[M]
R715	ERJ3GEYJ102V	1K 1/16W	[M]
R717	ERJ3GEYJ102V	1K 1/16W	[M]
R718	ERJ3GEYJ102V	1K 1/16W	[M]
R720	ERDS2TJ683T	68K 1/4W	[M]
R721	ERDS2TJ683T	68K 1/4W	[M]
R721	ERJ3GEYJ101V	100 1/16W	[M]
R722	ERDS2TJ104T	100K 1/4W	[M]
R723	ERDS2TJ102T	1K 1/4W	[M]
R723	ERJ3GEYJ103V	10K 1/16W	[M]
R724	ERDS2TJ104T	100K 1/4W	[M]
R724	ERJ3GEYJ153V	15K 1/16W	[M]
R725	ERDS2TJ102T	1K 1/4W	[M]
R725	ERJ3GEYJ681V	680 1/16W	[M]
R726	ERDS2TJ273T	27K 1/4W	[M]
R727	ERDS2TJ104T	100K 1/4W	[M]
R727	ERJ3GEYJ272V	2.7K 1/16W	[M]
R728	ERDS2TJ102T	1K 1/4W	[M]
R728	ERJ3GEYJ222V	2.2K 1/16W	[M]
R729	ERDS2TJ102T	1K 1/4W	[M]
R729	ERJ3GEYJ272V	2.7K 1/16W	[M]
R730	ERDS2TJ224T	220K 1/4W	[M]
R731	ERDS2TJ562T	5.6K 1/4W	[M]
R731	ERJ3GEYJ103V	10K 1/16W	[M]
R732	ERDS2TJ153T	15K 1/4W	[M]
R732	ERJ3GEYJ102V	1K 1/16W	[M]
R733	ERDS2TJ153T	15K 1/4W	[M]
R734	ERDS2TJ221T	220 1/4W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R735	ERDS2TJ224T	220K 1/4W	[M]
R735	ERJ3GEYJ101V	100 1/16W	[M]
R736	ERDS2TJ562T	5.6K 1/4W	[M]
R736	ERJ3GEYJ101V	100 1/16W	[M]
R737	ERDS2TJ681T	680 1/4W	[M]
R738	ERDS2TJ153T	15K 1/4W	[M]
R739	ERDS2TJ681T	680 1/4W	[M]
R740	ERDS2TJ153T	15K 1/4W	[M]
R741	ERDS2TJ562T	5.6K 1/4W	[M]
R741	ERJ3GEYJ473V	47K 1/16W	[M]
R742	ERDS2TJ562T	5.6K 1/4W	[M]
R742	ERJ3GEYJ224V	220K 1/16W	[M]
R743	ERDS2TJ102T	1K 1/4W	[M]
R744	ERDS2TJ153T	15K 1/4W	[M]
R744	ERJ3GEYJ393V	39K 1/16W	[M]
R745	ERDS2TJ562T	5.6K 1/4W	[M]
R746	ERDS2TJ562T	5.6K 1/4W	[M]
R747	ERDS2TJ102T	1K 1/4W	[M]
R748	ERDS2TJ152T	1.5K 1/4W	[M]
R749	ERDS2TJ152T	1.5K 1/4W	[M]
R749	ERJ3GEYJ272V	2.7K 1/16W	[M]
R750	ERDS2TJ332T	3.3K 1/4W	[M]
R750	ERJ3GEYJ103V	10K 1/16W	[M]
R751	ERDS2TJ332T	3.3K 1/4W	[M]
R751	ERJ3GEYJ472V	4.7K 1/16W	[M]
R752	ERDS2TJ104T	100K 1/4W	[M]
R753	ERDS2TJ103T	10K 1/4W	[M]
R753	ERJ3GEYJ100V	10 1/16W	[M]
R754	ERDS2TJ220T	22 1/4W	[M]
R754	ERJ3GEYJ5R6V	5.6 1/16W	[M]
R755	ERDS2TJ220T	22 1/4W	[M]
R756	ERDS2TJ220T	22 1/4W	[M]
R757	ERDS2TJ220T	22 1/4W	[M]
R758	ERDS2TJ103T	10K 1/4W	[M]
R759	ERDS2TJ682T	6.8K 1/4W	[M]
R760	ERDS2TJ223T	22K 1/4W	[M]
R761	ERDS2TJ223T	22K 1/4W	[M]
R762	ERDS2TJ103T	10K 1/4W	[M]
R763	ERDS2TJ103T	10K 1/4W	[M]
R764	ERDS2TJ683T	68K 1/4W	[M]
R765	ERDS2TJ683T	68K 1/4W	[M]
R766	ERDS2TJ123T	12K 1/4W	[M]
R767	ERDS2TJ123T	12K 1/4W	[M]
R768	ERDS2TJ472T	4.7K 1/4W	[M]
R769	ERDS2TJ472T	4.7K 1/4W	[M]
R770	ERDS2TJ332T	3.3K 1/4W	[M]
R771	ERDS2TJ104T	100K 1/4W	[M]
R772	ERDS2TJ682T	6.8K 1/4W	[M]
R773	ERDS2TJ102T	1K 1/4W	[M]
R774	ERDS2TJ104T	100K 1/4W	[M]
R775	ERDS2TJ153T	15K 1/4W	[M]
R776	ERDS2TJ102T	1K 1/4W	[M]
R777	ERDS2TJ221T	220 1/4W	[M]
R778	ERDS2TJ153T	15K 1/4W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R779	ERDS2TJ153T	15K 1/4W	[M]
R780	ERDS2TJ473T	47K 1/4W	[M]
R781	ERDS2TJ473T	47K 1/4W	[M]
R900	ERJ3GEYJ103V	10K 1/16W	[M]
R901	ERJ3GEYJ103V	10K 1/16W	[M]
R902	ERJ3GEYJ103V	10K 1/16W	[M]
R903	ERJ3GEYJ103V	10K 1/16W	[M]
R904	ERJ3GEYJ123V	12K 1/16W	[M]
R905	ERJ3GEYJ472V	4.7K 1/16W	[M]
R906	ERJ3GEYJ472V	4.7K 1/16W	[M]
R907	ERJ3GEYJ472V	4.7K 1/16W	[M]
R910	ERJ3GEYJ472V	4.7K 1/16W	[M]
R911	ERJ3GEYJ103V	10K 1/16W	[M]
R912	ERJ3GEYJ101V	100 1/16W	[M]
R913	ERJ3GEYJ562V	5.6K 1/16W	[M]
R914	ERJ3GEYJ562V	5.6K 1/16W	[M]
R915	ERJ3GEYJ562V	5.6K 1/16W	[M]
R916	ERJ3GEYJ562V	5.6K 1/16W	[M]
R917	ERJ3GEYJ101V	100 1/16W	[M]
R918	ERJ3GEYJ101V	100 1/16W	[M]
R919	ERJ3GEYJ101V	100 1/16W	[M]
R920	ERJ3GEYJ104V	100K 1/16W	[M]
R921	ERJ3GEYJ104V	100K 1/16W	[M]
R922	ERJ3GEYJ104V	100K 1/16W	[M]
R923	ERJ3GEYJ223V	22K 1/16W	[M]
R924	ERJ3GEYJ103V	10K 1/16W	[M]
R925	ERJ3GEYJ223V	22K 1/16W	[M]
R930	ERJ3GEYJ102V	1K 1/16W	[M]
R972	ERDS2TJ821T	820 1/4W	[M]
R973	ERDS2TJ393T	39K 1/4W	[M]
R1101	ERJ3GEYJ270V	27 1/16W	[M]
R1102	ERJ3GEYJ152V	1.5K 1/16W	[M]
R1103	ERJ3GEYJ183V	18K 1/16W	[M]
R1104	ERJ3GEYJ103V	10K 1/16W	[M]
R1105	ERJ3GEYJ222V	2.2K 1/16W	[M]
R1106	ERJ3GEYJ104V	100K 1/16W	[M]
R1107	ERJ3GEYJ102V	1K 1/16W	[M]
R1109	ERJ3GEYJ102V	1K 1/16W	[M]
R1110	ERJ3GEYJ333V	33K 1/16W	[M]
R1201	ERJ3GEYJ270V	27 1/16W	[M]
R1202	ERJ3GEYJ152V	1.5K 1/16W	[M]
R1203	ERJ3GEYJ183V	18K 1/16W	[M]
R1204	ERJ3GEYJ103V	10K 1/16W	[M]
R1205	ERJ3GEYJ222V	2.2K 1/16W	[M]
R1206	ERJ3GEYJ104V	100K 1/16W	[M]
R1207	ERJ3GEYJ102V	1K 1/16W	[M]
R1209	ERJ3GEYJ102V	1K 1/16W	[M]
R1210	ERJ3GEYJ333V	33K 1/16W	[M]
R1302	ERJ3GEYJ331V	330 1/16W	[M]
R1303	ERJ3GEYJ475V	4.7M 1/16W	[M]
R1304	ERJ3GEYJ223V	22K 1/16W	[M]
R1305	ERJ3GEYJ103V	10K 1/16W	[M]
R1307	ERD25FVJ220T	22 1/4W	[M]
R1308	ERD25FVJ220T	22 1/4W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
R1309	ERDS1FVJ471T	470 1/2W	[M]
R1313	ERJ3GEYJ103V	10K 1/16W	[M]
R1314	ERJ3GEYJ102V	1K 1/16W	[M]
R1316	ERJ3GEYJ102V	1K 1/16W	[M]
R1318	ERJ3GEYJ103V	10K 1/16W	[M]
R1327	ERJ3GEYJ472V	4.7K 1/16W	[M]
R1328	ERJ3GEYJ153V	15K 1/16W	[M]
R1329	ERJ3GEYJ472V	4.7K 1/16W	[M]
R1330	ERD2FCVJ4R7T	4.7 1/4W	[M]
R1331	ERJ3GEYJ752V	7.5K 1/16W	[M]
R1332	ERJ3GEYJ103V	10K 1/16W	[M]
R1333	ERD2FCVJ4R7T	4.7 1/4W	[M]
R1334	ERJ3GEYJ223V	22K 1/16W	[M]
R1335	ERJ3GEYJ152V	1.5K 1/16W	[M]
R1336	ERJ3GEYJ152V	1.5K 1/16W	[M]
R1337	ERJ3GEYJ103V	10K 1/16W	[M]
R1338	ERJ3GEYJ472V	4.7K 1/16W	[M]
R1341	ERJ3GEYJ471V	470 1/16W	[M]
R1342	ERJ3GEYJ473V	47K 1/16W	[M]
R1343	ERJ3GEYJ332V	3.3K 1/16W	[M]
R1344	ERJ3GEYJ273V	27K 1/16W	[M]
R1345	ERJ3GEYJ102V	1K 1/16W	[M]
R1371	ERJ3GEYJ223V	22K 1/16W	[M]
R1374	ERJ3GEYJ471V	470 1/16W	[M]
R1401	ERJ3GEYJ123V	12K 1/16W	[M]
R1402	ERJ3GEYJ274V	270K 1/16W	[M]
R1403	ERJ3GEYJ103V	10K 1/16W	[M]
R1404	ERJ3GEYJ223V	22K 1/16W	[M]
R1405	ERJ3GEYJ103V	10K 1/16W	[M]
		CAPACITORS	
C1	F1D1H5R6A017	5.6P 50V	[M]
C2	F1D1H102A029	1000P 50V	[M]
C3	F1D1H2R2A017	2.2P 50V	[M]
C4	ECBT1H181KB5	180P 50V	[M]
C5	F1D1H5R6A017	5.6P 50V	[M]
C6	F1D1H3R3A017	3.3P 50V	[M]
C7	F1D1H4R7A017	4.7P 50V	[M]
C8	F1D1H3R3A017	3.3P 50V	[M]
C9	F1D1H2R2A017	2.2P 50V	[M]
C10	ECBT1H180JC5	18P 50V	[M]
C11	F1D1E103A001	0.01 25V	[M]
C11	F1D1H102A029	1000P 50V	[M]
C12	ECA1CAK101XE	100 16V	[M]
C21	F1D1E103A001	0.01 25V	[M]
C22	ECA1CAK101XE	100 16V	[M]
C101	ECJ1VB1E103K	0.01 25V	[M]
C102	ECA1CAK100XB	10 16V	[M]
C103	ECJ1VB1E103K	0.01 25V	[M]
C104	ECJ1VB1H102K	1000P 50V	[M]
C106	ECJ1VB1H103K	0.01 50V	[M]
C107	ECUV1C473KBV	0.047 16V	[M]
C108	ECUV1H080DCV	8P 50V	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
C109	ECJ1VB1H102K	1000P 50V	[M]
C110	ECJ1VB1E103K	0.01 25V	[M]
C111	ECA1HAK4R7XB	4.7 50V	[M]
C112	ECJ1VB1E103K	0.01 25V	[M]
C113	ECJ1VB1H102K	1000P 50V	[M]
C114	ECA1HAK3R3XB	3.3 50V	[M]
C115	ECA1HAK4R7XB	4.7 50V	[M]
C116	ECUV1C333KBV	0.033 16V	[M]
C117	ECJ1VB1E103K	0.01 25V	[M]
C118	ECJ1VB1E103K	0.01 25V	[M]
C119	F0A2A681A010	680P 100V	[M]
C120	ECA1CAK100XB	10 16V	[M]
C121	ECA1HAKR47XB	0.47 50V	[M]
C122	ECA1HAK010XB	1 50V	[M]
C123	ECA1HAK010XB	1 50V	[M]
C124	ECUV1H101JCV	100P 50V	[M]
C125	ECA1CAK220XB	22 16V	[M]
C126	ECJ1VF1A105Z	10 10V	[M]
C127	ECA1CAK220XB	22 16V	[M]
C129	ECA0JAK101XB	100 6.3V	[M]
C130	ECA0JAK101XB	100 6.3V	[M]
C131	ECJ1VC1H151J	150P 50V	[M]
C132	ECJ1VB1H102K	1000P 50V	[M]
C133	ECUV1H270JCV	27P 50V	[M]
C134	ECUV1H270JCV	27P 50V	[M]
C136	ECJ1VB1H102K	1000P 50V	[M]
C137	ECUV1H332KBV	3300P 50V	[M]
C138	ECJ1VB1E103K	0.01 25V	[M]
C139	ECA1HAK4R7XB	4.7 50V	[M]
C141	ECA1HAK010XB	1 50V	[M]
C142	ECA1HAK010XB	1 50V	[M]
C143	ECUV1H682KBV	6800P 50V	[M]
C144	ECUV1H682KBV	6800P 50V	[M]
C147	ECJ1VB1H102K	1000P 50V	[M]
C148	ECJ1VB1E103K	0.01 25V	[M]
C149	F1H1C104A065	0.1 16V	[M]
C201	ECUV1H101JCV	100P 50V	[M]
C202	ECUV1H101JCV	100P 50V	[M]
C203	ECA1HAK4R7XB	4.7 50V	[M]
C205	ECA1HAK2R2XB	2.2 50V	[M]
C206	ECUV1H221KBV	220P 50V	[M]
C207	ECA1CAK100XB	10 16V	[M]
C208	ECA1HAK2R2XB	2.2 50V	[M]
C209	ECA1HAK2R2XB	2.2 50V	[M]
C210	ECUV1H471KBV	470P 50V	[M]
C211	ECQV1H823JZ3	0.082 50V	[M]
C212	ECQV1H394JZ3	0.39 50V	[M]
C213	ECA1CAK100XB	10 16V	[M]
C215	ECA1HAK2R2XB	2.2 50V	[M]
C217	ECJ1VB1H102K	1000P 50V	[M]
C218	ECUV1E473KBV	0.047 25V	[M]
C219	ECUV1E473KBV	0.047 25V	[M]
C301	ECJ1VB1H102K	1000P 50V	[M]
C302	ECJ1VB1E103K	0.01 25V	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
C303	ECUV1H101JCV	100P 50V	[M]
C304	ECUV1H101JCV	100P 50V	[M]
C305	ECUV1H101JCV	100P 50V	[M]
C306	ECA1HAK220XB	22 50V	[M]
C307	ECA1CAK101XB	100 16V	[M]
C308	ECJ1VB1H103K	0.01 50V	[M]
C401	ECUV1H101JCV	100P 50V	[M]
C402	ECUV1H101JCV	100P 50V	[M]
C403	ECA1HAK4R7XB	4.7 50V	[M]
C405	ECA1HAK2R2XB	2.2 50V	[M]
C406	ECUV1H221KBV	220P 50V	[M]
C407	ECA1CAK100XB	10 16V	[M]
C408	ECA1HAK2R2XB	2.2 50V	[M]
C409	ECA1HAK2R2XB	2.2 50V	[M]
C410	ECUV1H471KBV	470P 50V	[M]
C411	ECQV1H823JZ3	0.082 50V	[M]
C412	ECQV1H394JZ3	0.39 50V	[M]
C413	ECA1CAK100XB	10 16V	[M]
C415	ECA1HAK2R2XB	2.2 50V	[M]
C417	ECJ1VB1H102K	1000P 50V	[M]
C418	ECUV1E473KBV	0.047 25V	[M]
C419	ECUV1E473KBV	0.047 25V	[M]
C500	F1D1H821A012	820P 50V	[M]
C501	F1D1H821A012	820P 50V	[M]
C502	F1D1H821A012	820P 50V	[M]
C503	F1D1H821A012	820P 50V	[M]
C504	F1D1H330A006	33P 50V	[M]
C505	F1D1H330A006	33P 50V	[M]
C506	ECA1VAM222XB	2200 35V	[M]
C507	ECA1VAM222XB	2200 35V	[M]
C508	ECA1EAM332XE	3300 25V	[M]
C509	F1D1H330A006	33P 50V	[M]
C510	F1D1H330A006	33P 50V	[M]
C511	ECKR1H103ZF5	0.01 50V	[M]
C512	ECA1CAK101XB	100 16V	[M]
C513	ECKR1H103ZF5	0.01 50V	[M]
C514	ECA1AAK330XB	33 10V	[M]
C515	ECBT1H103KB5	0.01 50V	[M]
C516	ECA1HAK100XB	10 50V	[M]
C517	ECKR2H103ZF5	0.01 500V	[M]
C518	ECKR1H103ZF5	0.01 50V	[M]
C520	ECKR1H103ZF5	0.01 50V	[M]
C521	ECA1EAK330XB	33 25V	[M]
C526	ECA1HM330B	33 50V	[M]
C528	ECKR1H103ZF5	0.01 50V	[M]
C530	ECQE2104KF3	0.1 250V	[M]
C533	ECQV1H104JZ3	0.1 50V	[M]
C535	F1D1H1040002	0.1 50V	[M]
C536	ECA1AAK221XB	220 10V	[M]
C537	F1D1H102A012	1000P 50V	[M]
C548	ECKR1H103ZF5	0.01 50V	[M]
C550	ECJ1VB1H103K	0.01 50V	[M]
C551	ECUV1H104KBV	0.1 50V	[M]
C552	ECA1HAK4R7XB	4.7 50V	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
C553	**ECA1HAK010XB**	**1 50V**	**[M]**
C575	**ECA1HAK4R7XB**	**4.7 50V**	**[M]**
C576	**RCA1CM102BT**	**1000P 16V**	**[M]**
C577	**RCA1CM102BT**	**1000P 16V**	**[M]**
C578	**ECKR1H103ZF5**	**0.01 50V**	**[M]**
C580	**ECKR1H103ZF5**	**0.01 50V**	**[M]**
C581	**ECA1HAM470XB**	**47 50V**	**[M]**
C582	**ECQE2104KF3**	**0.1 250V**	**[M]**
C583	**ECKR1H103ZF5**	**0.01 50V**	**[M]**
C585	**ECA1EAM101XB**	**100 25V**	**[M]**
C586	**ECA2AM100B**	**10 100V**	**[M]**
C587	**ECA1JM101B**	**100 63V**	**[M]**
C588	**ECA1HM101B**	**100 50V**	**[M]**
C601	**ECEA1VKA220B**	**22 35V**	**[M]**
C602	**ECEA1VKA220B**	**22 35V**	**[M]**
C613	**ECA0JAK101XB**	**100 6.3V**	**[M]**
C614	**F1H1C104A065**	**0.1 16V**	**[M]**
C615	**ECA0JM102B**	**1000 6.3V**	**[M]**
C616	**ECJ1VB1H102K**	**1000P 50V**	**[M]**
C617	**ECJ1VB1H331K**	**330P 50V**	**[M]**
C618	**ECUV1H221KBV**	**220P 50V**	**[M]**
C619	**ECUV1H221KBV**	**220P 50V**	**[M]**
C620	**ECUV1H221KBV**	**220P 50V**	**[M]**
C621	**ECJ1VB1H103K**	**0.01 50V**	**[M]**
C622	**ECA1CAK220XB**	**22 16V**	**[M]**
C623	**ECUV1H561KBV**	**560P 50V**	**[M]**
C624	**ECUV1H561KBV**	**560P 50V**	**[M]**
C625	**ECUV1H561KBV**	**560P 50V**	**[M]**
C626	**ECUV1H561KBV**	**560P 50V**	**[M]**
C627	**ECUV1H101JCV**	**100P 50V**	**[M]**
C628	**ECUV1H101JCV**	**100P 50V**	**[M]**
C632	**ECUV1C223KBV**	**0.022 16V**	**[M]**
C633	**ECJ1VC1H680J**	**68P 50V**	**[M]**
C634	**ECJ1VC1H680J**	**68P 50V**	**[M]**
C635	**ECJ1VC1H180J**	**18P 50V**	**[M]**
C636	**ECJ1VC1H220J**	**22P 50V**	**[M]**
C637	**ECUV1H560JCV**	**56P 50V**	**[M]**
C638	**ECUV1H560JCV**	**56P 50V**	**[M]**
C639	**ECJ1VB1H102K**	**1000P 50V**	**[M]**
C640	**ECJ1VB1H102K**	**1000P 50V**	**[M]**
C641	**ECJ1VB1H103K**	**0.01 50V**	**[M]**
C642	**ECUV1H101JCV**	**100P 50V**	**[M]**
C643	**ECUV1H101JCV**	**100P 50V**	**[M]**
C644	**ECA1HAK010XB**	**1 50V**	**[M]**
C645	**ECA1HAK2R2XB**	**2.2 50V**	**[M]**
C646	**ECA1HAK3R3XB**	**3.3 50V**	**[M]**
C647	**ECJ1VB1H102K**	**1000P 50V**	**[M]**
C648	**ECJ1VB1H103K**	**0.01 50V**	**[M]**
C649	**ECA0JAK470XB**	**47 6.3V**	**[M]**
C651	**F1H1C104A065**	**0.1 16V**	**[M]**
C652	**ECUV1H101JCV**	**100P 50V**	**[M]**
C653	**ECUV1H101JCV**	**100P 50V**	**[M]**
C654	**ECUV1H101JCV**	**100P 50V**	**[M]**
C655	**ECUV1H101JCV**	**100P 50V**	**[M]**

Ref. No.	Part No.	Part Name & Description	Remarks
C656	ECUV1H101JCV	100P 50V	[M]
C657	ECUV1H101JCV	100P 50V	[M]
C658	ECUV1H101JCV	100P 50V	[M]
C659	ECUV1H101JCV	100P 50V	[M]
C660	ECUV1H101JCV	100P 50V	[M]
C661	ECUV1E473KBV	0.047 25V	[M]
C662	ECJ1VB1E223K	0.022 25V	[M]
C663	ECJ1VB1E223K	0.022 25V	[M]
C664	ECUV1H104KBV	0.1 50V	[M]
C700	ECA0JAK101XB	100 6.3V	[M]
C701	ECEA0JKA330I	33 6.3V	[M]
C701	ECEA1CKA330B	33 16V	[M]
C702	ECA1HAK2R2XB	2.2 50V	[M]
C702	F1H1C104A065	0.1 16V	[M]
C703	ECEA0JKA101I	100 6.3V	[M]
C703	F1D1H1040002	0.1 50V	[M]
C704	ECA1AAK221XB	220 10V	[M]
C704	F1H1C104A065	0.1 16V	[M]
C705	ECEA1AKN100B	10 10V	[M]
C705	F1H1C104A065	0.1 16V	[M]
C706	ECUV1C473KBV	0.047 16V	[M]
C707	ECUV1C393KBV	0.039 16V	[M]
C709	F1D1H102A012	1000P 50V	[M]
C710	ECUV1H391KBV	390P 50V	[M]
C710	F1D1H102A012	1000P 50V	[M]
C711	ECA1CAK100XB	10 16V	[M]
C711	ECJ1VB1H272K	2700P 50V	[M]
C712	ECBT1C122KR5	1200P 16V	[M]
C712	ECJ1VB1H272K	2700P 50V	[M]
C713	ECA1HAK2R2XB	2.2 50V	[M]
C713	F1H1C104A065	0.1 16V	[M]
C714	ECEA0JKA101I	100 6.3V	[M]
C714	ECFR1C273KR	0.027 16V	[M]
C715	ECBT1C122KR5	1200P 16V	[M]
C715	ECJ1VB1H272K	2700P 50V	[M]
C716	ECA1HAK2R2XB	2.2 50V	[M]
C716	ECUV1H821KBV	820P 50V	[M]
C717	ECFR1C273KR	0.027 16V	[M]
C717	ECUV1E104ZFV	0.1 25V	[M]
C718	ECUV1A224KBV	0.22 10V	[M]
C720	ECA1HAK010XB	1 50V	[M]
C721	ECJ1VC1H150J	15P 50V	[M]
C721	F1D1C562A010	5600P 16V	[M]
C722	ECJ1VC1H150J	15P 50V	[M]
C722	F1D1C562A010	5600P 16V	[M]
C723	ECA1HAK010XB	1 50V	[M]
C723	ECEA1AKA221I	220 10V	[M]
C724	F1D1C562A010	5600P 16V	[M]
C724	F1H1C104A065	0.1 16V	[M]
C725	ECJ1VB1H102K	1000P 50V	[M]
C725	F1D1C562A010	5600P 16V	[M]
C726	ECA1CAK100XB	10 16V	[M]
C726	ECJ1VB1H102K	1000P 50V	[M]
C727	ECA1CAK100XB	10 16V	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
C727	ECA1HAK010XI	1 50V	[M]
C728	ECA1HAK010XI	1 50V	[M]
C728	ECBT1C332KR5	3300P 16V	[M]
C729	ECBT1C332KR5	3300P 16V	[M]
C730	ECA1HAK3R3XB	3.3 50V	[M]
C730	ECUV1E104ZFV	0.1 25V	[M]
C731	ECA0JAK221XI	220 6.3V	[M]
C731	ECA1HAK3R3XB	3.3 50V	[M]
C732	ECEA0JKA221I	220 6.3V	[M]
C733	F1H1C104A065	0.1 16V	[M]
C734	ECEA1AKA221I	220 10V	[M]
C735	ECUV1E104ZFV	0.1 25V	[M]
C736	ECQV1H124JZ3	0.12 50V	[M]
C737	ECQV1H124JZ3	0.12 50V	[M]
C738	ECA1CAK100XB	10 16V	[M]
C738	ECUV1C563KBV	0.056 16V	[M]
C739	ECUV1H222KBV	2200P 50V	[M]
C739	F1D1C272A010	2700P 16V	[M]
C740	F1D1C272A010	2700P 16V	[M]
C741	ECA1HAKR33XB	0.33 50V	[M]
C742	ECA1HAKR33XB	0.33 50V	[M]
C742	ECUV1C473KBV	0.047 16V	[M]
C743	ECBT1H103KB5	0.01 50V	[M]
C743	ECUV1E104ZFV	0.1 25V	[M]
C744	ECBT1H103KB5	0.01 50V	[M]
C744	ECUV1H562KBV	5600P 50V	[M]
C745	ECUV1E104ZFV	0.1 25V	[M]
C745	F1D1H101A012	100P 50V	[M]
C746	F1D1H101A012	100P 50V	[M]
C747	ECBT1H470JC5	47P 50V	[M]
C747	ECUV1H471KBV	470P 50V	[M]
C748	ECBT1H470JC5	47P 50V	[M]
C749	ECBT1H822KB5	8200P 50V	[M]
C749	ECJ1VB1H222K	2200P 50V	[M]
C750	ECBT1H822KB5	8200P 50V	[M]
C751	ECA1CAK100XB	10 16V	[M]
C752	ECA1CAK100XB	10 16V	[M]
C752	ECUV1H152KBV	1500P 50V	[M]
C753	ECUV1H471KBV	470P 50V	[M]
C754	ECUV1H471KBV	470P 50V	[M]
C1101	ECA1HAK010XB	1 50V	[M]
C1102	ECUV1H471KBV	470P 50V	[M]
C1103	ECA1CAK101XB	100 16V	[M]
C1104	ECUV1C273KBV	0.027 16V	[M]
C1105	ECUV1H471KBV	470P 50V	[M]
C1106	ECA1HAK2R2XB	2.2 50V	[M]
C1107	F1H1H152A219	1500P 50V	[M]
C1108	ECA1CAK100XB	10 16V	[M]
C1109	ECA1HAK3R3XB	3.3 50V	[M]
C1110	ECUV1H682KBV	6800P 50V	[M]
C1121	ECJ1VB1H102K	1000P 50V	[M]
C1122	ECUV1E103KBV	0.01 25V	[M]
C1123	ECUV1H271KBV	270P 50V	[M]
C1201	ECA1HAK010XB	1 50V	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
C1202	ECUV1H471KBV	470P 50V	[M]
C1203	ECA1CAK101XB	100 16V	[M]
C1204	ECUV1C273KBV	0.027 16V	[M]
C1205	ECUV1H471KBV	470P 50V	[M]
C1206	ECA1HAK2R2XB	2.2 50V	[M]
C1207	F1H1H152A219	1500P 50V	[M]
C1208	ECA1CAK100XB	10 16V	[M]
C1209	ECA1HAK3R3XB	3.3 50V	[M]
C1210	ECUV1H682KBV	6800P 50V	[M]
C1221	ECJ1VB1H102K	1000P 50V	[M]
C1222	ECUV1E103KBV	0.01 25V	[M]
C1223	ECUV1H271KBV	270P 50V	[M]
C1301	ECA1HAK0R1XB	0.1 50V	[M]
C1302	ECUV1C333KBV	0.033 16V	[M]
C1303	ECUV1C333KBV	0.033 16V	[M]
C1304	ECEA1HKA4R7B	4.7 50V	[M]
C1305	ECA1CAK330XB	33 16V	[M]
C1307	ECA1AAK221XQ	220 10V	[M]
C1308	ECA1CAK220XB	22 16V	[M]
C1310	ECA1HAK0R1XB	0.1 50V	[M]
C1311	ECA1CAK470XB	47 16V	[M]
C1312	ECUV1H332KBV	3300P 50V	[M]
C1314	ECUV1H222KBV	2200P 50V	[M]
C1315	ECUV1H222KBV	2200P 50V	[M]
C1316	ECJ1VB1H102K	1000P 50V	[M]
C1317	ECJ1VB1H102K	1000P 50V	[M]
C1318	ECQV1H473JZ3	0.047 50V	[M]
C1319	ECA1CAK101XB	100 16V	[M]
C1320	ECA1HAK010XB	1 50V	[M]
C1321	ECQP1472JZT	4700P 100V	[M]
C1322	F0A2A102A010	1000P 100V	[M]
C1323	ECEA1HKN010B	1 50V	[M]
C1324	ECA1CAK470XB	47 16V	[M]
C1325	ECUV1E103KBV	0.01 25V	[M]
C1326	ECA1CAK100XB	10 16V	[M]
C1371	ECUV1E103KBV	0.01 25V	[M]
		CHIP JUMPER	
RJ701	ERJ3GEY0R00V	0 1/16W	[M]
RJ702	ERJ3GEY0R00V	0 1/16W	[M]
RJ703	ERJ3GEY0R00V	0 1/16W	[M]
RJ704	ERJ3GEY0R00V	0 1/16W	[M]
RJ707	ERJ3GEY0R00V	0 1/16W	[M]
RJ708	ERJ3GEY0R00V	0 1/16W	[M]
RJ709	ERJ3GEY0R00V	0 1/16W	[M]
RJ711	ERJ3GEY0R00V	0 1/16W	[M]
RJ712	ERJ3GEY0R00V	0 1/16W	[M]
RJ713	ERJ3GEY0R00V	0 1/16W	[M]
RJ714	ERJ3GEY0R00V	0 1/16W	[M]
RJ715	ERJ3GEY0R00V	0 1/16W	[M]
RJ716	ERJ3GEY0R00V	0 1/16W	[M]
RJ717	ERJ3GEY0R00V	0 1/16W	[M]
RJ718	ERJ3GEY0R00V	0 1/16W	[M]

Ref. No.	Part No.	Part Name & Description	Remarks
RJ719	ERJ3GEY0R00V	0 1/16W	[M]
RJ720	ERJ3GEY0R00V	0 1/16W	[M]
RJ721	ERJ3GEY0R00V	0 1/16W	[M]
RJ722	ERJ3GEY0R00V	0 1/16W	[M]
RJ723	ERJ3GEY0R00V	0 1/16W	[M]
RJ724	ERJ3GEY0R00V	0 1/16W	[M]
RJ725	ERJ3GEY0R00V	0 1/16W	[M]
RJ726	ERJ3GEY0R00V	0 1/16W	[M]
RJ727	ERJ3GEY0R00V	0 1/16W	[M]
RJ728	ERJ3GEY0R00V	0 1/16W	[M]
RJ729	ERJ3GEY0R00V	0 1/16W	[M]
RJ731	ERJ3GEY0R00V	0 1/16W	[M]
RJ732	ERJ3GEY0R00V	0 1/16W	[M]
RJ733	ERJ3GEY0R00V	0 1/16W	[M]
RJ734	ERJ3GEY0R00V	0 1/16W	[M]
RJ735	ERJ3GEY0R00V	0 1/16W	[M]
RJ736	ERJ3GEY0R00V	0 1/16W	[M]
RJ738	ERJ3GEY0R00V	0 1/16W	[M]

20.5. Packing Materials & Accessories Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
		PACKING MATERIALS	
P1	RPGX1166	PACKING CASE	[M]
P2	RPNX0162	POLYFOAM	[M]
P3	RPHV0001	MIRAMAT	[M]
		ACCESSORIES	
A1	EUR7711020	REMOTE CONTROL	[M]
A1-1	UR64EC2337J	R/C BATTERY COVER	[M]
A2	K2CB2CB00006	AC CORD	[M] ⚠
A3	RQT6683-P	O/I BOOK (En)	[M]
A3	RQT6684-M	O/I BOOK (Sp)	[M]
A4	RSA0006-L	FM ANTENNEA	[M]
A5	RSA0033A	AM LOOP ANTENNA	[M]

20.6. Packaging

ACCESSORIES CASE
A1 : REMOTE CONTROL
A2 : AC CORD
A3 : O/I BOOK
A4 : FM ANTENNA WIRE
A5 : AM LOOP ANTENNA


*P2 (A)
P2 (RPNX0162)
*P2 (B)
A1
A2
A3
A4
A5
SPACER
*P2 (A)
P3 (RPHV0001)
(SA-PM16)
MAIN UNIT
SB-PM18
SPEAKER
UNIT
*P2 (B)
P1 (RPGX1166)

PRT0303 D/E/J/N/S/A

A B C D E F G

1 2 3 4 5 6 7 8 9

I TACT SWITCH P.C.B (REPX0349A)


VOLUME
S617
CD1
S616
CD2
S615
CD3
S614
CD4
S613
CD5
R618
R617
R616
R615
R614
S604
DEMO
S608
TUNER
S607
TAPE
S606
CD
R604
R605
R608
R609
R606
R607
J804
J802
J801
J800
R603
R602
J806
R601
R613
R612
R610
R611
J803
J805
VR600
R662
R664
R663
C627
C628
Q614
C
B
E
S619
SSEQ
R693
D638
H610A
1 2 3 4 5 6 7
H607A
1 2 3 4 5 6 7 8 9 10 11 12
PbF

J AC LED P.C.B (REPX0349A)


D633
R689
H610B
7 6 5 4 3 2 1
S618
POW_ON
S609
AUX
PbF
S605
FF
S603
REW
S612
CD_CHECK

K HEADPHONE P.C.B (REPX0349A)


HEADPHONE
JK600
5 3 1
4 6
2 7
PbF
J14
J808
S611
CD_CHANGE
S610
CD_EJECT
H609A
9 8 7 6 5 4 3 2 1
C662
C663
L600
L601
C661
L602
J809
R623
S600
REC

L SENSOR P.C.B (REPX0349A)

F TAPE EJECT P.C.B (REPX0350A)


SENSOR
Z602
3
2
1
C649
C648
C647
3
2
1
H611/W611
PbF


S602
TAPE EJECT
PbF
W308B
2
1

H AC TRANSFORMER P.C.B (REPX0348A)


F1 125V 1.6A
FC1
FC2
RL501
1
2
3
4
T502 (SUB-TRANSFORMER)
CN507B
3
2
1
CN507A
3
2
1
J513
J514
J520
T501 (POWER TRANSFORMER)
Z501
R503
J511
J512
J519
J517
J518
JK501
J504
J503
J502
J501
AC IN
120V 60HZ

A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9


G
H
I
J
K
L
M
CN507A
3
2
1
3
4
J513
J514
J520
D579
C578
D580
C575
C576
R583
J505
PbF
J506
D505
J500
J509
CN505
1
2
3
4
5
6
7
Q575
E C B
R578
Q579
E
C
B
J510
D578
R581
R580
Q577
C580
E
C
B
C585
D581
C577
FP501
400
Z501
R503
C582
R577
D589
D584
D588
D587
J508
R576
D593
D582
C581
Q578
E C B
R584
D594
C548
C583
CN506
1
2
3
4
5
6
R586
R587
C586
J521
J516
R589
J511
J512
FP502
1000
C588
D592
C587
J519
J517
J518
J507

CAUTION
RISK OF ELECTRIC SHOCK
AC VOLTAGE LINE.
PLEASE DO NOT TOUCH THIS P.C.B

SCHEMATIC DIAGRAM -1


A
CD SERVO CIRCUIT
: +B SIGNAL LINE
: CD SIGNAL LINE
OPTICAL PICKUP CIRCUIT
CN701
E
VREF
A
NC
LPD
GND
GND
F
VCC
B
LD
LDG
C2 0.22
C1 0.47
C3 0.22
VR1
TRACKING COIL
FOCUS COIL
VCC
F
E
LD
LD GND
GND
A
GND
B
VREF
LPD
GND
T-
T+
F-
F+
Q701
R701 4.7
C701 6.3V33
Q701
2SA1037AKSTX
LASER POWER DRIVE
R754 5.6
C714 6.3V100
C713 0.1
TJ
TJ701
C703 6.3V100
C704 0.1
R750 10K
R751 4.7K
C702 0.1
C705 0.1
C707 0.039
C706 0.047
IC701
AN22004A-NF
SERVO AMP
IC701
LPD
LD
VCC
EQSW
RFOUT
RFIN
AGC
AGC
HPF-AMP
3TOUT
HPFDET
OFTCNT
BDO
OFTR
/RFDET
LDON
A
C
B
D
F
E
TBAL
FBAL
GCTL
FEOUT
FEN
TEOUT
TEN
VREF
EOBST
GND
C747 470P
R744 39K
C710 390P
R702 10K
R705 39K
C711 2700P
C712 2700P
C749 2200P
C742 0.047
R708 150K
R707 150K
R706 1K
R704 1K
TP 40
TP 33
IC703
BA5948FPE2
FOCUS COIL/
TRACKING COIL/
TRAVERSE MOTOR/
SPINDLE MOTOTR DRIVE
IC703
D3-
D3+
D4-
D4+
PVCC2
PGND2
NC
GND
NC
NC
NC
VCC
VREF
IN4
IN3
D2+
D2-
D1+
D1-
PVCC1
PGND1
NC
GND
NC
NC
NC
PC1
IN1
PC2
IN2
C735 0.1
C734 10V220
R732 1K
R723 10K
R736 100
TP 39
C737 0.12
TP 38
M701
TRV MOTOR
TP 36
C736 0.12
TP 37
M701
SPL MOTOR
R735 100
R725 680
C715 2700P
R724 15K
R715 1K
C752 1500P
C738 0.056
C739 2200P
R729 2.7K
R728 2.2K
R727 2.7K
R749 2.7K
R731 10K

SCHEMATIC DIAGRAM - 2

A CD SERVO CIRCUIT

—— : +B SIGNAL LINE ⇨ : CD SIGNAL LINE


TP 13
TP 14
TP 16
D750
MAZ80560ML
TP 19
R717
1K
C725
1000P
+
C727
50V1
TP 18
R721
100
C726
1000P
TP 17
R718
1K
+
C728
50V1
+
C731
6.3V220
C730
0.1
25
TP
27
TP
C754
470P
+
C732
6.3V220
C733
0.1
C753
470P
CN702
Lch OUT 19
A.GND 18
Rch OUT 17
+3.3V 16
LD SW 15
D.GND 14
+7.5V 13
TX 12
P.GND 11
MCLK 10
MDATA 9
MLD 8
BLKCK 7
SQCK 6
SUBQ 5
STAT 4
/RST 3
REST SW 2
LOADING 1
TO C PANEL CIRCUIT (CN606) ON SCHEMATIC DIAGRAM-8
35 TP
24 TP
26 TP
+
C723
10V220
C724
0.1
7 TP
8 TP
9 TP
6 TP
5 TP
C743
0.1
4 TP
X701
H2A169500009
R714
0
C722
15P
C721
15P
TP 31
R753
10
TP 3
IC702
MN662790RSC
SERVO PROCESSOR
DIGITAL SIGNAL PROCESSOR/
DIGITAL FILTER/
D/A CONVERTER
61 BYTCK
62 /CLDCK
63 FCLK
64 IPFLAG
65 FLAG
66 CLVS
67 CRC
68 DEMPH
69 RESY
70 IOSEL
71 /TEST
72 AVDD1
73 OUTL
74 AVSS1
75 OUTR
76 RSEL
77 IOVDD
78 PSEL
79 MSEL
80 SSEL
60 VDD
59 X2 OUT
58 X1 IN
57 VSS
56 SBCK
55 SUBC
54 VCOF2
53 PCK
52 EFM
51 AVSS2
50 AVDD2
49 VCOF
48 PLLF
47 DSLF
46 DRF
45 IREF
44 ARF
43 WVEL
42 DSLF2
41 PLLF2
1 BCLK
2 LRCK
3 SRDATA
4 DVDD1
5 DVSS1
6 TX
7 MCLK
8 MDATA
9 MLD
10 SENSE
11 /FLOCK
12 /TLOCK
13 BLKCK
14 SQCK
15 SUBQ
16 DMUTE
17 STAT
18 /RST
19 SMCK
20 CSEL
40 LDON
39 BDO
38 /RFDET
37 TRCRS
36 OFT
35 VDET
34 RFENV
33 TE
32 FE
31 TBAL
30 FBAL
29 VREF
28 FOD
27 TRD
26 KICK
25 ECS
24 ECM
23 PC
22 TVD
21 TRV
TP 28
TP 29
TP 30
C745
0.1
C718
0.22
R712
220
C744
5600P
R711
82K
C717
0.1
R709
47K
R741
47K
C716
820P
R742
220K
TP 1
S701
RESET SW
TP 11
TP 10

SCHEMATIC DIAGRAM - 3

B MAIN (TUNER) CIRCUIT

—— : +B SIGNAL LINE
➡ : AM SIGNAL LINE
▯▯⇨ : FM OSC SIGNAL LINE
⇨ : FM SIGNAL LINE
■■➡ : AM OSC SIGNAL LINE


N TUNER PACK CIRCUIT
FM EXT ANT
UNBALANCED 75 OHM
GND
JK101
AM LOOP ANT
AM EXT ANT
Z120 RAL0029
5.6P
2SK544 RF AMP
100K
0.001
2.2P
1.2u
820K
3.3P
10P
180P
2SC2786M FM MIXER
0.47u
390
0.001
100K
220
100K
560K
390
2SC1675L1L2 BUFFER AMP LOCAL OSC
390
2.7K
4.7P
2.2P
680K
10P
2.2P
CF201 J0B1075A0061
C103 0.01
R107 330
R106 470K
C104 1000P
R105 470
Q101
C101 0.01
C102 16V10
R103 270
Q101 2SC2058SPTA SWITCHING
L102 1.0µH
Z101 RLA2Z007-T
AM ANT COIL
AM OSC COIL
C136 1000P
C114 50V3.3
R118 3.3K
R119 3.3K
C127 16V22
C126 10
R110 1K
C107 0.047
R112 100K
C108 8P
D101 UDZSTE175R1B
R117 47K
R111 390
R128 82
C125 16V22
R113 10K
D101
C132 1000P
C130 6.3V100
C111 50V4.7
R114 5.6K
R115 560
R116 1K
R129 27K
C124 100P
C112 0.01
R151 82
C113 1000P
C133 27P
C110 0.01
R152 0
X103 H0H720400005
C134 27P
Xout VSS AOUT AIN PD VDD FMIN AMIN MONO IFIN
IC102
Xin CE DI CL DO AM LW SDC STRQ FM
R138 3.3K
R130 10K
R137 1K
R136 1K
R135 1K
R134 470
IC102 LC72131MDTRM PLL IC (TUNER)
CE
PLLDA
PLLCLK
DO/ST

SCHEMATIC DIAGRAM - 4

B MAIN (TUNER) CIRCUIT

— : +B SIGNAL LINE
➡ : AM SIGNAL LINE
⇨ : FM SIGNAL LINE
➡ : AM OSC SIGNAL LINE
➡ : FM/AM SIGNAL LINE



R104
1K
R101
0
CF202
J0B1075A0061
R121
22K
C120
16V10
Q106
Q106
KRA102MTA
TUNER SUPPLY
SWITCH
R143
22K
C138
0.01
R120
47K
C115
50V4.7
C119
680P
C116
0.033
C139
50V4.7
R102
4.7K
C131
150P
R123
68K
C137
3300P
C118
0.01
C117
0.01
C142
50V1
R142
6.8K
C141
50V1
R141
6.8K
R145
100K
R146
100K
C143
6800P
C144
6800P
C109
1000P
OSC OUT
OSC
AFC
AM RF in
AGC
AM OUT
DET OUT
PILOT IN
MPX IN
PILOT OUT
Rch
Lch
IC101
IC101
LA1833NMNTLM
IF & MPX IC
(TUNER)
FM IF in
AM MIX out
REG
AM IF in
GND
SD
ST
FM DET
VCC
STRQ
FM/AM
Mono
C106
0.01
Z102
RL12Z021M-T
R124
33
X102
RLFDFT22DD
C122
50V1
R122
2.7K
C121
50V0.47
C123
50V1
R131
68
C129
6.3V100
C148
0.01
C147
1000P
C149
0.1
R126
1K
R125
470
R127
470
R132
10K
R133
1K
SD
DO/ST
RCH A
CE B
LCH C
PLLDA D
PLLCLK E
TGND F
15V G
DO/ST H
SD I
7.5V J
(1B)
B
TO
MAIN CIRCUIT
(1A) ON
SCHEMATIC
DIAGRAM - 5

SCHEMATIC DIAGRAM - 5

B MAIN CIRCUIT

⇨ : MAIN SIGNAL LINE
⇨ : AUX SIGNAL LINE
⇨ : PLAYBACK SIGNAL LINE
— : +B SIGNAL LINE
➡ : AM/FM SIGNAL LINE
⇨ : RECORD SIGNAL LINE
⇨ : CD SIGNAL LINE


AUX
LCH
GND
RCH
JK303
R201 18K
C201 100P
C202 100P
R202 1.8K
C401 100P
C402 100P
R402 1.8K
R401 18K
C308 0.01
C301 1000P
(1A)
A TUN_R
B CE
C TUN_L
D PLLDA
E PLLCLK
F TGND
G 15V
H SQCLK/DO
I SD
J 7.5V
R301 4.7K
PLLCE
PLLDA
PLLCLK
TGND
15V
R302 10K
SQCLK/DO
SD
+9V
D301 RL1N4003N02
D302 RL1N4003N02
C302 0.01
TO B MAIN (TUNER) CIRCUIT (1B) ON SCHEMATIC DIAGRAM - 4
L110 G0A200D00002
R403 10K
L111 G0A200D00002
R203 10K
R404 18K
R204 18K
IC301 C1BB00000617 ELECTRONIC VOLUME CONTROL & TONE CONTROL
C203 50V4.7
C208 50V2.2
C215 50V2.2
C209 50V2.2
C210 470P
C211 0.082
C212 0.39
R211 3.9K
C213 16V10
R212 1.2K
R216 0
C303 100P
C304 100P
C305 100P
15 NC
14 L1
13 L2
12 L3
11 L4
10 LSEL0
9 LIN
8 LTRE
7 LBASS1
6 LBASS2
5 LOUT
4 TEST
3 VSS
2 CE
1 DI
AUX
TAPE
TUNER
CD
IC301
16 NC
17 R1
18 R2
19 R3
20 R4
21 RSEL0
22 RIN
23 RTRE
24 RBASS1
25 RBASS2
26 ROUT
27 NC
28 VREF
29 VDD
30 CL
C403 50V4.7
C408 50V2.2
C415 50V2.2
C409 50V2.2
C410 470P
C411 0.082
C412 0.39
C306 50V22
C307 16V100
R411 3.9K
R306 1
C413 16V10
R412 1.2K
R416 0
TO D DECK CIRCUIT (CN1304) ON SCHEMATIC DIAGRAM-10
9 PGND
8 MO10V
7 +9V
6 9VGND
5 PBL
4 PBR
3 DECK_AGND
2 RECL
1 RECR
H307
MO10V
+9V
R214 5.6K
C205 50V2.2
R414 5.6K
R415 8.2K
C406 220P
R215 8.2K
C206 220P
C405 50V2.2
R207 18K
C207 16V10
R407 18K
C407 16V10
R408 1.8K
R208 1.8K
+9V
PLAY_SW
ST_SW
M1_ROUT
M1_FOUT
OPEN_SW
120 SW5V
POS
BT_SW
M2_ROUT
M2_FOUT
R348 100
R347
PLAY_SW
ST_SW
M1_ROUT
M1_FOUT
OPEN_SW
SW5V
POS
BT_SW
M2_ROUT
M2_FOUT
(CDDGND)GND2
PGND
PGND
+7.5V
14 13 12 11 10 9 8 7 6 5 4 3 2 1
CN306
TO M CD LOADING CIRCUIT (CN1) ON SCHEMATIC DIAGRAM-14

SCHEMATIC DIAGRAM - 6

B MAIN CIRCUIT

: MAIN SIGNAL LINE
: +B SIGNAL LINE
: CD SIGNAL LINE


RDS_CL
RDS_DA
+9V
TX
CD3.3V
PGND
CDR
CDAGND
CDL
ASP_CLK
ASP_LATCH
ASP_DATA
M2_FOUT
M2_ROUT
BT_SW
POS
OPEN_SW
M1_FOUT
M1_ROUT
ST_SW
PLAY_SW
SD
SQCLK/DO
PLLCLK
PLLDA
PLLCE
CN305
TO C PANEL CIRCUIT (CN602) ON SCHEMATIC DIAGRAM-8
R313 0
R311 0
R312 0
R405 22K
C417 1000P
R406 6.8K
C217 1000P
R206 6.8K
R205 22K
C550 0.01
C551 0.1
Q500
Q1000
D502 UDZSTE177R5B
R590 150
MO10V
D501 B0ACCK000005
R591 330
C552 50V4.7
Q500 KTA1046 SWITCH
Q1000 KTC3199GRTA SWITCH
15V
TGND
ROUT
LOUT
AGND
DGND
SW5V
FAN(+)
FAN(-)
+7.5V
CN301
TO G POWER CIRCUIT (CP501) ON SCHEMATIC DIAGRAM-11
C218 0.047
R218 10
C219 0.047
R219 10
C418 0.047
R418 10
C419 0.047
R419 10
LO_R
GND
GND
HI_L
LO_L
GND
GND
HI_R
H303/W303
R_GND
LO_R
L_GND
LO_L
HI_R
R_GND
HI_L
L_GND
JK301
JK302
SPEAKERS
FAN(+)
FAN(-)
CN310
FAN
TO G POWER CIRCUIT (CN504) ON SCHEMATIC DIAGRAM-12

SCHEMATIC DIAGRAM - 7


C PANEL CIRCUIT
: -B SIGNAL LINE
: +B SIGNAL LINE
: MAIN SIGNAL LINE
L SENSOR CIRCUIT
Z602
B3RAB0000012
REMOTE SENSOR
O GND VDD
C647 1000P
C648 0.01
C649 6.3V47
H611/W611
CN611
R669 47
R650 1K
R649 22K
C617 330P
FL600
A2BD00000052
FL DISPLAY
C601 35V22
C602 35V22
RMT
TAPE_EJECT
VREF+
GND2
KEY1
VOL_JOG
KEY2
H/P
SSEQ
+9V
REC_SW
CD_EXCHG
CD_CURR
CN607A
TO I TACT SWITCH CIRCUIT (H607A) ON SCHEMATIC DIAGRAM-13
C613 6.3V100
C614 0.1
C615 1000
C616 1000P
L603 3.3µH
R692 470
R636 470
R690 470
R691 470
R634 0
R633 4.7K
C618 220P
C619 220P
C620 220P
R619 10K
R620 10K
R621 100
R622 100
KEY2
KEY1
HP_R
HP_GND
HP_SW
HP_L
IC600
C02BBGF000424
MICRO PROCESSOR
SEG1 SEG2 SEG3 SEG4 SEG5 SEG6 SEG7 SEG8 SEG9 SEG10 SEG11 SEG12 SEG13 SEG14 SEG15 SEG16 SEG17 SEG18 SEG19 SEG20 SEG21 SEG22 SEG23 SEG24 NC SSEQ RED PLUNGER GREEN EE_CS
GRID8/REG8
GRID7/REG7
GRID6
GRID5/REG5
GRID4/REG4
GRID3/REG3
GRID2/REG2
GRID1/REG1
VEE
REG_IN
VOC_C
VOC_B
ASP_LATCH
PLAY_SW
ASP_CLK
ASP_DATA
AVSS
VREF
PHOTO
DECK1
EE_CLK
DMT
BP1
REC
SSEQCTRL
MUTEH
MUTEA
MOTOR
CD_LED
PCONT
REST_SW
EE_DATA
STOCK_SW
M2_ROUT
M2_FOUT
OPEN
POSITION
DCDET
SYNC
MLD/PLLCE
DECK2 NC KEY2 KEY1 VOL_JOG /CD M1_FOUT CDRST STATUS M1_ROUT BOTTOM SQCK/ST/DO SD SUBQ RDS_CLOCK RDS_DATA CNVSS /RESET Xcout Xcin VSS Xin Xout VCC MBP1 MBP2 MCLK/PLLCK MDATA/PLLDA RMT BLKCK
R632 100
R631 100
R698 100
R660 100
R661 100
R678 100
R630 100
R679 10K
DECK_AD1
DECK_AD2
KEY2
KEY1
VOL_JOG
/CD
M1_FOUT
CDRST
STATUS
M1_ROUT
BT_SW
SQCLK/DO
SD
SUBQ
RDS_CLOCK
RDS_DATA
MCLK/PLLCK
MDATA/PLLDA
RMT
BLKCLK
C623 560P
C624 560P
C625 560P
C626 560P
D621
D620
C621 0.01
C622 16V22
D620, 621
1SS380TE-17
SYS6V
R629 4.7K
VREF+
EE_DAT/EX1_DAT
EE_CLK/EX1_CLK
EE_CS
R667 4.7K
R665 22K
R666 22K
C632 0.022
CD_CURR
CD_EXCHG
REC_SW
HP_R
HP_GND
HP_SW
HP_L
H/P
CN609B
H609A
S610 CD EJECT
S611 CD CHANGE
S600 REC
L602 100µH
C661 0.047
HEADPHONES
R623 22K
L600 100µH
C662 0.022
C663 0.022
L601 100µH
JK600
K HEADPHONE CIRCUIT

SCHEMATIC DIAGRAM - 8

C PANEL CIRCUIT

: -B SIGNAL LINE

: +B SIGNAL LINE

: CD SIGNAL LINE

: MAIN SIGNAL LINE



TO D DECK CIRCUIT (CN1303) ON SCHEMATIC DIAGRAM-10
H600/W600
PHOTO
MOTOR
PLUNGER
GND2
DVREF+
DECK_AD1
DECK_AD2
DMT
BP1
REC
TAPE_EJECT
Q904 KRC101STA MOTOR SWITCH
Q905 KRC101STA PLUNGER SWITCH
Q902 KRC101STA STATUS SWITCH
Q901 KRC101STA SUBQ SWITCH
Q903 KRC101STA BLKCLK SWITCH
Q613, 615 KRC119STA LED DRIVE
Q610 KTA1504GRTA DECK SUPPLY CONTROL
Q611 KRC120STA PCONT SWITCH
Q607 KRC103STA RESET SWITCH
Q608, 609 KTC3875GRTA µ-P BEAT PROOF CONTROL
D632 UDZSTE174R7B
L605 G0C101JA0027
C646 50V3.3
D637 B3CNE0000001
D636 B3CNE0000001
D631 B0ACCK000005
D640 RB501V-40
D641 - 643 RB501V-40
D644 B0ACCK000005
D645 B0ACCK000005
D630 B0ACCK000005
D650 B0ACCK000005
X600 RSXZ4M19B01T
X601 RSXD32K7S02
CN606
TO A CD SERVO CIRCUIT (CN702) ON SCHEMATIC DIAGRAM - 2
LOADING
REST_SW
RST
STAT
SUBQ
SQCK
BLKCK
MLD
MDATA
MCLK
PGND
TX
+7.5V
DGND
LD_SW
CD3.3V
Rch_OUT
AGND
Lch_OUT
CN602
TO B MAIN CIRCUIT (CN305) ON SCHEMATIC DIAGRAM - 6
PLLCE
MDATA/PLLDA
MCLK/PLLCK
SQCLK/DO
SD
PLAY_SW
ST_SW
M1_ROUT
M1_FOUT
OPEN_SW
POS
BT_SW
M2_ROUT
M2_FOUT
ASP_DATA
ASP_LATCH
ASP_CLK
7.5V
CDL
CDAGND
CDR
CD3.3V
TX
9V
RDS_DA/VOC_B
RDS_CLK/VOC_C
CN608
MUTE_A
SSEQ
CDDGND
CD3.3V
MUTE_H
DCDET
/CD
PGND
HP_L
HP_GND
HP_R
HP_SW
R708 47K
VREF+
FL1
FL2
-VP
SYS6V
SYNC (ECONO) PCONT
GND2
H604/W604
TO G POWER CIRCUIT (CN500) ON SCHEMATIC DIAGRAM -11
TO H AC TRANSFORMER CIRCUIT (CN505) ON SCHEMATIC DIAGRAM -13

SCHEMATIC DIAGRAM-9

D DECK CIRCUIT

—— : +B SIGNAL LINE

▨ : PLAYBACK SIGNAL LINE

▨ : REC SIGNAL LINE


CP1301
PBLIN
PBRIN
C1105
470P
R1103
18K
C1102
470P
C1122
0.01
R1101
27
C1104
0.027
R1104
10K
C1303
0.033
R1303
4.7M
C1307
10V220
C1101
50V1
C1103
16V100
C1121
1000P
R1102
1.5K
C1107
1500P
C1106
50V2.2
C1302
0.033
R1302
330
C1108
16V10
C1304
50V4.7
IC1001
AN7326K
P/B REC AMP IC
PB Lin
PB L NF
PB L EQ
PB L out
ALC LOW OUT
TPS GAIN ADJ
REC Lin
REC Lout
ALC
Nor/Cro SW
Vcc
PB AMP (L)
PB AMP (R)
Mute
TPS
REC AMP (L)
REC AMP (R)
NOR/Chro LOGIC
RIPPLE REJECTION
REC/PB LOGIC
PB Rin
PB R NF
PB R EQ
PB Rout
TPS Out
REC Rin
REC Rout
PB/REC SW
RF
GND
C1221
1000P
C1207
1500P
C1301
50V0.1
R1304
22K
C1305
16V33
C1308
16V22
C1203
16V100
R1202
1.5K
C1206
50V2.2
C1204
0.027
C1201
50V1
R1201
27
R1204
10K
C1208
16V10
R1305
10K
C1202
470P
R1203
18K
C1222
0.01
C1205
470P
C1223
270P
IC1000
C1AA00000612
ANALOG SWITCH IC
H=OFF
VCC
L1302
RLQB470JTD-D
Q1309, 1310
B1AAGC000006
BIAS SWITCH
RECH1
C1371
0.01
C1323
1
R1334
22K
C1316
1000P
Q1309
C1324
16V47
R1338
4.7K
R1329
4.7K
R1328
15K
R1333
4.7
C1312
3300P
R1330
4.7
Q1310
L1301
7L1A62N
C1322
1000P
C1321
4700P
C1318
0.047
R1327
4.7K
Q1317
B1ABGC000005
SWITCH BEAT PROOF LEVEL
C1317
1000P
R1335
1.5K
C1319
16V100
C1314
2200P
C1315
2200P
Q1313
2SC2784FTA
SWITCH
R1337
10K
D1301
B0ACCK000005
R1332
10K
Q1312
C1311
16V47
C1325
0.01
C1320
50V1
R1331
7.5K
R1336
1.5K
2SC2412KT96R
BPL

SCHEMATIC DIAGRAM-10

D DECK CIRCUIT

▨ : PLAYBACK SIGNAL LINE
—— : +B SIGNAL LINE ▨ : REC SIGNAL LINE


R1307
22
Q1101, 1201
B1ABGC000005
MUTING SWITCH
R1105
2.2K
R1109
1K
C1110
6800P
R1106
100K
Q1101
R1107
1K
C1123
270P
R1308
22
R1205
2.2K
R1209
1K
C1210
6800P
R1206
100K
Q1201
R1207
1K
R1309
470
D9V
R1313
10K
C1310
50V0.1
Q1302
C1109
50V3.3
C1209
50V3.3
Q1302
DTA114EKA146
DECK MUTING CONTROL
MOTOR_GND
MOTOR_9V
9V
9V_GND
PB Lout
PB Rout
AF_GND
REC Lin
REC Rin
TO B MAIN CIRCUIT (H307) ON SCHEMATIC DIAGRAM - 5
R1110
33K
R1210
33K
CN1304
BPL
RECH1
R1401
12K
R1371
22K
AN6
R1318
10K
VREF+
Q1305
DTC114EKA146
SWITCH
Q1304
10K
4.7K
Q1304
DTC143XKA146
SWITCH (REC:H)
R1403
10K
R1404
22K
AN7
Q1305
10K
10K
Q1303
4.7K
10K
Q1303
DTC143XKA146
SWITCH
R1405
10K
VREF-
R1316
1K
R1314
1K
R1402
270K
PHOTO
Q1315
KTA12710YTA
SWITCH
BP
REC
TAPE_EJECT
REC
BP
DMT
AN6
AN7
VREF+
VREF-
PL_L
MOTOR_L
PHOTO
TO C PANEL CIRCUIT (H600/W600) ON SCHEMATIC DIAGRAM-8
CN1303
PL_VCC
GND2
PHOTO
VREF+
VREF-
Q1315
R1342
47K
R1344
27K
C1326
10V10
R1343
3.3K
CP1902
CS971
R1341
470
R1374
470
10K
4.7K
Q1314
Q1316
R1345
1K
MOTOR_VCC
Q1316
2SD09650RA
SWITCH
Q1314
DTA143XKA146
SWITCH (MOTOR SUPPLY)
D971
MA2C1650OE
PL
CRO2
RECINH_F
MODE
HALF
S973
S975
S971
S972
R972
820
R973
39K
IC971
CNB13030R2AU
PHOTO INTERUPTOR
W1903
−
+
M
W308B
S602
TAPE EJECT
E DECK MECHANISM CIRCUIT
F TAPE EJECT CIRCUIT

SCHEMATIC DIAGRAM - 11

G POWER CIRCUIT

- - - - : -B SIGNAL LINE
——— : +B SIGNAL LINE
⇨ : MAIN SIGNAL LINE


Q700
B1AACF000063
SWITCH
Q701
KTA12710YTA
SWITCH
Q702
B1AACF000063
SWITCH
R704 56K
C700 6.3V100
R702 100
Q700
16V33
C701
10K
R705
Q701
R707 5.6K
R706 4.7K
R708 10K
Q702
R700 18
R701 56K
D706 B0AACK0000004
D705 B0AACK0000004
R703 10K
FAN1
FAN2
10V
R778 15K
Q720
KTC3199GRTA
AGC
R776 1K
D708 MA2C16500E
C738 16V10
R774 100K
R772 6.8K
R752 100K
R758 10K
C750 8200P
R720 68K
R766 12K
C746 100P
C748 47P
C726 16V10
R728 1K
C730 50V3.3
R734 220
R768 4.7K
68K
R764
2700P
C740
50V0.33
C742
0.01
C744
C736 0.082
C737 0.082
R769 4.7K
68K
R765
2700P
C739
50V0.33
C741
0.01
C743
IC501
C0ABB000117
DUAL OP-AMP
C710 1000P
C709 1000P
R725 1K
Q711
R724 100K
Q710
R723 1K
R722 100K
Q710, 711
B1AAGC000006
MUTING SWITCH
Q716, 717
KTC3199GRTA
MUTING SWITCH
C745 100P
C747 47P
C727 16V10
R729 1K
C731 50V3.3
R777 220
R767 12K
R721 68K
R727 100K
C749 8200P
R753 10K
R744 15K
R745 5.6K
R746 5.6K
C723 50V1
R747 1K
Q717
C725 5600P
C724 5600P
Q716
C722 5600P
C721 5600P
R742 5.6K
C720 50V1
R743 1K
R740 15K
R741 5.6K
R775 15K
Q721
R773 1K
D709 MA2C16500E
C711 16V10
R771 100K
R759 6.8K
Q721
KTC3199GRTA
AGC
R730 220K
C712 1200P
R731 5.6K
R737 680
C714 0.027
C713 50V2.2
R733 15K
R732 15K
Q714
Q715
R738 15K
R779 15K
C716 50V2.2
R739 680
C717 0.027
R735 220K
C715 1200P
R736 5.6K
Q714, 715
KTC3199GRTA
MUTING SWITCH
Q718, 719
B1AAGC000006
MUTING SWITCH
Q704
KRA110MTA
MUTING CONTROL
Q704
R748 1.5K
Q718
R750 3.3K
R754 22
R756 22
C728 3300P
C729 3300P
Q719
R751 3.3K
R755 22
R757 22
R749 1.5K
56K
R713
10V10
C705
27K
R726
TO B MAIN CIRCUIT (CN301) ON SCHEMATIC DIAGRAM - 6
1 +15V
2 TGND
3 R_IN
4 L_IN
5 SGND
6 +9V
7 DGND
8 SW5V
9 10V
10 FAN1
11 FAN2
12 7.5V
13 PGND
CP501
+15V
+9V
SW5V
10V
FAN1
FAN2
8.5V
D743
B0EAKM000085
D701
D702
D703
D704
D700
D700-704
B0AACK000004
TO C PANEL CIRCUIT (CN608) ON SCHEMATIC DIAGRAM - 8
1 HP_SW
2 HP_R
3 HP_GND
4 HP_L
5 -9V
6 PGND
7 CD
8 DCDET
9 MUTEH
10 CD3.3V
11
12 CDDGND
13 SSEQ
14 MUTEA
CN500
D527
B0AACK000004
D526
D526
B0AACK000004
CD
DCDET
+9V
MUTE_H
CD3.3V
CD7.5V

SCHEMATIC DIAGRAM - 12

G POWER CIRCUIT

- - - : -B SIGNAL LINE

—— : +B SIGNAL LINE

⇨ : MAIN SIGNAL LINE


Q703
B1AACF000063
SWITCH
Q703
R710 56K
C703 0.1
R711 82K
C704 10V220
D707
B0AACK000004
R709 820K
C702 50V2.2
IC500
HI_L_IN
HI_R_IN
IN_GND
LO_L_IN
LO_R_IN
GND
-VccM
LO_R_OUT
ACDET
LO_L_OUT
HI_R_OUT
-Vcc
+Vcc
HI_L_OUT
14 13 12 11 10 9 8 7 6 5 4 3 2 1
IC500
RSN314H41A-P
POWER AMP
C515 0.01
C503 820P
C501 820P
C500 820P
C502 820P
R514 56K
C509 33P
R515 56K
C510 33P
R506 56K
C505 33P
R505 56K
C504 33P
R534 330
R550 330
R554 330
D508
MAZ4150NLF
R532 15K
R533 15K
R540 15K
R541 15K
R542 3.3K
R543 3.3K
R544 5.6K
R545 5.6K
R761 22K
R763 10K
R760 22K
R762 10K
HI_R 8
GND 7
GND 6
LO_L 5
HI_L 4
GND 3
GND 2
LO_R 1
CN504
TO B MAIN CIRCUIT (H303/W303) ON SCHEMATIC DIAGRAM - 6
R566 10K
Q519
B1AAGC000006
MUTING SWITCH
Q519
R770 3.3K
D530
B0AACK000004
R546 22K
R561 100K
R562 390K
R548 180K
R547 68K
C733
C735
C732
C734
R551 100K
C536 10V220
C537 1000P
Q516
Q515
R565 12K
DCDET
MUTE_H
+15V
Q515, 516
KTC3199GRTA
SWITCH (DCDET)
Q514
2SD0592ARA
VOLTAGE REGULATOR
Q517
KTC32030YTA
VOLTAGE REGULTOR
Q501
KTC2026
VOLTAGE REGULATOR
R781 47K
R780 47K
CD7.5V
Q510
KRA110MTA
SWITCH
SW5V
Q517
CD
Q510
C533 0.1
E501
SNE1004-2
Q514
R556 27
R557 27
C518 0.01
R537 2.2K
C528 0.01
R539 3.9K
C535 0.1
C506 35V2200
R521 100
R522 12
R523 12
CD3.3V
Q503
R567 150
C526 50V33
D524
MAZ4150NMF
4
3
2
1
C530 0.1
C513 0.01
R507 10K
R516 2.2K
D517
B0BA5R6000016
D528 B0AACK000004
D518 B0AACK000004
R510 1.2K
Q507
D541
RLN14003N02
Q501
R536 2.2
R549 2.2
C511 0.01
R512 150
R511 1K
C507 35V2200
R513 330
C514 10V33
R509 4.7K
Q503
KTA12710YTA
CURRENT CONTROL
Q507
KTC3199GRTA
STABILIZER
C512 16V100
D515
B0BA9R60002
D500
KBL402G
8.5V
+9V
R573 2.7K
R572 560
Q505
C516 50V10
Q505
KTA1267GRTA
SUPPLY SWITCH
D540
RLN14003N02
C751 16V10
R574 2.7K
D539
RLN14003N02
10V
C517 0.01
R571 3.3K
R568 15
R569 27
Q506
Q506
KTA1046
CURRENT CONTROL
S3 1
S4 2
GND 3
GND 4
GND2 5
SUB+B 6
C508 25V3300
TO H AC TRANSFORMER CIRCUIT (CN506) ON SCHEMATIC DIAGRAM - 13
H503/ W503
C752 16V10
R524 2.2
R520 2.2
R519 2.2
Q502
KTA1046
STABILIZER
Q502
Q509
KRA110MTA
CURRENT LIMITTING
C520 0.01
R526 10K
Q509
R518 1.2K
D525
B0AACK000004
Q508
KTC3199GRTA
VOLTAGE REGULATOR
Q508
R517 330
C521 25V33
D520
B0BA9R600002

SCHEMATIC DIAGRAM-13

H AC TRANSFORMER CIRCUIT

- - - - : -B SIGNAL LINE

——— : +B SIGNAL LINE


D578
RL1N4003N02
R580
18
R581
18
D581
RL1N4003N02
C585
25V100
Q577
2SC3940ARA
REGULATOR
SYS 6V
Q577
C580
0.01
R583
820
R584
150
C576
1000P
D579
RL1N4003N02
CN507A
CN507B
C578
0.01
C577
16V1000P
D580
RL1N4003N02
C575
50V4.7
D584
D587
C581
50V47
D582
B0BA6R600008
D584,587,588,589
RL1N4003N02
C582
0.1
D589
D588
Q578
R576
10K
C583
0.01
R577
10K
R578
3.3K
Q575
CN505
GND2
ECONO
SYNC
SYS6V
-VP
FL2
FL1
TO C PANEL CIRCUIT (H604/W604) ON SCHEMATIC DIAGRAM - 8
Q578
KRC102MTA
SWITCH
Q575
B1AAGC000006
ECONOMY SWITCH
D505
B0AACK000004
T502
RTP1H3E002
Q579
2SB0621AHA
-VP VOLTAGE
REGULATOR
CN506
S3
S4
GND1
GND2
SUB+B
TO G POWER CIRCUIT (H503/W503) ON SCHEMATIC DIAGRAM - 12
Q579
R589
4.7
D592
RL1N4003N02
C588
50V100
C548
0.01
R586
150
R587
4.7K
C586
100V10
D594
MTZJ24CTA
C587
63V100
D593
RL1N4003N02
FP502
1000
FP501
4000
T501
G4C6ADD00004
RL501
RSY0040M-0
F1
125V 1.6A
FC2
FC1
JK501
AC IN
120V (60Hz)
Z501
ERZV10V511CS
R503
3.3M

I TACT SWITCH CIRCUIT

J AC LED CIRCUIT


S605
+/FF/NEXT
S603
-/REW/PREV
S612
CD CHECK
S618
POWER
R689
3.3K
D633
B3AAA0000583
S609
AUX
+/FF/NEXT
-/REW/PREV
CD_ALL_OPEN
KEY_1
VREF+
GND2
KEY_2
H610B


H610A
+/FF/NEXT
-/REW/PREV
CD_ALL_OPEN
KEY_1
VREF+
GND2
KEY_2
Q614
KRC119STA
LED DRIVE
Q614
D638
LNJ801TPSJA
R693
470
VR600
EVEJ1CF2524B
VOLUME JOG
R663
12K
R664
22K
C627
100P
C628
100P
R662
10K
H607A
TAPE_EJECT
VREF+
GND2
KEY1
VOL_JOG
KEY2
H/P
SSEQ
+9V
REC_SW
CD_EXCHG
CD_CURR
TO C PANEL CIRCUIT (CN607A) ON SCHEMATIC DIAGRAM - 7
R601
10K
R602
6.8K
R603
4.7K
R604
2.7K
R605
2.2K
R606
1.8K
R607
1.2K
R608
1K
R609
1K
S604
DEMO
S606
CD
(PLAY/PAUSE)
S607
TAPE (PLAY)
S608
TUNER/BAND
R610
10K
R611
6.8K
R612
4.7K
R613
2.7K
R614
2.2K
R615
1.8K
R616
1.2K
R617
1K
R618
1K
S619
SSEQ
S613
CD5
S614
CD4
S615
CD3
S616
CD2
S617
CD1

SCHEMATIC DIAGRAM-14

M CD LOADING CIRCUIT

: +B SIGNAL LINE


IC11
C0GAG0000007
UP/DOWN MOTOR DRIVE
VREF
OUT2
RNF
OUT1
VM
VCC
F_IN
GND
R_IN
1
2
3
4
5
6
7
8
9
C11
0.01
C12
16V100
RM11
UP/DOWN
MOTOR
M
S3
BOTTOM
S4
OPEN
S1
STOCK
S2
PLAY
Q1
B3NAA0000068
SENSOR
CN1
1
2
3
4
5
6
7
8
9
10
11
12
13
14
TO B
MAIN CIRCUIT
(CN306) ON
SCHMEATIC
DIAGRAM - 5
IC21
C0GAG0000007
LOADING MOTOR DRIVE
VREF
OUT2
RNF
OUT1
VM
VCC
F_IN
GND
R_IN
1
2
3
4
5
6
7
8
9
C21
0.01
C22
16V100
RM21
LOADING
MOTOR
M


OPTICAL PICKUP
A CD SERVO P.C.B.
SOLDER SIDE
CN702
19 18
1 2
M701
TRV MOTOR
M702
SPL MOTOR
M
CN701
2 1
16 15
PbF
J AC LED P.C.B.
SOLDER SIDE
H610B
1
7
PbF
E DECK MECHANISM P.C.B.
SOLDER SIDE
CS971
9
1
CP1301
4 2
5 3 1
D DECK P.C.B
SOLDER SIDE
MOTOR
W1903
CN1304
1
9
CP1902
9 1
W308B
2 1
CN1303
11 1
I TACT SWITCH P.C.B.
SOLDER SIDE
PbF
H607A
1 12
H610A
1 7
VR600
VOLUME
C PANEL P.C.B
SOLDER SIDE
CN609B
9
1
CN608
1 13
2 14
CN607A
12
1
CN606
1 19
2 18
CN602
1
2
29
30
H604/W604
7
1
CN611
1 2 3
H600/W600
1 11
PbF
K HEADPHONE P.C.B
SOLDER SIDE
H609A
1
9
JK600
HEADPHONE
FM LOOP ANTENNA
AM LOOP ANTENNA
AUX
HIGH-CH SPEAKERS
LOW-CH SPEAKERS
JK101
Z101
JK303
JK302
JK301
H303/W303
8 1
B MAIN P.C.B
SOLDER SIDE
Z102
Z120
CN310
1
2
H307
1
9
CN306
1
2
13
14
CN301
1
13
CN305
30 2
29 1
PbF
L SENSOR P.C.B.
SOLDER SIDE
H611W611
3 2 1
F TAPE EJECT P.C.B.
SOLDER SIDE
W308A
1
2
AC IN ∿
120V 60HZ
JK501
T502
CN507B
T501 (POWER TRANSFORMER)
CN507A
H AC TRANSFORMER P.C.B
SOLDER SIDE
CAUTION
RISK OF ELECTRIC SHOCK
AC VOLTAGE LINE. PLEASE DO NOT
TOUCH THIS P.C.B
CN506
6 1
CN505
7 1
M
UPDOWN MOTOR
CN1
1
14
M CD LOADING P.C.B
SOLDER SIDE
LOADING MOTOR
CN500
1 13
2 14
PbF
H503/W503
6
1
G POWER P.C.B
SOLDER SIDE
CP501
13
1
CN504
1
8


OPTICAL PICKUP
SEMICONDUCTOR LASER
PHOTO DETECTOR
E
E
D
A
D
C
B
C
F
F
+B
Q701
LASER POWER DRIVE
+B
IC701
AN22004A-NF
SERVO AMP
+B
1 LPD
2 LD
27 E
32 A
31 C
30 B
29 D
28 F
3 VCC
8 AGC
RF
13 BDO
14 OFTR
9 INPF-AMP
+B
10 ENV
15 /RFDET
22 FEN
23 FEOUT
20 TEN
21 TEOUT
BDO
OFTR
ENV
/RFDET
FE
TE
16 LDON
4 EQSW
24 GCTL
26 TBAL
25 FBAL
18 EQBST
19 VREF
+B
LDON
FCLK
TBAL
FBAL
IC703
BA5948FPE2
FOCUS COIL/TRACKING COIL/
TRAVERSE MOTOR/
SPINDLE MOTOR DRIVE
VREF 26
+B
FOCUS COIL
F+
F-
15 D3-
16 D3+
[CH3]
LEVEL SHIFT
IN3 28
FOD
TRACKING COIL
T+
T-
17 D4-
18 D4+
[CH4]
LEVEL SHIFT
IN4 27
TRD
M701
TRAVERSE MOTOR
M
14 D2+
13 D2-
[CH2]
LEVEL SHIFT
IN2 1
TVD
ECM
M702
SPINDLE MOTOR
M
12 D1+
11 D1-
[CH1]
LEVEL SHIFT
IN1 3
ECS
MUTE [CH1]
PC1 4
PC
MUTE [CH2]
PC2 2


TO MAIN BLOCK
A
IC702
MN662790RSC
SERVO PROCESSOR/
DIGITAL SIGNAL PROCESSOR/
DIGITAL FILTER/D//A CONVERTER
+B
+B
70
78
79
80
IOSEL
PSEL
MSEL
SSEL
66 CLVS
67 CRC
BLKCK
13 BLKCK
62 /CLDCK
56 SBCK
55 SUBC
68 DEMPH
ST/DO
14 SQCK
SUBQ
15 SUBQ
53 PCK
48 PLLF
52 EFM
41 PLLF2
DSLF2
47 DSLF
46 DRF
RF
44 ARF
76 RSEL
+B
72 AVDO1
CE
9 MLD
CL
7 MCLK
DI
8 MDATA
+B
45 IREF
STAT
17 STAT
54 VCOF2
49 VCOF
61 BYTCK
CD-TEXT BUFFER
SUBCODE BUFFER
EFM DEMODULATION/ SYNC INTERPOLATION SUBCODE DEMODULATION
DSL/PLL VCO
DIGITAL DE-EMPHASIS
8 TIMES OVERSAMPLING DIGITAL FILTER
1 BIT DAC PWM LOGICS
PWM (L)
PWM (R)
OUTL 73
CD SIGNAL
OUTR 75
RCH
FLAG 65
IPFLAG 64
TX 6
ECM 24
ECM
ECS 25
ECS
PC 23
PC
LRCK 2
SRDATA 3
BCLK 1
DMUTE 16
DSLF2 42
DSLF2
KICK 26
TRV 21
VREF 29
+B
TVD 22
TVD
TRD 27
TRD
FOD 28
FOD
TBAL 31
TBAL
FBAL 30
FBAL
/TLOCK 12
/FLOCK 11
16K SRAM
CIRC ERROR CORRECTION/ DEINTERLEAVE
DIGITAL AUDIO INTERFACE
DIGITAL AUDIO INTERFACE
INTERPOLATION/ SOFT MUTING/ DIGITAL ATTENUATION
D/A CONVERTER
OUTPUT PORT
SERVO CPU
MICRO COMPUTER INTERFACE
VCO
TIMING GENERATOR PITCH CONTROL
A/D CONVERTER
INPUT PORT
SERVO TIMING GENERATOR
SMCK 19
FCLK 63
CSEL 20
X2 OUT 59
X1 IN 58
X701
FE 32
TE 33
RFENV 34
TRCRS 37
VDET 35
BDO 39
/RFDET 38
OFT 36
SENSE 10
/RST 18
LDON 40
WVEL 43
FCLK
FE
TE
ENV
BDO
/RFDET
OFTR
CDRST
LDON


FM ANT
Z120
Q1 (RF AMP)
Q2
MIXER
Q3
OSC
Q4
BUFFER
+B
(FM)
CF201
Q101
SWITCHING
CF202
AM ANT
Z101
AM ANT COIL
AM OSC COIL
(FM)
+B
RCH
IC101
LA1833NMNTLM
IF & MPX IC
(TUNER)
ALC
AM OSC
BUFFER
AM MIX
AM RM AMP
AGC
LEVEL DET
S-CURVE
AM/FM IF BUFFER
AM IF
AM DET
FM IF
FM DET
COMP
TUNING DRIVE
DECODER
PHASE DET
PILOT CANCEL
STEREO SWITCH
VCO
FF
FF
FF
PILOT DET
REG
REG
SD
ST
X102
Z102
AM IFT
ST/DO
SD
IC102
LC72131MDTRM
PLL IC
(TUNER)
PHASE DETECTOR CHARGE PUMP
REFERENCE DIVIDER
UNLOCK DETECTOR
SWALLOW COUNTER 1/6,1/17,4 BITS
1 2
12 BITS PROGRAMMABLE DIVIDER
X103
UNIVERSAL COUNTER
POWER ON RESET
SHIFT REGISTER LATCH
C2B I/F
CE
DI
CL
DO
PLLCE
DI
CL
ST/DO
Q106
TUNER SUPPLY SWITCH
+B
+B
(FM)
A
TO CD DRIVE BLOCK


FILTER
CD SIGNAL
JK303
AUX
RCH
RCH
RCH
LSELO
LIN
LTRE
LBASS1
LBASS2
LOUT
10
9
8
7
6
5
11 L4
12 L3
13 L2
14 L1
15 NC
16 NC
17 R1
18 R2
19 R3
20 R4
CONTROL CIRCUIT
CONTROL CIRCUIT
CONTROL CIRCUIT
CCB INTERFACE
LVREF
RVREF
TEST 4
VCC 3
CE 2
DI 1
CL 30
VDD 29
VREF 28
NC 27
+B
RSELO
RIN
RTRE
RBASS1
RBASS2
ROUT
21
22
23
24
25
26
RCH
RCH
IC301
C1BB00000617
ELECTRONIC VOLUME
CONTROL & TONE CONTROL
Q901
SUBQ SWITCH
Q902
STATUS SWITCH
Q903
BLKCLK SWITCH
SUBQ
STAT
BLKCK
PLLCE
CE
DI
CL
SD
ST/DO
CDRST
E
D645
D644
RM11
UP/DOWN MOTOR
M
4 OUT1
2 OUT2
IC11
C0GAG0000007
UP/DOWN MOTOR DRIVER
F_IN 7
R_IN 9
RM21
LOADING MOTOR
M
4 OUT1
2 OUT2
IC21
C0GAG0000007
LOADING MOTOR DRIVER
F_IN 7
R_IN 9
D637
D636
Q615
LED DRIVER
Q613
LED DRIVER
+B
+B
31 MLD/PLLCE
28 MDATA/PLLDA
27 MCLK/PLLCK
13 SD
12 SQCK/ST/DO
8 CDRST
30 BLKCK
9 STATUS
14 SUBQ
36 M2 FOUT
37 M2 ROUT
7 M1 FOUT
10 M1 ROUT
52 GREEN
54 RED
95 ASP_CLK
96 ASP_DATA
93 ASP_LATCH
C2BBGF000424
IC600
MICROPROCESSOR
40 REST_SW
38 STOCK_SW
94 PLAY_SW
11 BOTTOM
35 OPEN
18 /RESET
S701 (RESET)
S1 (STOCK)
S2 (PLAY)
S3 (BOTTOM)
S4 (OPEN)
+B
D621
FILTER
Q607
RESET SWITCH


LCH
(DECK 2)
R/P HEAD
FILTER
Q1101
(Q1201)
MUTING
SWITCH
IC1001
AN7326K
P/B REC AMP
22(1)
21(2)
20(3)
19(4)
18
17
16(7)
15(8)
14
13
12
10
+B
PB LIN(R)
PB L NF(R)
PB L EQ(R)
PB LOUT(R)
ALC LOW OUT
TPS
GAIN ADJ
REC
LIN(R)
REC
L OUT(R)
ALC
NOR/CRO SW
VCC
RF
RIPPLE
REJECTION
TPS
LOGIC
SWITCH
ALC
MUTE
REC AMP (L)
TPS OUT
PB/REC SW
6
9
IC1000
C1AA00000612
ANALOG SWITCH
2
3
4
Q1302
DECK
MUTING
CONT
Q1304
+B
SWITCH
(REC:H)
Q1303
SWITCH
Q1317
BEAT PROOF
LEVEL SWITCH
(DECK 2)
ERASE HEAD
L1301
+B
Q1309,
Q1310,
Q1312
BIAS
SWITCH
D1301
Q1313
SWITCH
+B
Q1
(SENSOR)
Q1305
SWITCH
S971 (MODE)
−B
S972 (HALF)
S975 (RECINH_F)
+B
IC971
CNB13030R2AU
PHOTO
INTERRUPTOR
Q1008,
Q1009
SWITCH
PHOTO:ON/OFF
KEY SW
(JOG VOL)
VR600
3
34
48
5
1
100
99
47
49
KEY2
POSITION
BP1
VOL_JOG
DECK2
DECK1
PHOTO
REC
DMT
C2BBGF000424
IC600
MICROPROCESSOR
SEG24
SEG1
GRID1
GRID8
57~80
88~81
RMT
29
MBP1
MBP2
XOUT
XIN
25
26
23
22
X600
µP
BEAT PROOF
CONTROL
Q608,Q609
XCIN
XCOUT
20
19
X601
FL DISPLAY
FL600
FROM POWER
TRANSFORMER
Z602
(REMOTE SENSOR)


5(3)
7(1)
IC501
C0AABB000117
DUAL OP AMP
Q710
(Q711)
MUTING SWITCH
Q721
(Q720)
AGC
Q718(Q719)
MUTING SWITCH
HP
Q704
MUTING CONTROL
Q509
CURRENT LIMITING
SUB+B
Q502
STABILIZER
Q508
VOLTAGE REGULATOR
+B
Q500
SWITCH
D539~
D541
Q1000
SWITCH
Q517
VOLTAGE REGULATOR
D517
+B
Q1314,Q1316
M
+B
Q1315
SWITCH
SWITCH (MOTOR SUPPLY)
PL
D951
Q510
MUTING SWITCH
D528
+B
Q503
CURRENT CONTROL
D518
Q507
STABILIZER
Q515,Q516
SWITCH (DCDET)
DCDET
Q904
MOTOR SWITCH
Q905
PLUNGER SWITCH
Q700~Q703
FAN MOTOR SUPPLY SWITCH
FAN
M
E
43
53
44
6
33
MOTOR
PLUNGER
MUTEA
/CD
DCDET
KEY SW
KEY1
4
KEY SW
SYNC
32
SYNC
C2BBGF000424
IC600
MICROPROCESSOR
MUTEH
45
MUTE_H
REC_LED AMBR
PCONT
55
41
PCONT
Q614
LED DRIVER
+B
D638
Q610
DECK SUPPLY SWITCH
Q611
PCONT SWITCH
+B


IC500
RSN314H41A-P
POWER AMP
IC2
4ch DRIVER
27 28 29 30 31 32 35
26 24 23 21 20 19 18
37 38 39 40 1 2 3 6 7
17 16 15 12 11 10 9 8
9 8 7 6 5 4 1 2 3
HI_LIN
HI_RIN
IN GND
LO_LIN
LO_RIN
GND
-VCCM
LO_ROUT
AC DET
LO_LOUT
HI_ROUT
-VCC
+VCC
HI_LOUT
14 13 12 11 10 9 8 7 6 5 4 3 2 1
RCH
D508
Q717(Q716)
MUTING SWITCH
FILTER
LCH
JK302
HIGH CH
(6Ω)
Q715(Q714)
MUTING SWITCH
FILTER
LCH
JK301
LOW CH
(6Ω)
DCDET
FAN
KEY SW
HP
RCH
JK600
HEADPHONE
MUTE_H
Q519
MUTING SWITCH
SYNC
Q578
SWITCH
Q514
+B
VOLTAGE REGULATOR
D524
Q577
+B
SYS 6V REGULATOR
D579~D581
T502
SUB-TRANSFORMER
T501
+B
Q505,Q506
SUPPLY SWITCH/ CURRENT CONTROL
DCDET
D500
Q501
VOLTAGE REGULATOR
D584,D587~D589
FP501
MAIN TRANSFORMER
Z501
RL501
F1
JK501
AC INLET
SUB+B
Q579
−B
-VP VOLTAGE REGULATOR
FP502
+B
TO FL DISPLAY
Q575
PCONT
ECONOMY SWITCH
E501

SIGNAL LINES

⇨ : MAIN SIGNAL LINE	➡ : AM SIGNAL LINE	▨ : CD SIGNAL LINE	▨ : PLAYBACK SIGNAL LINE
⇨ : FM SIGNAL LINE	➡ : AM OSC SIGNAL LINE	▨ : RECORD SIGNAL LINE	
⇨ : FM OSC SIGNAL LINE	➡ : FM /AM SIGNAL LINE	▥ : AUX SIGNAL LINE	

( ) Indicates the Pin No. of Right Channel.

NOTE : Signal Lines are applicable to the Left Channel only.

BA5948FPE2 (28P)
AN7326K (26P)



AN22004A-NF (32P)
LA1833NMNTLM (24P)
LC72131MDTRM (20P)
C1BB00000617 (30P)



MN662790RSC(80P)
C2BBGF000424(100P)



C0AABB000117



CNB13030R2AU



C1AA00000612



RSN314H41A-P



C0GAG0000007



2SC2058SPTA
2SC2784FTA



KRA102MTA
KRC102MTA
KRA110MTA



B1AAGC000006



B1AAAC000011
B1AAAD000013
KTC3199GRTA



KTA1046
KTC2026



B1ABGC000005
KTC3875GRTA
KRC101STA
KRC102STA
KRC103STA
2SA1037AKSTX
2SC2412KT96R
DTA114EKA146

DTA143XKA146
DTC143XKA146
DTC114EKA146



2SD0592ARA
2SD09650RA
KTA12710YTA
KTA1504GRTA
KTC32030YTA
KTA1267GRTA



KRC119STA



2SC3940ARA



2SK544F-AC



2SB0621AHA



B1AACF000063



B0ACCK000005


Cathode
Ca
Anode
A

UDZSTE177R5B
UDZSTE175R1B


Cathode
Ca
Anod
A

UDZSTE174R7B


Cathode
Anode
Ca
A

RL1N4003N02


Ca
Cathode
A
Anode

B0CAAD000002


Anode
A
Anode
Cathode
Ca
A

B0AACK000004
MA2C16500E


Ca
Cathode
A
Anode

RB501V-40


Cathode
Ca
Anode
A

KBL402G



LNJ801TPSJA


Anode
Cathode
A
Ca

B3CNE0000001


Anode
Cathode
Anode
A
Ca
A

MAZ80560ML


Cathode
Ca
Anode
A

B0BA5R600016
B0BA9R600002
B0BA6R600008
MAZ4150NLF
MAZ4150NMF
MTZJ24CTA


Ca
A
Cathode
Anode

1SS380TE-17


Cathode
Ca
Anode
A

B0EAKM000085


Ca
Cathode
A
Anode

B3NAA0000068



M CD LOADING P.C.B (REP3340A)



A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9
UPDOWN MOTOR
IC11
1
2
3
4
5
6
7
8
9
C11
C12
J13
S3
BOTTOMSW
Q1
CN1
1
14
S2
PLAYSW
S1
STOCKSW
J21
J11
J12
J15
J14
C22
LOADING MOTOR
C21
IC21
1
2
3
4
5
6
7
8
9
S4
OPENSW

A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9

D DECK P.C.B (REPX0350A)


PbF
Q1310
Q1309
J1029
J1028
C1315
CN1304
CN1303
J1009
J1035
J1053
Q1304
Q1303
C1317
C1319
C1316
C1312
R1329
R1331
C1311
L1301
C1318
R1333
R1330
R1327
C1314
D1301
J1012
R1332
R1328
Q1312
J1046
J1045
J1044
J1043
J1042
J1052
J1051
Q1305
R1316
R1314
L1302
J1010
R1309
J1008
Q1302
C1310
R1337
R1335
Q1313
C1321
Q1317
IC1000
R1334
R1336
C1320
C1324
R1305
R1313
J1007
R1338
Q1201
Q1101
R1207
R1209
R1107
R1109
R1106
R1105
R1110
C1110
C1206
R1205
C1210
R1206
J1005
J1033
J1001
J1036
J1399
C1323
C1322
C1325
CP1301
C1202
J1019
J1017
J1062
J1021
J1061
C1207
C1205
C1222
J1013
C1305
R1304
R1204
R1210
C1209
R1307
R1308
J1034
J1375
J1031
R1403
W308B
C1203
C1204
R1202
R1201
C1201
R1203
C1208
C1371
R1371
J1048
W1903
J1003
C1102
J1018
J1016
C1301
J1011
Q1316
R1345
R1342
J1002
J1006
Q1314
R1374
C1326
C1307
IC1001
C1221
C1223
C1308
R1341
J1032
J1004
J1041
CP1902
R1404
R1344
Q1315
R1343
R1405
J1014
C1121
R1101
C1101
R1302
C1108
J1306
R1303
J1020
C1105
C1303
C1122
C1302
J1015
R1103
C1107
C1304
C1123
R1104
R1401
R1318
R1402
C1103
R1102
C1106
C1109
C1104
E C B
+ -

E DECK MECHANISM P.C.B (REPX0321H)


S973
CR02
J13
J5
J30
S972
HALF
J11
J12
S971
MODE
J14
1
9
CS971
S975
RECINH_F
R973
J6
D971
J4
4 1
IC971
3 2
J10
J16
J8
J9
J7
R972
PL+
PL-
SOLENOID

B MAIN P.C.B (REPX0349A)


A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9
CN310
CN305
CN306
CN301
H307
Q500
Q1000
D501
D502
D301
D302
C552
C553
C550
C551
R591
R590
J300
J301
J302
J303
J298
J299
J272
J217
J249
J235
J236
J237
J264
R347
R348
J270
J222
J234
J277
J257
J263
J262
J258
J246
J266
J261
J271
J254
J233
J232
J242
J202
J21
J20
J241
J227
J226
J244
J229
J230
J260
J253
J265
J228
J211
J210
J209
J239
J252
J274
J231
J238
J132
J133
R407
R408
C407
R208
R207
C207
L111
L110
R216
R212
R313
C213
C212
C210
R211
C211
C209
R205
J13
R203
R204
C208
C215
R206
C217
C205
R215
C203
C206
R214
C403
R414
C405
C406
R415
J205
IC301
C306
R306
R312
C303
R311
C304
C305
C307
J204
J203
R416
R412
C413
C409
C412
R411
C411
C410
C408
R404
C415
R301
R302
J208
J206
C301
C302
C134
X103
IC102
R137
R136
R135
R134
R133
R117
R138
C133
R116
C132
R151
R129
C124
R132
R127
J105
R152
C113
R130
J104
C122
R122
C121
C141
R141
R145
C143
R142
R146
C144
C137
C138
C142
R123
R143
C118
C117
C139
R102
C116
C131
C119
C120
R121
C115
R120
J106
J108
J109
J110
J111
J112
J145
IC101
R124
X102
C149
C126
C106
J144
CF202
R119
C136
J114
J113
C114
R118
J116
C109
R131
J150
J120
C130
J107
R128
D101
R115
C112
C111
J119
C125
J101
C101
J102
OSC
IF
CF201
R105
J117
C104
C123
J115
C148
C129
C147
J118
Z102
PbF


G
H
I
J
K
L
M
CN310
IC102
IC101
IC301
Z120
Z101
Z102
CF201
CF202
Q101
Q106
X102
X103
OSC
IF
+B
V1
GND
GND
ANT
JK101
FM LOOP/
ANTENNA
AM LOOP/
ANTENNA
JK303
LCH
RCH
GND
AUX
H303/W303
JK302
HI_L
HI_R
LGND
RGND
HIGH-CH
SPEAKERS
JK301
LGND
RGND
LO_L
LO_R
LOW-CH
SPEAKERS
J273
J259
L102
L110
L111
D101
D301
D302

C PANEL P.C.B (REPX0349A)



A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9
CN607A
CN608
CN606
CN611
H604/W604
H600/W600
IC600
FL600
X600
X601
L603
L605
Q610
Q611
Q613
Q615
Q607
Q608
Q609
Q901
Q902
Q903
Q904
Q905
D620
D621
D630
D631
D632
D636
D637
D641
D642
D644
D645
D650
C602
C613
C614
C615
C616
C621
C622
C623
C624
C625
C626
C632
C633
C634
C635
C636
C637
C638
C639
C640
C641
C642
C643
C644
C645
C646
C651
C654
C655
C657
C659
C660
C664
R600
R624
R627
R628
R633
R634
R636
R638
R639
R644
R645
R646
R647
R648
R651
R652
R653
R654
R655
R656
R657
R658
R659
R661
R665
R666
R667
R668
R669
R670
R671
R672
R673
R674
R675
R676
R678
R679
R680
R681
R682
R683
R684
R685
R686
R687
R688
R690
R691
R695
R697
R699
R700
R701
R708
R901
R902
R903
R904
R905
R906
R907
R913
R914
R915
R916
R917
R918
R919
R920
R921
R922
R923
R930
J01
J02
J03
J04
J06
J08
J600
J603
J605
J610
J611
J612
J613
J614
J615
J617
J618
J619
J621
J622
J623
J624
J627
J628
J629
J631
J633
J634
J635
J636
J637
J639
J641
J642
J643
J644
J645
J646
J649
J650
J651
J652
J653
J654
J655
J656
J657
J658
J659
J663
J664
J665
J666
J667
J668
J671
J672
J673
J674
J675
J677
J679
J680
J682
J684
J686
J687
J688
J689
J690
J691
J693
J694
J695
J696
J697
J702
J703
J705
1
30
31
50
51
80
81
100
44
40
35
30
25
20
15
10
5


G
H
I
J
K
L
M
CN609B
CN608
CN607A
CN606
CN602
IC600
FL600
X600
X601
L603
Q903
Q607
Q608
Q609
Q901
Q902
Q613
Q615
Q905
Q904
D645
D630
D632
D636
D637
D640
D641
D642
D643
D644
D650
D620
D621
C601
C602
C613
C615
C616
C645
C621
C617
H600/W600
PbF

G POWER P.C.B (REPX0348A)



A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9
R703
R571
C517
C752
J702
R568
R705
D705
D706
Q701
Q505
C516
C701
R569
R704
R700
R574
D704
R702
R701
Q506
R706
R572
R573
Q501
Q502
Q700
R707
J70
R524
R520
R526
D540
D541
D539
Q703
C700
C5
Q509
R518
R519
C520
Q508
R711
R512
C703
R710
D520
D515
C521
J708
Q702
C704
R708
D525
R517
C751
C512
R511
R549
R536
C511
J709
R780
J751
J753
R709
J710
C702
J752
D500
J712
D707
R561
R562
J773
J754
J735
J775
J774
J777
J776
J783
J764
J789
J784
R566
J790
J785
C507
J791
R548
R546
R534
R550
R554
J765
J713
R547
J714
IC500
R505
C504
R506
C505
R545
R544
D508
J780
J795
D702
D703
J721
J738
Q715
R735
C715
R763
J718
C716
R762
R737
R779
C717
R739
C713
R743
R736
R747
R731
R738
Q714
C501
C502
C515
R532
R514
C509
R543
J781
J768
J720
J756
J766
J796
J769
J739
C503
C500
R515
C510
R542
R540
R533
C723
R730
C712
R541
J757
C720
R761
R760
J782
J787
D743
R732
R733
C714
J744
J758
J759
J788
J792
J770
J799
J747
CP501
J745
J798
J731
CN504
J743
E
C
B
1
2
3
4
5
6
7
8
9
10
11
12
13
14
1 2 3 4 5 6 7 8 9 10 11 12 13
8 7 6 5 4 3 2 1


G
H
I
J
K
L
M
Q514
R537
R567
C518
Q517
D517
C533
D701
D527
J771
R556
C528
R523
R539
R522
D524
J701
Q519
R507
Q503
R705
D705
D706
R568
J702
C701
R569
R700
R704
R702
R701
D704
Q516
R781
C526
C513
Q507
Q501
Q502
Q700
J703
Q515
R557
J704
D530
R513
D518
C514
R510
J750
J705
CN500
Q703
C537
R551
J706
D700
R509
D528
C700
R711
C536
Q510
R521
R770
R516
C730
R728
C731
R729
Q702
C703
R710
J708
J707
R565
H503/W503
C727
R759
R771
C704
R708
C530
C711
D526
C751
R709
J710
J772
D709
J711
R755
J751
J753
C702
J752
D500
J733
Q721
R753
R773
C709
R758
R772
D708
J773
R757
R750
R756
J712
D707
J754
J735
J786
J736
C535
C726
R774
C738
J774
R754
J776
J779
J778
C508
C728
C749
C710
R776
J764
C507
R727
Q720
J784
IC501
C750
J785
C729
R550
R554
J765
R721
C747
R752
C748
J714
J755
J780
R724
R775
C746
J715
D702
D703
J716
C745
R720
J763
J738
Q715
R735
R751
J717
C739
R766
R762
J718
C716
C715
R769
J719
R767
R765
C744
R737
R779
C506
R734
R722
C743
C737
Q711
C741
R739
C713
C717
C732
R777
Q710
Q719
R743
R736
R738
C742
R778
J769
R747
Q714
R731
R745
J722
R723
C723
R730
Q717
C724
J794
Q718
R725
C736
J740
J741
C712
J724
J723
R764
C740
C720
R732
R733
J760
R744
C705
R746
C725
R748
J787
D743
C714
R741
R740
E501
R749
R768
J744
J758
J761
J762
J763
J726
C721
J725
Q716
Q704
J727
R742
C722
J797
J730
J731
C733
R726
R713
J748
J746
J749
J732
PbF

A
B
C
D
E
F
G
1
2
3
4
5
6
7
8
9

A CD SERVO P.C.B (REPX0362A)


(RF)
TJ701
IC702
IC701
IC703
CN702
CN701
M701
TRV MOTOR
M702
SPL MOTOR
REST.SW
S701
Q701
X701
(VREF)
TJ702

N Tuner Pack P.C.B (REP1999B)


Q1
Q2
Q3
Q4
D1
D2
D3
*L11
*L10
*L12
L1
L2
J1
J2
J3
J4